
Sushy Documentation

Release 3.4.7.dev1

OpenStack Foundation

Aug 26, 2022

CONTENTS

1 About Sushy	1
2 Documentation	3
Python Module Index	85
Index	87

ABOUT SUSHY

Sushy is a Python library to communicate with [Redfish](#) based systems.

The goal of the library is to be extremely simple, small, have as few dependencies as possible and be very conservative when dealing with BMCs by issuing just enough requests to it (BMCs are very flaky).

Therefore, the scope of the library has been limited to what is supported by the [OpenStack Ironic](#) project. As the project grows and more features from [Redfish](#) are needed we can expand Sushy to fulfill those requirements.

- Free software: Apache license
- **Includes Redfish registry files licensed under** Creative Commons Attribution 4.0 License: <https://creativecommons.org/licenses/by/4.0/>
- Documentation: <https://docs.openstack.org/sushy/latest/>
- Usage: <https://docs.openstack.org/sushy/latest/reference/usage.html>
- Source: <https://opendev.org/openstack/sushy>
- Bugs: <https://storybook.openstack.org/#!/project/960>

2.1 Installing Sushy

At the command line:

```
$ pip install sushy
```

Or, if you have virtualenvwrapper installed:

```
$ mkvirtualenv sushy  
$ pip install sushy
```

2.2 Contributing to Sushy

2.2.1 How to contribute

If you would like to contribute to the development of OpenStack, you must follow the steps in this page:

<http://docs.openstack.org/infra/manual/developers.html>

If you already have a good understanding of how the system works and your OpenStack accounts are set up, you can skip to the development workflow section of this documentation to learn how changes to OpenStack should be submitted for review via the Gerrit tool:

<http://docs.openstack.org/infra/manual/developers.html#development-workflow>

Pull requests submitted through GitHub will be ignored.

Bugs should be filed in StoryBoard, not GitHub:

<https://storyboard.openstack.org/#!/project/960>

2.2.2 Running a Redfish emulator

Testing and/or developing Sushy without owning a real baremetal machine that supports the Redfish protocol is possible by running an emulator, the `sushy-tools` project ships with two emulators that can be used for this purpose. To install it run:

```
sudo pip install --user sushy-tools
```

Note: Installing the dependencies requires libvirt development files. For example, run the following command to install them on Fedora:

```
sudo dnf install -y libvirt-devel
```

Static emulator

After installing `sushy-tools` you will have a new CLI tool named `sushy-static`. This tool creates a HTTP server to serve any of the `Redfish` mockups. The files are static so operations like changing the boot device or the power state **will not** have any effect. But that should be enough for enabling people to test parts of the library.

To use `sushy-static` we need the Redfish mockup files that can be downloaded from <https://www.dmtf.org/standards/redfish>, for example:

```
wget https://www.dmtf.org/sites/default/files/standards/documents/DSP2043_
↪1.0.0.zip
```

After the download, extract the files somewhere in the file-system:

```
unzip DSP2043_1.0.0.zip -d <output-path>
```

Now run `sushy-static` pointing to those files. For example to serve the `DSP2043-server` mockup files, run:

```
sushy-static --mockup-files <output-path>/DSP2043-server
```

Libvirt emulator

The second emulator shipped by `sushy-tools` is the CLI tool named `sushy-emulator`. This tool starts a ReST API that users can use to interact with virtual machines using the Redfish protocol. So operations such as changing the boot device or the power state will actually affect the virtual machines. This allows users to test the library in a more dynamic way. To run it do

```
sushy-emulator

# Or, running with custom parameters
sushy-emulator --port 8000 --libvirt-uri "qemu:///system"
```

That's it, now you can test Sushy against the `http://localhost:8000` endpoint.

Enabling SSL

Both mockup servers supports [SSL](#) if you want Sushy with it. To set it up, first you need to generate key and certificate files with OpenSSL use following command:

```
openssl req -x509 -newkey rsa:2048 -keyout key.pem -out cert.pem -days 365
```

Start the mockup server passing the `--ssl-certificate` and `--ssl-key` parameters to it, for example:

```
sushy-emulator --ssl-key key.pem --ssl-certificate cert.pem
```

Now to connect with [SSL](#) to the server use the `verify` parameter pointing to the certificate file when instantiating Sushy, for example:

```
import sushy

# Note the HTTP"S"
s = sushy.Sushy('https://localhost:8000', verify='cert.pem', username='foo
→', password='bar')
```

2.3 Sushy Library Reference

2.3.1 Features

- Abstraction around the SystemCollection and System resources (Basic server identification and asset information)
- Systems power management (Both soft and hard; Including NMI injection)
- Changing systems boot device, frequency (Once or permanently) and mode (UEFI or BIOS)
- Virtual media management
- SessionManagement

Using Sushy

To use sushy in a project:

Specifying an authentication type

There are three authentication objects. By default we use `SessionOrBasicAuth`. Authentication Modes: `auth.SessionOrBasicAuth`: Use session based authentication. If we are unable to create a session we will fallback to basic authentication. `auth.BasicAuth`: Use basic authentication only. `auth.SessionAuth`: Use session based authentication only.

```
import logging

import sushy
from sushy import auth
```

(continues on next page)

(continued from previous page)

```
# Enable logging at DEBUG level
LOG = logging.getLogger('sushy')
LOG.setLevel(logging.DEBUG)
LOG.addHandler(logging.StreamHandler())

basic_auth = auth.BasicAuth(username='foo', password='bar')
session_auth = auth.SessionAuth(username='foo', password='bar')
session_or_basic_auth = auth.SessionOrBasicAuth(username='foo',
                                                password='bar')

s = sushy.Sushy('http://localhost:8000/redfish/v1',
               auth=basic_auth)

s = sushy.Sushy('http://localhost:8000/redfish/v1',
               auth=session_auth)

s = sushy.Sushy('http://localhost:8000/redfish/v1',
               auth=session_or_basic_auth)

# It is important to note that you can
# call sushy without supplying an
# authentication object. In that case we
# will use the SessionOrBasicAuth authentication
# object in an attempt to connect to all different
# types of redfish servers.
s = sushy.Sushy('http://localhost:8000/redfish/v1',
               username='foo',
               password='bar')
```

Creating and using a sushy system object

```
import logging

import sushy

# Enable logging at DEBUG level
LOG = logging.getLogger('sushy')
LOG.setLevel(logging.DEBUG)
LOG.addHandler(logging.StreamHandler())

s = sushy.Sushy('http://localhost:8000/redfish/v1',
               username='foo', password='bar')

# Get the Redfish version
print(s.redfish_version)

# Instantiate a system object
sys_inst = s.get_system('/redfish/v1/Systems/437XR1138R2')

# Using system collections
```

(continues on next page)

(continued from previous page)

```

# Instantiate a SystemCollection object
sys_col = s.get_system_collection()

# Print the ID of the systems available in the collection
print(sys_col.members_identities)

# Get a list of systems objects available in the collection
sys_col_insts = sys_col.get_members()

# Instantiate a system object, same as getting it directly
# from the s.get_system()
sys_inst = sys_col.get_member(sys_col.members_identities[0])

# Refresh the system collection object
#
# See below for more options on how to refresh resources.
sys_col.refresh()

# Using system actions

# Power the system ON
sys_inst.reset_system(sushy.RESET_ON)

# Get a list of allowed reset values
print(sys_inst.get_allowed_reset_system_values())

# Refresh the system object (with all its sub-resources)
sys_inst.refresh()

# Alternatively, you can only refresh the resource if it is stale by_
↳passing
# force=False:
sys_inst.refresh(force=False)

# A resource can be marked stale by calling invalidate. Note that its
# subresources won't be marked as stale, and thus they won't be refreshed_
↳by
# a call to refresh(force=False)
sys_inst.invalidate()

# Get the current power state
print(sys_inst.power_state)

# Set the next boot device to boot once from PXE in UEFI mode
sys_inst.set_system_boot_source(sushy.BOOT_SOURCE_TARGET_PXE,
                               enabled=sushy.BOOT_SOURCE_ENABLED_ONCE,
                               mode=sushy.BOOT_SOURCE_MODE_UEFI)

# Get the current boot source information
print(sys_inst.boot)

# Get a list of allowed boot source target values
print(sys_inst.get_allowed_system_boot_source_values())

```

(continues on next page)

(continued from previous page)

```
# Get the memory summary
print(sys_inst.memory_summary)

# Get the processor summary
print(sys_inst.processors.summary)
```

Creating and using a sushy manager object

```
import logging

import sushy

# Enable logging at DEBUG level
LOG = logging.getLogger('sushy')
LOG.setLevel(logging.DEBUG)
LOG.addHandler(logging.StreamHandler())

s = sushy.Sushy('http://localhost:8000/redfish/v1',
               username='foo', password='bar')

# Instantiate a manager object
mgr_inst = s.get_manager('BMC')

# Get the manager name & description
print(mgr_inst.name)
print(mgr_inst.description)

# Using manager collections

# Instantiate a ManagerCollection object
mgr_col = s.get_manager_collection()

# Print the ID of the managers available in the collection
print(mgr_col.members_identities)

# Get a list of manager objects available in the collection
mgr_insts = mgr_col.get_members()

# Instantiate a manager object, same as getting it directly
# from the s.get_manager()
mgr_inst = mgr_col.get_member(mgr_col.members_identities[0])

# Refresh the manager collection object
mgr_col.invalidate()
mgr_col.refresh()

# Using manager actions
```

(continues on next page)

(continued from previous page)

```
# Get supported graphical console types
print(mgr_inst.get_supported_graphical_console_types())

# Get supported serial console types
print(mgr_inst.get_supported_serial_console_types())

# Get supported command shell types
print(mgr_inst.get_supported_command_shell_types())

# Get a list of allowed manager reset values
print(mgr_inst.get_allowed_reset_manager_values())

# Reset the manager
mgr_inst.reset_manager(sushy.RESET_MANAGER_FORCE_RESTART)

# Refresh the manager object (with all its sub-resources)
mgr_inst.refresh(force=True)

# Using Virtual Media

# Instantiate a VirtualMediaCollection object
virtmedia_col = mgr_inst.virtual_media

# Print the ID of the VirtualMedia available in the collection
print(virtmedia_col.members_identities)

# Get a list of VirtualMedia objects available in the collection
virtmedia_insts = virtmedia_col.get_members()

# Instantiate a VirtualMedia object
virtmedia_inst = virtmedia_col.get_member(
    virtmedia_col.members_identities[0])

# Print out some of the VirtualMedia properties
print(virtmedia_inst.name,
      virtmedia_inst.media_types)

# Insert virtual media (invalidates virtmedia_inst contents)
virtmedia_inst.insert_media('https://www.dmtf.org/freeImages/Sardine.img')

# Refresh the resource to load actual contents
virtmedia_inst.refresh()

# Print out some of the VirtualMedia properties
print(virtmedia_inst.image,
      virtmedia_inst.image_path,
      virtmedia_inst.inserted,
      virtmedia_inst.write_protected)

# ... Boot the system off the virtual media...

# Eject virtual media (invalidates virtmedia_inst contents)
virtmedia_inst.eject_media()
```

Creating and using a sushy client with Sessions

```
import logging

import sushy

# Enable logging at DEBUG level
LOG = logging.getLogger('sushy')
LOG.setLevel(logging.DEBUG)
LOG.addHandler(logging.StreamHandler())

s = sushy.Sushy('http://localhost:8000/redfish/v1',
               username='foo', password='bar')

# Get the ComputerSystem object (if there is only one), otherwise
# the identity must be provided as a path to the system.
system = s.get_system()

# A session is created automatically for you.
# Print the boot field in the ComputerSystem.
print(system.boot)

# Upon session timeout, Sushy recreates the session based upon
# provided credentials. If this fails, an exception is raised.

# Explicitly request a session_key and session_uri.
# This is not stored, but may be useful.
session_key, session_uri = s.create_session(username='foo',
                                           password='bar')

# Retrieve the session
session = s.get_session(session_uri)

# Delete the session
session.delete()
```

Using OEM extensions

Before running this example, please make sure you have a Redfish BMC that includes the OEM piece for a specific vendor, as well as the Sushy OEM extension package installed in the system for the same vendor.

You can check the presence of the OEM extension within each Redfish resource by specifying the vendor ID and search for them.

In the following example, we are looking up “Acme” vendor extension to Redfish Manager resource.

```
import sushy

root = sushy.Sushy('http://localhost:8000/redfish/v1')

# Instantiate a system object
system = root.get_system('/redfish/v1/Systems/437XR1138R2')

print('Working on system resource %s' % system.identity)
```

(continues on next page)

(continued from previous page)

```
for manager in system.managers:

    print('Using System manager %s' % manager.identity)

    # Get a list of OEM extension names for the system manager
    oem_vendors = manager.oem_vendors

    print('Listing OEM extension name(s) for the System '
          'manager %s' % manager.identity )

    print(*oem_vendors, sep="\n")

    try:
        manager_oem = manager.get_oem_extension('Acme')

    except sushy.exceptions.OEMExtensionNotFoundError:
        print('ERROR: Acme OEM extension not found in '
              'Manager %s' % manager.identity)
        continue

    print('%s is an OEM extension of Manager %s'
          % (manager_oem.get_extension(), manager.identity))

    # set boot device to a virtual media device image
    manager_oem.set_virtual_boot_device(sushy.VIRTUAL_MEDIA_CD,
                                       manager=manager)
```

If you do not have any real baremetal machine that supports the Redfish protocol you can look at the [Contributing to Sushy](#) page to learn how to run a Redfish emulator.

For the OEM extension example, presently, both of the emulators (static/dynamic) do not expose any OEM; as a result, users may need to add manually some OEM resources to emulators' templates. It may be easier to start with a static emulator.

2.3.2 Missing Features

These are some features that sushy is presently missing.

- Collect sensor data (Health state, temperature, fans etc...)
- System disk size
- Serial console

2.3.3 Sushy Python API Reference

- modindex

sushy

sushy package

Subpackages

sushy.resources package

Subpackages

sushy.resources.chassis package

Subpackages

sushy.resources.chassis.power package

Submodules

sushy.resources.chassis.power.constants module

sushy.resources.chassis.power.constants.INPUT_TYPE_AC = 'ac'
Alternating Current (AC) input range.

sushy.resources.chassis.power.constants.INPUT_TYPE_DC = 'dc'
Direct Current (DC) input range.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_AC120 = 'ac120v'
AC 120V nominal input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_AC240 = 'ac240v'
AC 240V nominal input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_AC277 = 'ac277v'
AC 277V nominal input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_ACDCWIDE = 'acdc'
Wide range AC or DC input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_ACHIGH = 'achigh'
277V AC input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_ACLOW = 'aclowli'
100-127V AC input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_ACMID = 'acmidli'
200-240V AC input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_ACWIDE = 'acwide'
Wide range AC input.

sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_DC240 = 'dc240v'
DC 240V nominal input.

`sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_DC380 = 'dc380v'`
 High Voltage DC input (380V).

`sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_DCNEG48 = 'dcneg48'`
 -48V DC input.

`sushy.resources.chassis.power.constants.LINE_INPUT_VOLTAGE_TYPE_UNKNOWN = 'unknown'`
 The power supply line input voltage type cannot be determined.

`sushy.resources.chassis.power.constants.POWER_SUPPLY_TYPE_AC = 'ac'`
 Alternating Current (AC) power supply.

`sushy.resources.chassis.power.constants.POWER_SUPPLY_TYPE_ACDC = 'acdc'`
 Power Supply supports both DC or AC.

`sushy.resources.chassis.power.constants.POWER_SUPPLY_TYPE_DC = 'dc'`
 Direct Current (DC) power supply.

`sushy.resources.chassis.power.constants.POWER_SUPPLY_TYPE_UNKNOWN = 'unknown'`
 The power supply type cannot be determined.

sushy.resources.chassis.power.mappings module

sushy.resources.chassis.power.power module

class `sushy.resources.chassis.power.power.InputRangeListField` (**args*, ***kwargs*)

Bases: `sushy.resources.base.ListField`

This type describes an input range for a power supply

input_type = `<sushy.resources.base.MappedField object>`
 The Input type (AC or DC)

maximum_frequency_hz = `<sushy.resources.base.Field object>`
 The maximum line input frequency at which this power supply input range is effective

maximum_voltage = `<sushy.resources.base.Field object>`
 The maximum line input voltage at which this power supply input range is effective

minimum_frequency_hz = `<sushy.resources.base.Field object>`
 The minimum line input frequency at which this power supply input range is effective

minimum_voltage = `<sushy.resources.base.Field object>`
 The minimum line input voltage at which this power supply input range is effective

output_wattage = `<sushy.resources.base.Field object>`
 The maximum capacity of this Power Supply when operating in this input range

class `sushy.resources.chassis.power.power.Power` (*connector*, *path=""*, *redfish_version=None*, *registries=None*, *reader=None*, *json_doc=None*)

Bases: `sushy.resources.base.ResourceBase`

This class represents a Power resource.

identity = <sushy.resources.base.Field object>

Identifier of the resource

name = <sushy.resources.base.Field object>

The name of the resource

power_supplies = <sushy.resources.chassis.power.power.PowerSupplyListField object>

Details of a power supplies associated with this system or device

```
class sushy.resources.chassis.power.power.PowerSupplyListField(*args,  
                                                                **kwargs)
```

Bases: *sushy.resources.base.ListField*

The power supplies associated with this Power resource

firmware_version = <sushy.resources.base.Field object>

The firmware version for this Power Supply

identity = <sushy.resources.base.Field object>

Identifier of the Power Supply

indicator_led = <sushy.resources.base.MappedField object>

The state of the indicator LED, used to identify the power supply

input_ranges = <sushy.resources.chassis.power.power.InputRangeListField object>

This is the input ranges that the power supply can use

last_power_output_watts = <sushy.resources.base.Field object>

The average power output of this Power Supply

line_input_voltage = <sushy.resources.base.Field object>

The line input voltage at which the Power Supply is operating

line_input_voltage_type = <sushy.resources.base.MappedField object>

The line voltage type supported as an input to this Power Supply

manufacturer = <sushy.resources.base.Field object>

This is the manufacturer of this power supply

model = <sushy.resources.base.Field object>

The model number for this Power Supply

name = <sushy.resources.base.Field object>

Name of the Power Supply

part_number = <sushy.resources.base.Field object>

The part number for this Power Supply

power_capacity_watts = <sushy.resources.base.Field object>

The maximum capacity of this Power Supply

power_supply_type = <sushy.resources.base.MappedField object>

The Power Supply type (AC or DC)

serial_number = <sushy.resources.base.Field object>

The serial number for this Power Supply

spare_part_number = <sushy.resources.base.Field object>

The spare part number for this Power Supply

status = <sushy.resources.common.StatusField object>
Status of the sensor

Module contents

sushy.resources.chassis.thermal package

Submodules

sushy.resources.chassis.thermal.constants module

sushy.resources.chassis.thermal.constants.FAN_READING_UNIT_PERCENTAGE = 'Percent'
Indicates that the fan reading and thresholds are measured in percentage

sushy.resources.chassis.thermal.constants.FAN_READING_UNIT_RPM = 'RPM'
Indicates that the fan reading and thresholds are measured in rotations per minute.

sushy.resources.chassis.thermal.mappings module

sushy.resources.chassis.thermal.thermal module

class sushy.resources.chassis.thermal.thermal.FansListField(*args,
**kwargs)

Bases: *sushy.resources.chassis.thermal.thermal.Sensor*

The Fan device/s associated with Thermal.

indicator_led = <sushy.resources.base.MappedField object>
The state of the indicator LED, used to identify the fan

manufacturer = <sushy.resources.base.Field object>
This is the manufacturer of this Fan

max_reading_range = <sushy.resources.base.Field object>
Maximum value for Reading

min_reading_range = <sushy.resources.base.Field object>
Minimum value for Reading

model = <sushy.resources.base.Field object>
The model of this Fan

part_number = <sushy.resources.base.Field object>
Part number of this Fan

reading = <sushy.resources.base.Field object>
Current Fan Speed

reading_units = <sushy.resources.base.MappedField object>
Units in which the reading and thresholds are measured

serial_number = <sushy.resources.base.Field object>
Serial number of this Fan

class `sushy.resources.chassis.thermal.thermal.Sensor` (**args*, ***kwargs*)

Bases: `sushy.resources.base.ListField`

The sensor device/s associated with Thermal.

identity = `<sushy.resources.base.Field object>`

Identifier of the Sensor

lower_threshold_critical = `<sushy.resources.base.Field object>`

Below normal range but not yet fatal

lower_threshold_fatal = `<sushy.resources.base.Field object>`

Below normal range and is fatal

lower_threshold_non_critical = `<sushy.resources.base.Field object>`

Below normal range

name = `<sushy.resources.base.Field object>`

The name of this sensor

physical_context = `<sushy.resources.base.Field object>`

Area or device associated with this sensor

status = `<sushy.resources.common.StatusField object>`

Status of the sensor

upper_threshold_critical = `<sushy.resources.base.Field object>`

Above normal range but not yet fatal

upper_threshold_fatal = `<sushy.resources.base.Field object>`

Above normal range and is fatal

upper_threshold_non_critical = `<sushy.resources.base.Field object>`

Above normal range

class `sushy.resources.chassis.thermal.thermal.TemperaturesListField` (**args*, ***kwargs*)

Bases: `sushy.resources.chassis.thermal.thermal.Sensor`

The Temperature device/s associated with Thermal.

max_allowable_operating_value = `<sushy.resources.base.Field object>`

Maximum allowable operating temperature for this equipment

max_reading_range_temp = `<sushy.resources.base.Field object>`

Maximum value for ReadingCelsius

min_allowable_operating_value = `<sushy.resources.base.Field object>`

Minimum allowable operating temperature for this equipment

min_reading_range_temp = `<sushy.resources.base.Field object>`

Minimum value for ReadingCelsius

reading_celsius = `<sushy.resources.base.Field object>`

Temperature

sensor_number = `<sushy.resources.base.Field object>`

A numerical identifier to represent the temperature sensor

```
class sushy.resources.chassis.thermal.thermal.Thermal (connector,
                                                    path="", red-
                                                    fish_version=None,
                                                    registries=None,
                                                    reader=None,
                                                    json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

This class represents a Thermal resource.

```
fans = <sushy.resources.chassis.thermal.thermal.FansListField object>
    A tuple of Fan identities
```

```
identity = <sushy.resources.base.Field object>
    Identifier of the resource
```

```
name = <sushy.resources.base.Field object>
    The name of the resource
```

```
status = <sushy.resources.common.StatusField object>
    Status of the resource
```

```
temperatures = <sushy.resources.chassis.thermal.thermal.TemperaturesListField object>
    A tuple of Temperature identities
```

Module contents

Submodules

sushy.resources.chassis.chassis module

```
class sushy.resources.chassis.chassis.ActionsField (*args, **kwargs)
    Bases: sushy.resources.base.CompositeField
```

```
reset = <sushy.resources.common.ResetActionField object>
```

```
class sushy.resources.chassis.chassis.Chassis (connector, identity, red-
                                                    fish_version=None, reg-
                                                    istries=None)
```

Bases: *sushy.resources.base.ResourceBase*

Chassis resource

The Chassis represents the physical components of a system. This resource represents the sheet-metal confined spaces and logical zones such as racks, enclosures, chassis and all other containers.

```
asset_tag = <sushy.resources.base.Field object>
    The user assigned asset tag of this chassis
```

```
chassis_type = <sushy.resources.base.MappedField object>
    The type of physical form factor of the chassis
```

```
depth_mm = <sushy.resources.base.Field object>
    Depth in millimeters The depth of the chassis. The value of this property shall represent the depth (length) of the chassis (in millimeters) as specified by the manufacturer.
```

description = <sushy.resources.base.Field object>

The chassis description

get_allowed_reset_chassis_values ()

Get the allowed values for resetting the chassis.

Returns A set of allowed values.

Raises MissingAttributeError, if Actions/#Chassis.Reset attribute not present.

height_mm = <sushy.resources.base.Field object>

Height in millimeters The height of the chassis. The value of this property shall represent the height of the chassis (in millimeters) as specified by the manufacturer.

identity = <sushy.resources.base.Field object>

Identifier for the chassis

indicator_led = <sushy.resources.base.MappedField object>

The state of the indicator LED, used to identify the chassis

property managers

A list of managers for this chassis.

Returns a list of *Manager* objects representing the managers that manage this chassis.

Raises MissingAttributeError if '@odata.id' field is missing.

Returns A list of *Manager* instances

manufacturer = <sushy.resources.base.Field object>

The manufacturer of this chassis

model = <sushy.resources.base.Field object>

The model number of the chassis

name = <sushy.resources.base.Field object>

The chassis name

part_number = <sushy.resources.base.Field object>

The part number of the chassis

physical_security = <sushy.resources.chassis.chassis.PhysicalSecurity object>

PhysicalSecurity This value of this property shall contain the sensor state of the physical security.

property power

Property to reference *Power* instance

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done). Here the actual refresh of the sub-resource happens, if stale.

power_state = <sushy.resources.base.MappedField object>

The current power state of the chassis

reset_chassis (*value*)

Reset the chassis.

Parameters *value* – The target value.

Raises InvalidParameterValueError, if the target value is not allowed.

serial_number = <sushy.resources.base.Field object>

The serial number of the chassis

set_indicator_led (*state*)

Set IndicatorLED to the given state.

Parameters *state* – Desired LED state, lit (INDICATOR_LED_LIT), blinking (INDICATOR_LED_BLINKING), off (INDICATOR_LED_OFF)

Raises InvalidParameterValueError, if any information passed is invalid.

sku = <sushy.resources.base.Field object>

Stock-keeping unit number (SKU) The value of this property shall be the stock-keeping unit number for this chassis.

status = <sushy.resources.common.StatusField object>

Status and Health This property describes the status and health of the chassis and its children.

property systems

A list of systems residing in this chassis.

Returns a list of *System* objects representing systems being mounted in this chassis/cabinet.

Raises MissingAttributeError if '@odata.id' field is missing.

Returns A list of *System* instances

property thermal

Property to reference *Thermal* instance

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done). Here the actual refresh of the sub-resource happens, if stale.

uuid = <sushy.resources.base.Field object>

The Universal Unique Identifier (UUID) for this Chassis.

weight_kg = <sushy.resources.base.Field object>

Weight in kilograms The value of this property shall represent the published mass (commonly referred to as weight) of the chassis (in kilograms).

width_mm = <sushy.resources.base.Field object>

Width in millimeters The value of this property shall represent the width of the chassis (in millimeters) as specified by the manufacturer.

```
class sushy.resources.chassis.chassis.ChassisCollection (connector,
                                                    path, red-
                                                    fish_version=None,
                                                    reg-
                                                    istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

```
class sushy.resources.chassis.chassis.PhysicalSecurity (*args,
                                                         **kwargs)
```

Bases: *sushy.resources.base.CompositeField*

intrusion_sensor = <sushy.resources.base.MappedField object>

IntrusionSensor This indicates the known state of the physical security sensor, such as if it is hardware intrusion detected.

intrusion_sensor_number = <sushy.resources.base.Field object>

A numerical identifier to represent the physical security sensor

`intrusion_sensor_re_arm = <sushy.resources.base.MappedField object>`

This indicates how the Normal state to be restored

sushy.resources.chassis.constants module

`sushy.resources.chassis.constants.CHASSIS_INTRUSION_SENSOR_HARDWARE_INTRUSION = HardwareIntrusion`

A door, lock, or other mechanism protecting the internal system hardware from being accessed is detected as being in an insecure state.

`sushy.resources.chassis.constants.CHASSIS_INTRUSION_SENSOR_NORMAL = 'normal chassis'`
No abnormal physical security conditions are detected at this time

`sushy.resources.chassis.constants.CHASSIS_INTRUSION_SENSOR_RE_ARM_AUTOMATIC = 'automatic'`
Automatic

This sensor would be restored to the Normal state automatically as no abnormal physical security conditions are detected.

`sushy.resources.chassis.constants.CHASSIS_INTRUSION_SENSOR_RE_ARM_MANUAL = 'manual'`
This sensor would be restored to the Normal state by a manual re-arm

`sushy.resources.chassis.constants.CHASSIS_INTRUSION_SENSOR_TAMPERING_DETECTED = 'tampering'`
Physical tampering of the monitored entity is detected

`sushy.resources.chassis.constants.CHASSIS_TYPE_BLADE = 'blade chassis type'`
Blade

An enclosed or semi-enclosed, typically vertically-oriented, system chassis which must be plugged into a multi-system chassis to function normally.

`sushy.resources.chassis.constants.CHASSIS_TYPE_CARD = 'card chassis type'`
Card

A loose device or circuit board intended to be installed in a system or other enclosure.

`sushy.resources.chassis.constants.CHASSIS_TYPE_CARTRIDGE = 'cartridge chassis type'`
Cartridge

A small self-contained system intended to be plugged into a multi-system chassis

`sushy.resources.chassis.constants.CHASSIS_TYPE_COMPONENT = 'component chassis type'`
Component

A small chassis, card, or device which contains devices for a particular subsystem or function.

`sushy.resources.chassis.constants.CHASSIS_TYPE_DRAWER = 'drawer chassis type'`
Drawer

An enclosed or semi-enclosed, typically horizontally-oriented, system chassis which may be slid into a multi-system chassis.

`sushy.resources.chassis.constants.CHASSIS_TYPE_ENCLOSURE = 'enclosure chassis type'`
A generic term for a chassis that does not fit any other description

`sushy.resources.chassis.constants.CHASSIS_TYPE_EXPANSION = 'expansion chassis type'`
A chassis which expands the capabilities or capacity of another chassis

`sushy.resources.chassis.constants.CHASSIS_TYPE_IP_BASED_DRIVE = 'IP based drive'`
A chassis in a drive form factor with IP-based network connections

`sushy.resources.chassis.constants.CHASSIS_TYPE_MODULE = 'module chassis type'`
Module

A small, typically removable, chassis or card which contains devices for a particular subsystem or function.

`sushy.resources.chassis.constants.CHASSIS_TYPE_OTHER = 'other chassis type'`
A chassis that does not fit any of these definitions

`sushy.resources.chassis.constants.CHASSIS_TYPE_POD = 'pod chassis type'`
Pod

A collection of equipment racks in a large, likely transportable, container

`sushy.resources.chassis.constants.CHASSIS_TYPE_RACK = 'rack chassis type'`
An equipment rack, typically a 19-inch wide freestanding unit

`sushy.resources.chassis.constants.CHASSIS_TYPE_RACK_GROUP = 'rack group chassis'`
A group of racks which form a single entity or share infrastructure

`sushy.resources.chassis.constants.CHASSIS_TYPE_RACK_MOUNT = 'rack mount chassis'`
RackMount

A single system chassis designed specifically for mounting in an equipment rack.

`sushy.resources.chassis.constants.CHASSIS_TYPE_ROW = 'row chassis type'`
A collection of equipment rack

`sushy.resources.chassis.constants.CHASSIS_TYPE_SHELF = 'shelf chassis type'`
Shelf

An enclosed or semi-enclosed, typically horizontally-oriented, system chassis which must be plugged into a multi-system chassis to function normally.

`sushy.resources.chassis.constants.CHASSIS_TYPE_SIDE CAR = 'sidecar chassis type'`
Sidecar

A chassis that mates mechanically with another chassis to expand its capabilities or capacity.

`sushy.resources.chassis.constants.CHASSIS_TYPE_SLED = 'sled chassis type'`
Sled

An enclosed or semi-enclosed, system chassis which must be plugged into a multi-system chassis to function normally similar to a blade type chassis.

`sushy.resources.chassis.constants.CHASSIS_TYPE_STAND_ALONE = 'stand alone chassis'`
StandAlone

A single, free-standing system, commonly called a tower or desktop chassis.

`sushy.resources.chassis.constants.CHASSIS_TYPE_STORAGE_ENCLOSURE = 'storage enclosure'`
A chassis which encloses storage

`sushy.resources.chassis.constants.CHASSIS_TYPE_ZONE = 'zone chassis type'`
Zone

A logical division or portion of a physical chassis that contains multiple devices or systems that cannot be physically separated.

sushy.resources.chassis.mappings module

Module contents

sushy.resources.compositionservice package

Submodules

sushy.resources.compositionservice.compositionservice module

class sushy.resources.compositionservice.compositionservice.**CompositionService** (*ca*

Bases: *sushy.resources.base.ResourceBase*

allow_overprovisioning = <sushy.resources.base.Field object>

This indicates whether this service is allowed to overprovision

allow_zone_affinity = <sushy.resources.base.Field object>

This indicates whether a client is allowed to request that given composition request

description = <sushy.resources.base.Field object>

The composition service description

identity = <sushy.resources.base.Field object>

The composition service identity string

name = <sushy.resources.base.Field object>

The composition service name

property resource_blocks

Property to reference *ResourceBlockCollection* instance

property resource_zones

Property to reference *ResourceZoneCollection* instance

service_enabled = <sushy.resources.base.Field object>

The status of composition service is enabled

status = <sushy.resources.common.StatusField object>

The status of composition service

sushy.resources.compositionservice.constants module

sushy.resources.compositionservice.mappings module

sushy.resources.compositionservice.resourceblock module

class `sushy.resources.compositionservice.resourceblock.CompositionStatusField` (*a
**/

Bases: `sushy.resources.base.CompositeField`

composition_state = `<sushy.resources.base.MappedField object>`
Inform the client, state of the resource block

max_compositions = `<sushy.resources.base.Field object>`
The maximum number of compositions

number_of_compositions = `<sushy.resources.base.Field object>`
The number of compositions

reserved_state = `<sushy.resources.base.Field object>`
Inform the resource block has been identified by a client

sharing_capable = `<sushy.resources.base.Field object>`
Indicates if this Resource Block is capable of participating in multiple compositions simultaneously

sharing_enabled = `<sushy.resources.base.Field object>`
Indicates if this Resource Block is allowed to participate in multiple compositions simultaneously

class `sushy.resources.compositionservice.resourceblock.ResourceBlock` (*connector,*
iden-
tity,
red-
fish_version=None,
reg-
istries=None)

Bases: `sushy.resources.base.ResourceBase`

composition_status = `<sushy.resources.compositionservice.resourceblock.Compo`
The composition state of resource block

description = `<sushy.resources.base.Field object>`
The resource block description

identity = `<sushy.resources.base.Field object>`
The resource block identity string

name = `<sushy.resources.base.Field object>`
The resource block name

resource_block_type = `<sushy.resources.base.MappedField object>`
The type of resource block

status = `<sushy.resources.common.StatusField object>`
The status of resource block

```
class sushy.resources.compositionservice.resourceblock.ResourceBlockCollection (ca
```

Bases: *sushy.resources.base.ResourceCollectionBase*

```
description = <sushy.resources.base.Field object>
```

The resource block collection description

```
name = <sushy.resources.base.Field object>
```

The resource block collection name

sushy.resources.compositionservice.resourcezone module

```
class sushy.resources.compositionservice.resourcezone.LinksField (*args,
```

```
**kwargs)
```

Bases: *sushy.resources.base.CompositeField*

```
endpoints = <sushy.resources.base.Field object>
```

The references to the endpoints that are contained in this zone

```
involved_switches = <sushy.resources.base.Field object>
```

The references to the switches in this zone

```
resource_blocks = <sushy.resources.base.Field object>
```

The references to the Resource Blocks that are used in this zone

```
class sushy.resources.compositionservice.resourcezone.ResourceZone (connector,
```

```
identity,
```

```
red-
```

```
fish_version=None,
```

```
reg-
```

```
istries=None)
```

Bases: *sushy.resources.base.ResourceBase*

```
description = <sushy.resources.base.Field object>
```

The resources zone description

```
identity = <sushy.resources.base.Field object>
```

The resource zone identity string

```
links = <sushy.resources.compositionservice.resourcezone.LinksField object>
```

The references to other resources that are related to this resource

```
name = <sushy.resources.base.Field object>
```

The resource zone name

```
status = <sushy.resources.common.StatusField object>
```

The resource zone status

class `sushy.resources.compositionservice.resourcezone.ResourceZoneCollection` (*conn
iden-
tity,
red-
fish_
reg
istrie*)

Bases: `sushy.resources.base.ResourceCollectionBase`

description = `<sushy.resources.base.Field object>`
The resource zone collection description

name = `<sushy.resources.base.Field object>`
The resource zone collection name

Module contents

sushy.resources.fabric package

Submodules

sushy.resources.fabric.constants module

`sushy.resources.fabric.constants.ADDRESS_STATE_DEPRECATED` = `'Deprecated'`
This address is currently within it's valid lifetime, but is now outside of it's preferred lifetime as defined in RFC 4862.

`sushy.resources.fabric.constants.ADDRESS_STATE_FAILED` = `'Failed'`
This address has failed Duplicate Address Detection testing as defined in RFC 4862 section 5.4 and is not currently in use.

`sushy.resources.fabric.constants.ADDRESS_STATE_PREFERRED` = `'Preferred'`
This address is currently within both it's valid and preferred lifetimes as defined in RFC 4862.

`sushy.resources.fabric.constants.ADDRESS_STATE_TENTATIVE` = `'Tentative'`
This address is currently undergoing Duplicate Address Detection testing as defined in RFC 4862 section 5.4.

sushy.resources.fabric.endpoint module

class `sushy.resources.fabric.endpoint.ConnectedEntitiesListField` (**args,
**kwargs*)

Bases: `sushy.resources.base.ListField`

All the entities connected to this endpoint.

entity_pci_id = `<sushy.resources.fabric.endpoint.PciIdField object>`
The PCI ID of the connected entity.

entity_role = `<sushy.resources.base.MappedField object>`
The role of the connected entity.

entity_type = <sushy.resources.base.MappedField object>

The type of the connected entity.

identifiers = <sushy.resources.common.IdentifiersListField object>

Identifiers for the remote entity.

pci_class_code = <sushy.resources.base.Field object>

The Class Code, Subclass code, and Programming Interface code of this PCIe function.

pci_function_number = <sushy.resources.base.Field object>

The PCI ID of the connected entity.

```
class sushy.resources.fabric.endpoint.Endpoint(connector, path="", red-
                                         fish_version=None,
                                         registries=None,
                                         reader=None,
                                         json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

This class represents a fabric endpoint.

It represents the properties of an entity that sends or receives protocol defined messages over a transport.

IP_transport_details = <sushy.resources.fabric.endpoint.IPTransportDetailsListField object>

This array contains details for each IP transport supported by this endpoint. The array structure can be used to model multiple IP addresses for this endpoint.

connected_entities = <sushy.resources.fabric.endpoint.ConnectedEntitiesListField object>

All entities connected to this endpoint.

description = <sushy.resources.base.Field object>

The endpoint description

endpoint_protocol = <sushy.resources.base.MappedField object>

The protocol supported by this endpoint.

host_reservation_memory_bytes = <sushy.resources.base.Field object>

The amount of memory in Bytes that the Host should allocate to connect to this endpoint.

identity = <sushy.resources.base.Field object>

Identifier for the endpoint

name = <sushy.resources.base.Field object>

The endpoint name

pci_id = <sushy.resources.fabric.endpoint.PciIdField object>

The PCI ID of the endpoint.

status = <sushy.resources.common.StatusField object>

The endpoint status

```
class sushy.resources.fabric.endpoint.EndpointCollection(connector,
                                                         path, red-
                                                         fish_version=None,
                                                         reg-
                                                         istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

Represents a collection of endpoints associated with the fabric.

```
class sushy.resources.fabric.endpoint.IPTransportDetailsListField(*args,  
                                                                **kwargs)
```

Bases: *sushy.resources.base.ListField*

IP transport details

This array contains details for each IP transport supported by this endpoint. The array structure can be used to model multiple IP addresses for this endpoint.

```
ipv4_address = <sushy.resources.fabric.endpoint.IPv4AddressField object>  
    The IPv4 address object.
```

```
ipv6_address = <sushy.resources.fabric.endpoint.IPv6AddressField object>  
    The IPv6 address object.
```

```
port = <sushy.resources.base.Field object>  
    The UDP or TCP port number used by the Endpoint.
```

```
transport_protocol = <sushy.resources.base.MappedField object>  
    The protocol used by the connection entity.
```

```
class sushy.resources.fabric.endpoint.IPv4AddressField(*args,  
                                                       **kwargs)
```

Bases: *sushy.resources.base.CompositeField*

```
address = <sushy.resources.base.Field object>  
    This is the IPv4 Address.
```

```
address_origin = <sushy.resources.base.MappedField object>  
    This indicates how the address was determined.
```

```
gateway = <sushy.resources.base.Field object>  
    This is the IPv4 gateway for this address.
```

```
subnet_mask = <sushy.resources.base.Field object>  
    This is the IPv4 Subnet mask.
```

```
class sushy.resources.fabric.endpoint.IPv6AddressField(*args,  
                                                       **kwargs)
```

Bases: *sushy.resources.base.CompositeField*

```
address = <sushy.resources.base.Field object>  
    This is the IPv6 Address.
```

```
address_origin = <sushy.resources.base.MappedField object>  
    This indicates how the address was determined.
```

```
address_state = <sushy.resources.base.MappedField object>  
    The current state of this address as defined in RFC 4862.
```

```
prefix_length = <sushy.resources.base.Field object>  
    This is the IPv6 Address Prefix Length.
```

```
class sushy.resources.fabric.endpoint.PciIdField(*args, **kwargs)
```

Bases: *sushy.resources.base.CompositeField*

```
device_id = <sushy.resources.base.Field object>  
    The Device ID of this PCIe function.
```

```
subsystem_id = <sushy.resources.base.Field object>  
    The Subsystem ID of this PCIefunction.
```

subsystem_vendor_id = <sushy.resources.base.Field object>

The Subsystem Vendor ID of thisPCIe function.

vendor_id = <sushy.resources.base.Field object>

The Vendor ID of this PCIe function.

sushy.resources.fabric.fabric module

```
class sushy.resources.fabric.fabric.Fabric (connector, identity, red-  
fish_version=None, reg-  
istries=None)
```

Bases: *sushy.resources.base.ResourceBase*

Fabric resource

The Fabric represents a simple fabric consisting of one or more switches, zero or more endpoints, and zero or more zones.

description = <sushy.resources.base.Field object>

The fabric description

property endpoints

fabric_type = <sushy.resources.base.MappedField object>

The protocol being sent over this fabric

identity = <sushy.resources.base.Field object>

Identifier for the fabric

max_zones = <sushy.resources.base.Field object>

The maximum number of zones the switch can currently configure

name = <sushy.resources.base.Field object>

The fabric name

status = <sushy.resources.common.StatusField object>

The fabric status

```
class sushy.resources.fabric.fabric.FabricCollection (connector,  
path, red-  
fish_version=None,  
registries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

sushy.resources.fabric.mappings module

Module contents

sushy.resources.manager package

Submodules

sushy.resources.manager.constants module

`sushy.resources.manager.constants.COMMAND_SHELL_IPMI = 'command shell ipmi'`
Command Shell connection using the IPMI Serial-over-LAN (SOL) protocol

`sushy.resources.manager.constants.COMMAND_SHELL_OEM = 'command shell oem'`
Command Shell connection using an OEM-specific protocol

`sushy.resources.manager.constants.COMMAND_SHELL_SSH = 'command shell ssh'`
Command Shell connection using the SSH protocol

`sushy.resources.manager.constants.COMMAND_SHELL_TELNET = 'command shell telnet'`
Command Shell connection using the Telnet protocol

`sushy.resources.manager.constants.GRAPHICAL_CONSOLE_KVMIP = 'graphical console kvmip'`
Graphical Console connection using a KVM-IP (redirection of Keyboard, Video, Mouse over IP) protocol

`sushy.resources.manager.constants.GRAPHICAL_CONSOLE_OEM = 'graphical console oem'`
Graphical Console connection using an OEM-specific protocol

`sushy.resources.manager.constants.MANAGER_TYPE_AUXILIARY_CONTROLLER = 'auxiliary controller'`
A controller which provides management functions for a particular subsystem or group of devices

`sushy.resources.manager.constants.MANAGER_TYPE_BMC = 'bmc'`
A controller which provides management functions for a single computer system

`sushy.resources.manager.constants.MANAGER_TYPE_ENCLOSURE_MANAGER = 'enclosure manager'`
A controller which provides management functions for a chassis or group of devices or systems

`sushy.resources.manager.constants.MANAGER_TYPE_MANAGEMENT_CONTROLLER = 'management controller'`
A controller used primarily to monitor or manage the operation of a device or system

`sushy.resources.manager.constants.MANAGER_TYPE_RACK_MANAGER = 'rack manager'`
A controller which provides management functions for a whole or part of a rack

`sushy.resources.manager.constants.RESET_MANAGER_FORCE_RESTART = 'force restart'`
Perform an immediate (non-graceful) shutdown, followed by a restart

`sushy.resources.manager.constants.RESET_MANAGER_GRACEFUL_RESTART = 'graceful restart'`
Perform a graceful shutdown followed by a restart of the system

`sushy.resources.manager.constants.SERIAL_CONSOLE_IPMI = 'serial console ipmi'`
Serial Console connection using the IPMI Serial-over-LAN (SOL) protocol

`sushy.resources.manager.constants.SERIAL_CONSOLE_OEM = 'serial console oem'`
Serial Console connection using an OEM-specific protocol

`sushy.resources.manager.constants.SERIAL_CONSOLE_SSH = 'serial console ssh'`
Serial Console connection using the SSH protocol

`sushy.resources.manager.constants.SERIAL_CONSOLE_TELNET = 'serial console telnet'`
Serial Console connection using the Telnet protocol

sushy.resources.manager.manager module

class `sushy.resources.manager.manager.ActionsField` (*args, **kwargs)
Bases: `sushy.resources.base.CompositeField`

reset = `<sushy.resources.common.ResetActionField object>`

class `sushy.resources.manager.manager.Manager`(connector, identity, redfish_version=None, registries=None)
Bases: `sushy.resources.base.ResourceBase`

auto_dst_enabled = `<sushy.resources.base.Field object>`
Indicates whether the manager is configured for automatic DST adjustment

property chassis

A list of chassis managed by this manager.

Returns a list of *Chassis* objects representing the chassis or cabinets managed by this manager.

Raises `MissingAttributeError` if '@odata.id' field is missing.

Returns A list of *Chassis* instances

command_shell = `<sushy.resources.manager.manager.RemoteAccessField object>`
A dictionary containing the remote access support service via command shell (e.g. Telnet, SSH) and max concurrent sessions

description = `<sushy.resources.base.Field object>`
The manager description

firmware_version = `<sushy.resources.base.Field object>`
The manager firmware version

get_allowed_reset_manager_values ()
Get the allowed values for resetting the manager.

Returns A set of allowed values.

Raises `MissingAttributeError`, if `Actions/#Manager.Reset` attribute not present.

get_supported_command_shell_types ()
Get the supported values for Command Shell connection types.

Returns A set of supported values.

get_supported_graphical_console_types ()
Get the supported values for Graphical Console connection types.

Returns A set of supported values.

get_supported_serial_console_types ()
Get the supported values for Serial Console connection types.

Returns A set of supported values.

graphical_console = `<sushy.resources.manager.manager.RemoteAccessField object>`
A dictionary containing the remote access support service via graphical console (e.g. KVMIP) and max concurrent sessions

identity = `<sushy.resources.base.Field object>`
The manager identity string

manager_type = <sushy.resources.base.MappedField object>

The manager type

model = <sushy.resources.base.Field object>

The manager model

name = <sushy.resources.base.Field object>

The manager name

reset_manager (*value*)

Reset the manager.

Parameters *value* – The target value.

Raises InvalidParameterValueError, if the target value is not allowed.

serial_console = <sushy.resources.manager.manager.RemoteAccessField object>

A dictionary containing the remote access support service via serial console (e.g. Telnet, SSH, IPMI) and max concurrent sessions

property systems

A list of systems managed by this manager.

Returns a list of *System* objects representing systems being managed by this manager.

Raises MissingAttributeError if '@odata.id' field is missing.

Returns A list of *System* instances

uuid = <sushy.resources.base.Field object>

The manager UUID

property virtual_media

```
class sushy.resources.manager.manager.ManagerCollection(connector,
                                                    path, red-
                                                    fish_version=None,
                                                    reg-
                                                    istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

```
class sushy.resources.manager.manager.RemoteAccessField(*args,
                                                    **kwargs)
```

Bases: *sushy.resources.base.CompositeField*

connect_types_supported = <sushy.resources.base.Field object>

max_concurrent_sessions = <sushy.resources.base.Field object>

service_enabled = <sushy.resources.base.Field object>

sushy.resources.manager.mappings module

sushy.resources.manager.virtual_media module

```
class sushy.resources.manager.virtual_media.ActionsField(*args,
                                                         **kwargs)
```

Bases: *sushy.resources.base.CompositeField*

eject_media = <sushy.resources.common.ActionField object>

insert_media = <sushy.resources.common.ActionField object>

```
class sushy.resources.manager.virtual_media.VirtualMedia(connector,
                                                         path="",
                                                         red-
                                                         fish_version=None,
                                                         reg-
                                                         istries=None,
                                                         reader=None,
                                                         json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

connected_via = <sushy.resources.base.MappedField object>

Current virtual media connection methods

Applet: Connected to a client application NotConnected: No current connection Oem: Connected via an OEM-defined method URI: Connected to a URI location

eject_media ()

Detach remote media from virtual media

After ejecting media inserted will be False and image_name will be empty.

identity = <sushy.resources.base.Field object>

Virtual Media resource identity string

image = <sushy.resources.base.Field object>

A URI providing the location of the selected image

image_name = <sushy.resources.base.Field object>

The image name

insert_media (image, inserted=True, write_protected=False)

Attach remote media to virtual media

Parameters

- **image** – a URI providing the location of the selected image
- **inserted** – specify if the image is to be treated as inserted upon completion of the action.
- **write_protected** – indicates the media is write protected

inserted = <sushy.resources.base.Field object>

Indicates if virtual media is inserted in the virtual device

media_types = <sushy.resources.base.Field object>

List of supported media types as virtual media

name = <sushy.resources.base.Field object>

The name of resource

write_protected = <sushy.resources.base.Field object>

Indicates the media is write protected

class sushy.resources.manager.virtual_media.VirtualMediaCollection(*connector*,
path,
redfish_version=None,
registries=None)

Bases: *sushy.resources.base.ResourceCollectionBase*

A collection of virtual media attached to a Manager

Module contents

sushy.resources.oem package

Submodules

sushy.resources.oem.base module

class sushy.resources.oem.base.OEMResourceBase(*connector*, *path=""*, *redfish_version=None*,
registries=None,
reader=None)

Bases: *sushy.resources.base.ResourceBase*

set_parent_resource(*parent_resource*, *vendor_id*)

sushy.resources.oem.common module

sushy.resources.oem.common.get_resource_extension_by_vendor(*resource_name*,
vendor,
resource)

Helper method to get Resource specific OEM extension object for vendor

Parameters

- **resource_name** – The underscore joined name of the resource e.g. ‘system’ / ‘ethernet_interface’ / ‘update_service’
- **vendor** – This is the OEM vendor string which is the vendor-specific extensibility identifier. Examples are: ‘Contoso’, ‘Hpe’. As a matter of fact the lowercase of this string will be the plugin entry point name.
- **resource** – The Sushy resource instance

Returns The object returned by `plugin(*args, **kwds)` of extension.

Raises *OEMExtensionNotFoundError* – if no valid resource OEM extension found.

sushy.resources.oem.fake module

```
class sushy.resources.oem.fake.ContosoActionsField (*args, **kwargs)
    Bases: sushy.resources.base.CompositeField
```

```
    reset = <sushy.resources.common.ResetActionField object>
```

```
class sushy.resources.oem.fake.FakeOEMSystemExtension (connector,
                                                        path="", red-
                                                        fish_version=None,
                                                        registries=None,
                                                        reader=None)

    Bases: sushy.resources.oem.base.OEMResourceBase
```

```
    data_type = <sushy.resources.base.Field object>
```

```
    get_reset_system_path()
```

```
    production_location = <sushy.resources.oem.fake.ProductionLocationField obje
```

```
class sushy.resources.oem.fake.ProductionLocationField (*args,
                                                         **kwargs)
```

```
    Bases: sushy.resources.base.CompositeField
```

```
    country = <sushy.resources.base.Field object>
```

```
    facility_name = <sushy.resources.base.Field object>
```

```
sushy.resources.oem.fake.get_extension (*args, **kwargs)
```

Module contents

```
sushy.resources.oem.get_resource_extension_by_vendor (resource_name,
                                                       vendor, resource)
```

Helper method to get Resource specific OEM extension object for vendor

Parameters

- **resource_name** – The underscore joined name of the resource e.g. ‘system’ / ‘ethernet_interface’ / ‘update_service’
- **vendor** – This is the OEM vendor string which is the vendor-specific extensibility identifier. Examples are: ‘Contoso’, ‘Hpe’. As a matter of fact the lower-case of this string will be the plugin entry point name.
- **resource** – The Sushy resource instance

Returns The object returned by `plugin(*args, **kwds)` of extension.

Raises *OEMExtensionNotFoundError* – if no valid resource OEM extension found.

sushy.resources.registry package

Submodules

sushy.resources.registry.message_registry module

```
class sushy.resources.registry.message_registry.MessageDictionaryField (*args,  
                                                                    **kwargs)
```

Bases: *sushy.resources.base.DictionaryField*

description = <sushy.resources.base.Field object>
Indicates how and when the message is returned by the Redfish service

message = <sushy.resources.base.Field object>
Template text of the message

Template can include placeholders for message arguments in form %<integer> where <integer> denotes a position passed from MessageArgs.

number_of_args = <sushy.resources.base.Field object>
Number of arguments to be expected to be passed in as MessageArgs for this message

param_types = <sushy.resources.base.Field object>
Mapped MessageArg types, in order, for the message

resolution = <sushy.resources.base.Field object>
Suggestions on how to resolve the situation that caused the error

severity = <sushy.resources.base.MappedField object>
Mapped severity of the message

```
class sushy.resources.registry.message_registry.MessageRegistry (connector,  
                                                                path="",  
                                                                red-  
                                                                fish_version=None,  
                                                                reg-  
                                                                istries=None,  
                                                                reader=None,  
                                                                json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

description = <sushy.resources.base.Field object>
Human-readable description of the message registry

identity = <sushy.resources.base.Field object>
The Message registry identity string

language = <sushy.resources.base.Field object>
RFC 5646 compliant language code for the registry

messages = <sushy.resources.registry.message_registry.MessageDictionaryField object>
List of messages in this registry

name = <sushy.resources.base.Field object>
The name of the message registry

owning_entity = <sushy.resources.base.Field object>
Organization or company that publishes this registry

registry_prefix = <sushy.resources.base.Field object>

Prefix used in messageIDs which uniquely identifies all of the messages in this registry as belonging to this registry

registry_version = <sushy.resources.base.Field object>

Message registry version which is used in the middle portion of a messageID

sushy.resources.registry.message_registry.**parse_message** (*message_registries*,
message_field)

Using message registries parse the message and substitute any parms

Parameters

- **message_registries** – dict of Message Registries
- **message_field** – settings.MessageListField to parse

Returns parsed settings.MessageListField with missing attributes filled

sushy.resources.registry.message_registry_file module

class sushy.resources.registry.message_registry_file.**LocationListField** (**args*,
***kwargs*)

Bases: *sushy.resources.base.ListField*

Location for each registry file of languages supported

There are 3 options where the file can be hosted:

- locally as a single file,
- locally as a part of archive (zip or other),
- publicly on the Internet.

archive_file = <sushy.resources.base.Field object>

File name for registry if using archive_uri

archive_uri = <sushy.resources.base.Field object>

Location URI for archive file

language = <sushy.resources.base.Field object>

File's RFC5646 language code or the string 'default'

publication_uri = <sushy.resources.base.Field object>

Location URI of publicly available schema

uri = <sushy.resources.base.Field object>

Location URI for co-located registry file with the Redfish service

class sushy.resources.registry.message_registry_file.**MessageRegistryFile** (*connector*,
path="",
redfish_version,
registries=None,
reader=None,
json_doc=None)

Bases: *sushy.resources.base.ResourceBase*

description = <sushy.resources.base.Field object>

Description of Message Registry file resource

get_message_registry (*language, public_connector*)

Load message registry file depending on its source

Will try to find *MessageRegistry* based on *odata.type* property and provided language. If desired language is not found, will pick a registry that has 'default' language.

Parameters

- **language** – RFC 5646 language code for registry files
- **public_connector** – connector to use when downloading registry from the Internet

identity = <sushy.resources.base.Field object>

Identity of Message Registry file resource

languages = <sushy.resources.base.Field object>

List of RFC 5646 language codes supported by this resource

location = <sushy.resources.registry.message_registry_file.LocationListField>

List of locations of Registry files for each supported language

name = <sushy.resources.base.Field object>

Name of Message Registry file resource

registry = <sushy.resources.base.Field object>

Prefix for MessageId used for messages from this resource

This attribute is in form *Registry_name.Major_version.Minor_version*

class *sushy.resources.registry.message_registry_file.MessageRegistryFileCollecti*

Bases: *sushy.resources.base.ResourceCollectionBase*

Collection of Message Registry Files

```
class sushy.resources.registry.message_registry_file.RegistryType (connector,
                                                                    path=",
                                                                    red-
                                                                    fish_version=None,
                                                                    reg-
                                                                    istries=None,
                                                                    reader=None,
                                                                    json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

Module contents

sushy.resources.sessionservice package

Submodules

sushy.resources.sessionservice.session module

```
class sushy.resources.sessionservice.session.Session (connector,  
identity, red-  
fish_version=None,  
registries=None)
```

Bases: *sushy.resources.base.ResourceBase*

delete ()

Method for deleting a Session.

Raises ServerSideError

description = <sushy.resources.base.Field object>

The session service description

identity = <sushy.resources.base.Field object>

The session service identify string

name = <sushy.resources.base.Field object>

The session service name

username = <sushy.resources.base.Field object>

The UserName for the account for this session.

```
class sushy.resources.sessionservice.session.SessionCollection (connector,  
iden-  
tity,  
red-  
fish_version=None,  
reg-  
istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

description = <sushy.resources.base.Field object>

The session collection description

name = <sushy.resources.base.Field object>

The session collection name

sushy.resources.sessionservice.sessionservice module

class sushy.resources.sessionservice.sessionservice.**SessionService** (*connector*,
identity,
redfish_version=None,
registries=None)

Bases: *sushy.resources.base.ResourceBase*

close_session (*session_uri*)

This function is for closing a session based on its id.

Raises ServerSideError

create_session (*username*, *password*, *target_uri=None*)

This function will try to create a session.

Create a session and return the associated key and URI.

Parameters

- **username** – the username of the user requesting a new session
- **password** – the password associated to the user requesting a new session
- **target_uri** – the “Sessions” uri, usually in the form: ‘/redfish/v1/SessionService/Sessions’

Returns A session key and uri in the form of a tuple

Raises MissingXAuthToken

Raises ConnectionError

Raises AccessError

Raises HTTPError

description = <sushy.resources.base.Field object>

The session service description

identity = <sushy.resources.base.Field object>

The session service identify string

name = <sushy.resources.base.Field object>

The session service name

service_enabled = <sushy.resources.base.Field object>

Tells us if session service is enabled

session_timeout = <sushy.resources.base.Field object>

The session service timeout

property sessions

Property to provide reference to the *SessionCollection* instance

It is calculated once when the first time it is queried. On refresh, this property gets reset.

Module contents

sushy.resources.system package

Subpackages

sushy.resources.system.storage package

Submodules

sushy.resources.system.storage.constants module

`sushy.resources.system.storage.constants.RAID_TYPE_RAID0 = 'RAID0'`

A placement policy where consecutive logical blocks of data are uniformly distributed across a set of independent storage devices without offering any form of redundancy.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID00 = 'RAID00'`

A placement policy that creates a RAID 0 stripe set over two or more RAID 0 sets.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID01 = 'RAID01'`

A data placement policy that creates a mirrored device (RAID 1) over a set of striped devices (RAID 0).

`sushy.resources.system.storage.constants.RAID_TYPE_RAID1 = 'RAID1'`

A placement policy where each logical block of data is stored on more than one independent storage device.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID10 = 'RAID10'`

A placement policy that creates a striped device (RAID 0) over a set of mirrored devices (RAID 1).

`sushy.resources.system.storage.constants.RAID_TYPE_RAID10E = 'RAID10E'`

A placement policy that uses a RAID 0 stripe set over two or more RAID 10 sets.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID10Triple = 'RAID10Triple'`

A placement policy that uses a striped device (RAID 0) over a set of triple mirrored devices (RAID 1Triple).

`sushy.resources.system.storage.constants.RAID_TYPE_RAID1E = 'RAID1E'`

A placement policy that uses a form of mirroring implemented over a set of independent storage devices where logical blocks are duplicated on a pair of independent storage devices so that data is uniformly distributed across the storage devices.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID1Triple = 'RAID1Triple'`

A placement policy where each logical block of data is mirrored three times across a set of three independent storage devices.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID3 = 'RAID3'`

A placement policy using parity-based protection where logical bytes of data are uniformly distributed across a set of independent storage devices and where the parity is stored on a dedicated independent storage device.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID4 = 'RAID4'`

A placement policy using parity-based protection where logical blocks of data are uniformly dis-

tributed across a set of independent storage devices and where the parity is stored on a dedicated independent storage device.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID5 = 'RAID5'`

A placement policy using parity-based protection for storing stripes of 'n' logical blocks of data and one logical block of parity across a set of 'n+1' independent storage devices where the parity and data blocks are interleaved across the storage devices.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID50 = 'RAID50'`

A placement policy that uses a RAID 0 stripe set over two or more RAID 5 sets of independent storage devices.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID6 = 'RAID6'`

A placement policy using parity-based protection for storing stripes of 'n' logical blocks of data and two logical blocks of independent parity across a set of 'n+2' independent storage devices where the parity and data blocks are interleaved across the storage devices.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID60 = 'RAID60'`

A placement policy that uses a RAID 0 stripe set over two or more RAID 6 sets of independent storage devices.

`sushy.resources.system.storage.constants.RAID_TYPE_RAID6TP = 'RAID6TP'`

A placement policy that uses parity-based protection for storing stripes of 'n' logical blocks of data and three logical blocks of independent parity across a set of 'n+3' independent storage devices where the parity and data blocks are interleaved across the storage devices.

`sushy.resources.system.storage.constants.VOLUME_INIT_TYPE_FAST = 'fast'`

The volume is prepared for use quickly, typically by erasing just the beginning and end of the space so that partitioning can be performed.

`sushy.resources.system.storage.constants.VOLUME_INIT_TYPE_SLOW = 'slow'`

The volume is prepared for use slowly, typically by completely erasing the volume.

`sushy.resources.system.storage.constants.VOLUME_TYPE_MIRRORED = 'mirrored'`

The volume is a mirrored device.

`sushy.resources.system.storage.constants.VOLUME_TYPE_NON_REDUNDANT = 'nonredunda'`

The volume is a non-redundant storage device.

`sushy.resources.system.storage.constants.VOLUME_TYPE_RAW_DEVICE = 'rawdevice'`

The volume is a raw physical device without any RAID or other virtualization applied.

`sushy.resources.system.storage.constants.VOLUME_TYPE_SPANNED_MIRRORS = 'spannedm'`

The volume is a spanned set of mirrored devices.

`sushy.resources.system.storage.constants.VOLUME_TYPE_SPANNED_STRIPES_WITH_PARITY`

The volume is a spanned set of devices which uses parity to retain redundant information.

`sushy.resources.system.storage.constants.VOLUME_TYPE_STRIPED_WITH_PARITY = 'stri'`

The volume is a device which uses parity to retain redundant information.

sushy.resources.system.storage.drive module

```
class sushy.resources.system.storage.drive.Drive (connector, path="", red-  
fish_version=None,  
registries=None,  
reader=None,  
json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

This class represents a disk drive or other physical storage medium.

block_size_bytes = <sushy.resources.base.Field object>

The size of the smallest addressable unit of this drive in bytes

capacity_bytes = <sushy.resources.base.Field object>

The size in bytes of this Drive

identifiers = <sushy.resources.common.IdentifiersListField object>

The Durable names for the drive

identity = <sushy.resources.base.Field object>

The Drive identity string

indicator_led = <sushy.resources.base.MappedField object>

Whether the indicator LED is lit or off

manufacturer = <sushy.resources.base.Field object>

This is the manufacturer of this drive

media_type = <sushy.resources.base.Field object>

The type of media contained in this drive

model = <sushy.resources.base.Field object>

This is the model number for the drive

name = <sushy.resources.base.Field object>

The name of the resource

part_number = <sushy.resources.base.Field object>

The part number for this drive

protocol = <sushy.resources.base.MappedField object>

Protocol this drive is using to communicate to the storage controller

serial_number = <sushy.resources.base.Field object>

The serial number for this drive

set_indicator_led (*state*)

Set IndicatorLED to the given state.

Parameters *state* – Desired LED state, lit (INDICATOR_LED_LIT), blinking (INDICATOR_LED_BLINKING), off (INDICATOR_LED_OFF)

Raises InvalidParameterValueError, if any information passed is invalid.

status = <sushy.resources.common.StatusField object>

This type describes the status and health of the drive

sushy.resources.system.storage.mappings module

sushy.resources.system.storage.storage module

```
class sushy.resources.system.storage.storage.Storage (connector,
                                                    path="", red-
                                                    fish_version=None,
                                                    registries=None,
                                                    reader=None,
                                                    json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

This class represents the storage subsystem resources.

A storage subsystem represents a set of storage controllers (physical or virtual) and the resources such as drives and volumes that can be accessed from that subsystem.

property drives

Return a list of *Drive* objects present in the storage resource.

It is set once when the first time it is queried. On subsequent invocations, it returns a cached list of *Drives* objects until it is marked stale.

Returns A list of *Drive* objects

Raises ResourceNotFoundError

drives_identities = <sushy.resources.base.Field object>

A tuple with the drive identities

property drives_max_size_bytes

Max size available in bytes among all *Drives* of this collection.

property drives_sizes_bytes

Sizes of all *Drives* in bytes in *Storage* resource.

Returns the list of cached values until it (or its parent resource) is refreshed.

get_drive (drive_identity)

Given the drive identity return a *Drive* object

Parameters drive_identity – The identity of the *Drive*

Returns The *Drive* object

Raises ResourceNotFoundError

identity = <sushy.resources.base.Field object>

The *Storage* identity string

name = <sushy.resources.base.Field object>

The name of the resource

status = <sushy.resources.common.StatusField object>

Describes the status and health of the resource and its children.

storage_controllers = <sushy.resources.system.storage.storage.StorageControl

The storage devices associated with this resource.

property volumes

Property to reference *VolumeCollection* instance

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done at that point). Here only the actual refresh of the sub-resource happens, if resource is stale.

```
class sushy.resources.system.storage.storage.StorageCollection (connector,  
path,  
red-  
fish_version=None,  
reg-  
istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

This class represents the collection of Storage resources

property drives_sizes_bytes

Sizes of each Drive in bytes in Storage collection resource.

Returns the list of cached values until it (or its parent resource) is refreshed.

property max_drive_size_bytes

Max size available (in bytes) among all Drive resources.

Returns the cached value until it (or its parent resource) is refreshed.

property max_volume_size_bytes

Max size available (in bytes) among all Volume resources.

Returns the cached value until it (or its parent resource) is refreshed.

property volumes_sizes_bytes

Sizes of each Volume in bytes in Storage collection resource.

Returns the list of cached values until it (or its parent resource) is refreshed.

```
class sushy.resources.system.storage.storage.StorageControllersListField (*args,  
**kwargs)
```

Bases: *sushy.resources.base.ListField*

The set of storage controllers represented by this resource.

```
controller_protocols = <sushy.resources.base.MappedListField object>
```

The protocols by which this storage controller can be communicated to

```
device_protocols = <sushy.resources.base.MappedListField object>
```

The protocols which the controller can use to communicate with devices

```
identifiers = <sushy.resources.common.IdentifiersListField object>
```

The Durable names for the storage controller.

```
member_id = <sushy.resources.base.Field object>
```

Uniquely identifies the member within the collection.

```
name = <sushy.resources.base.Field object>
```

The name of the storage controller

```
raid_types = <sushy.resources.base.MappedListField object>
```

The set of RAID types supported by the storage controller.

speed_gbps = <sushy.resources.base.Field object>

The maximum speed of the storage controller's device interface.

status = <sushy.resources.common.StatusField object>

Describes the status and health of the resource and its children.

sushy.resources.system.storage.volume module

```
class sushy.resources.system.storage.volume.ActionsField(*args,
                                                         **kwargs)
```

Bases: *sushy.resources.base.CompositeField*

initialize = <sushy.resources.common.InitializeActionField object>

```
class sushy.resources.system.storage.volume.Volume(connector,
                                                    path="", redfish_version=None,
                                                    registries=None,
                                                    reader=None,
                                                    json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

This class adds the Storage Volume resource

block_size_bytes = <sushy.resources.base.Field object>

The size of the smallest addressable unit of this volume in bytes.

capacity_bytes = <sushy.resources.base.Field object>

The size in bytes of this Volume.

delete_volume (*payload=None*)

Delete the volume.

Parameters **payload** – May contain @Redfish.OperationApplyTime property

Raises ConnectionError

Raises HTTPError

encrypted = <sushy.resources.base.Field object>

Is this Volume encrypted.

get_allowed_initialize_volume_values ()

Get the allowed values for initializing the volume.

Returns A set with the allowed values.

identifiers = <sushy.resources.common.IdentifiersListField object>

The Durable names for the volume.

identity = <sushy.resources.base.Field object>

The Volume identity string

initialize_volume (*value*)

Initialize the volume.

Parameters **value** – The InitializeType value.

Raises InvalidParameterValueError, if the target value is not allowed.

name = <sushy.resources.base.Field object>

The name of the resource

operation_apply_time_support = <sushy.resources.common.OperationApplyTimeSup

Indicates if a client is allowed to request for a specific apply time of a create, delete, or action operation of a given resource

raid_type = <sushy.resources.base.MappedField object>

The RAID type of this volume.

volume_type = <sushy.resources.base.MappedField object>

The type of this volume.

```
class sushy.resources.system.storage.volume.VolumeCollection (connector,  
path,  
red-  
fish_version=None,  
reg-  
istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

This class represents the Storage Volume collection

create_volume (*payload*)

Create a volume.

Parameters **payload** – The payload representing the new volume to create.

Raises ConnectionError

Raises HTTPError

Returns Newly created Volume resource or None if no Location header

property max_size_bytes

Max size available (in bytes) among all Volume resources.

Returns the cached value until it (or its parent resource) is refreshed.

property max_volume_size_bytes

Max size available (in bytes) among all Volume resources.

Returns the cached value until it (or its parent resource) is refreshed.

operation_apply_time_support = <sushy.resources.common.OperationApplyTimeSup

Indicates if a client is allowed to request for a specific apply time of a create, delete, or action operation of a given resource

property volumes_sizes_bytes

Sizes of all Volumes in bytes in VolumeCollection resource.

Returns the list of cached values until it (or its parent resource) is refreshed.

Module contents

Submodules

sushy.resources.system.bios module

class `sushy.resources.system.bios.ActionsField(*args, **kwargs)`

Bases: `sushy.resources.base.CompositeField`

change_password = `<sushy.resources.common.ActionField object>`

reset_bios = `<sushy.resources.common.ActionField object>`

class `sushy.resources.system.bios.Bios(connector, path, redfish_version=None, registries=None)`

Bases: `sushy.resources.base.ResourceBase`

property `apply_time_settings`

attributes = `<sushy.resources.base.Field object>`

Vendor-specific key-value dict of effective BIOS attributes

Attributes cannot be updated directly. To update use `set_attribute()` or `set_attributes()`

change_password (`new_password, old_password, password_name`)

Change BIOS password

description = `<sushy.resources.base.Field object>`

Human-readable description of the BIOS resource

identity = `<sushy.resources.base.Field object>`

The Bios resource identity string

maintenance_window = `<sushy.resources.settings.MaintenanceWindowField object>`

Indicates if a given resource has a maintenance window assignment for applying settings or operations

name = `<sushy.resources.base.Field object>`

The name of the resource

property `pending_attributes`

Pending BIOS attributes

BIOS attributes that have been committed to the system, but for them to take effect system restart is necessary

reset_bios ()

Reset the BIOS attributes to default

set_attribute (`key, value, apply_time=None, maint_window_start_time=None, maint_window_duration=None`)

Update an attribute

Attribute update is not immediate but requires system restart. Committed attributes can be checked at `pending_attributes` property

Parameters

- **key** – Attribute name

- **value** – Attribute value
- **apply_time** – When to update the attribute. Optional. APPLY_TIME_IMMEDIATE - Immediate, APPLY_TIME_ON_RESET - On reset, APPLY_TIME_MAINT_START - During specified maintenance time APPLY_TIME_MAINT_RESET - On reset during specified maintenance time
- **maint_window_start_time** – The start time of a maintenance window, datetime. Required when updating during maintenance window and default maintenance window not set by the system.
- **maint_window_duration** – Duration of maintenance time since maintenance window start time in seconds. Required when updating during maintenance window and default maintenance window not set by the system.

set_attributes (*value*, *apply_time=None*, *maint_window_start_time=None*,
maint_window_duration=None)
Update many attributes at once

Attribute update is not immediate but requires system restart. Committed attributes can be checked at *pending_attributes* property

Parameters

- **value** – Key-value pairs for attribute name and value
- **apply_time** – When to update the attributes. Optional. APPLY_TIME_IMMEDIATE - Immediate, APPLY_TIME_ON_RESET - On reset, APPLY_TIME_MAINT_START - During specified maintenance time APPLY_TIME_MAINT_RESET - On reset during specified maintenance time
- **maint_window_start_time** – The start time of a maintenance window, datetime. Required when updating during maintenance window and default maintenance window not set by the system.
- **maint_window_duration** – Duration of maintenance time since maintenance window start time in seconds. Required when updating during maintenance window and default maintenance window not set by the system.

property supported_apply_times

List of supported BIOS update apply times

Returns List of supported update apply time names

property update_status

Status of the last attribute update

Returns *sushy.resources.settings.SettingsUpdate* object containing status and any messages

sushy.resources.system.constants module

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_BIOS_SETUP = 'bios setup'`
 Boot to the BIOS Setup Utility

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_CD = 'cd'`
 Boot from the CD/DVD disc

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_DIAGS = 'diags'`
 Boot the manufacturer's Diagnostics program

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_FLOPPY = 'floppy'`
 Boot from the floppy disk drive

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_HDD = 'hdd'`
 Boot from a hard drive

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_NONE = 'none'`
 Boot from the normal boot device

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_PXE = 'pxe'`
 Boot from the Pre-Boot EXecution (PXE) environment

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_SD_CARD = 'sd card'`
 Boot from an SD Card

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_UEFI_HTTP = 'uefi http'`
 Boot from a UEFI HTTP network location

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_UEFI_SHELL = 'uefi shell'`
 Boot to the UEFI Shell

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_UEFI_TARGET = 'uefi target'`
 Boot to the UEFI Device specified in the UefiTargetBootSourceOverride property

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_USB = 'usb'`
 Boot from a USB device as specified by the system BIOS

`sushy.resources.system.constants.BOOT_SOURCE_TARGET_UTILITIES = 'utilities'`
 Boot the manufacturer's Utilities program(s)

`sushy.resources.system.constants.SYSTEM_INDICATOR_LED_BLINKING = 'indicator led'`
 The Indicator LED is blinking

Deprecated: Use `sushy.resources.constants.INDICATOR_LED_BLINKING`.

`sushy.resources.system.constants.SYSTEM_INDICATOR_LED_LIT = 'indicator led lit'`
 The Indicator LED is lit

Deprecated: Use `sushy.resources.constants.INDICATOR_LED_LIT`.

`sushy.resources.system.constants.SYSTEM_INDICATOR_LED_OFF = 'indicator led off'`
 The Indicator LED is off

Deprecated: Use `sushy.resources.constants.INDICATOR_LED_OFF`.

`sushy.resources.system.constants.SYSTEM_INDICATOR_LED_UNKNOWN = 'indicator led u'`
 The state of the Indicator LED cannot be determine

Deprecated: Use `sushy.resources.constants.INDICATOR_LED_UNKNOWN`.

`sushy.resources.system.constants.SYSTEM_POWER_STATE_OFF = 'off'`

The system is powered off, although some components may continue to have AUX power such as management controller

`sushy.resources.system.constants.SYSTEM_POWER_STATE_ON = 'on'`

The system is powered on

`sushy.resources.system.constants.SYSTEM_POWER_STATE_POWERING_OFF = 'powering off'`

A temporary state between On and Off. The power off action can take time while the OS is in the shutdown process

`sushy.resources.system.constants.SYSTEM_POWER_STATE_POWERING_ON = 'powering on'`

A temporary state between Off and On. This temporary state can be very short

`sushy.resources.system.constants.SYSTEM_TYPE_COMPOSED = 'Composed'`

A computer system created by binding resource blocks together

`sushy.resources.system.constants.SYSTEM_TYPE_OS = 'OS'`

An operating system instance

`sushy.resources.system.constants.SYSTEM_TYPE_PHYSICAL = 'Physical'`

A physical computer system

`sushy.resources.system.constants.SYSTEM_TYPE_PHYSICALLY_PARTITIONED = 'PhysicallyPartitioned'`

A hardware-based partition of a computer system

`sushy.resources.system.constants.SYSTEM_TYPE_VIRTUAL = 'Virtual'`

A virtual machine instance

`sushy.resources.system.constants.SYSTEM_TYPE_VIRTUALLY_PARTITIONED = 'VirtuallyPartitioned'`

A virtual or software-based partition of a computer system

sushy.resources.system.ethernet_interface module

```
class sushy.resources.system.ethernet_interface.EthernetInterface(connector,  
                                                                path=","  
                                                                red-  
                                                                fish_version=None,  
                                                                reg-  
                                                                istries=None,  
                                                                reader=None,  
                                                                json_doc=None)
```

Bases: `sushy.resources.base.ResourceBase`

This class adds the EthernetInterface resource

description = `<sushy.resources.base.Field object>`

Description

identity = `<sushy.resources.base.Field object>`

The Ethernet Interface identity string

mac_address = `<sushy.resources.base.Field object>`

This is the currently configured MAC address of the interface.

name = `<sushy.resources.base.Field object>`

The name of the resource or array element

permanent_mac_address = <sushy.resources.base.Field object>

This is the permanent MAC address assigned to this interface (port)

speed_mbps = <sushy.resources.base.Field object>

This is the current speed in Mbps of this interface.

status = <sushy.resources.common.StatusField object>

Describes the status and health of this interface.

class sushy.resources.system.ethernet_interface.EthernetInterfaceCollection (*connector,*

path,

red-

fish_v

reg-

istries

Bases: *sushy.resources.base.ResourceCollectionBase*

property summary

Summary of MAC addresses and interfaces state

This filters the MACs whose health is OK, which means the MACs in both 'Enabled' and 'Disabled' States are returned.

Returns dictionary in the format {'aa:bb:cc:dd:ee:ff': sushy.STATE_ENABLED, 'aa:bb:aa:aa:aa:aa': sushy.STATE_DISABLED}

sushy.resources.system.mappings module

sushy.resources.system.processor module

class sushy.resources.system.processor.Processor (*connector, identity, red-
fish_version=None, reg-
istries=None*)

Bases: *sushy.resources.base.ResourceBase*

identity = <sushy.resources.base.Field object>

The processor identity string

instruction_set = <sushy.resources.base.MappedField object>

The instruction set of the processor

manufacturer = <sushy.resources.base.Field object>

The processor manufacturer

max_speed_mhz = <sushy.resources.base.Field object>

The maximum clock speed of the processor in MHz.

model = <sushy.resources.base.Field object>

The product model number of this device

processor_architecture = <sushy.resources.base.MappedField object>

The architecture of the processor

processor_id = <sushy.resources.system.processor.ProcessorIdField object>

The processor id

processor_type = <sushy.resources.base.MappedField object>

The type of processor

socket = <sushy.resources.base.Field object>

The socket or location of the processor

status = <sushy.resources.common.StatusField object>

The processor status

property sub_processors

A reference to the collection of Sub-Processors

total_cores = <sushy.resources.base.Field object>

The total number of cores contained in this processor

total_threads = <sushy.resources.base.Field object>

The total number of execution threads supported by this processor

```
class sushy.resources.system.processor.ProcessorCollection(connector,  
path,  
red-  
fish_version=None,  
reg-  
istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

property summary

Property to provide ProcessorSummary info

It is calculated once when the first time it is queried. On refresh, this property gets reset.

Returns A namedtuple containing the count of processors in regards to logical CPUs, and their architecture.

```
class sushy.resources.system.processor.ProcessorIdField(*args,  
**kwargs)
```

Bases: *sushy.resources.base.CompositeField*

effective_family = <sushy.resources.base.Field object>

The processor effective family

effective_model = <sushy.resources.base.Field object>

The processor effective model

identification_registers = <sushy.resources.base.Field object>

The processor identification registers

microcode_info = <sushy.resources.base.Field object>

The processor microcode info

step = <sushy.resources.base.Field object>

The processor stepping

vendor_id = <sushy.resources.base.Field object>

The processor vendor id

```
class sushy.resources.system.processor.ProcessorSummary(count, archi-  
ture)
```

Bases: tuple

architecture

Alias for field number 1

count

Alias for field number 0

sushy.resources.system.simple_storage module

```
class sushy.resources.system.simple_storage.DeviceListField(*args,
                                                         **kwargs)
```

Bases: *sushy.resources.base.ListField*

The storage device/s associated with SimpleStorage.

capacity_bytes = <sushy.resources.base.Field object>

The size of the storage device.

name = <sushy.resources.base.Field object>

The name of the storage device

status = <sushy.resources.common.StatusField object>

Describes the status and health of a storage device.

```
class sushy.resources.system.simple_storage.SimpleStorage(connector,
                                                           path="",
                                                           red-
                                                           fish_version=None,
                                                           reg-
                                                           istries=None,
                                                           reader=None,
                                                           json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

This class represents a simple storage.

It represents the properties of a storage controller and its directly-attached devices. A storage device can be a disk drive or optical media device.

devices = <sushy.resources.system.simple_storage.DeviceListField object>

The storage devices associated with this resource.

identity = <sushy.resources.base.Field object>

The SimpleStorage identity string

name = <sushy.resources.base.Field object>

The name of the resource

```
class sushy.resources.system.simple_storage.SimpleStorageCollection(connector,
                                                                      path,
                                                                      red-
                                                                      fish_version=None,
                                                                      reg-
                                                                      istries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

Represents a collection of simple storage associated with system.

property disks_sizes_bytes

Sizes of each Disk in bytes in SimpleStorage collection resource.

Returns the list of cached values until it (or its parent resource) is refreshed.

property max_size_bytes

Max size available (in bytes) among all enabled Disk resources.

Returns the cached value until it (or its parent resource) is refreshed.

sushy.resources.system.system module

class `sushy.resources.system.system.ActionsField(*args, **kwargs)`

Bases: `sushy.resources.base.CompositeField`

reset = `<sushy.resources.common.ResetActionField object>`

class `sushy.resources.system.system.BootField(*args, **kwargs)`

Bases: `sushy.resources.base.CompositeField`

allowed_values = `<sushy.resources.base.Field object>`

enabled = `<sushy.resources.base.MappedField object>`

mode = `<sushy.resources.base.MappedField object>`

target = `<sushy.resources.base.MappedField object>`

class `sushy.resources.system.system.MemorySummaryField(*args,`

`**kwargs)`

Bases: `sushy.resources.base.CompositeField`

health = `<sushy.resources.base.Field object>`

The overall health state of memory.

This signifies health state of memory along with its dependent resources.

size_gib = `<sushy.resources.base.Field object>`

The size of memory of the system in GiB.

This signifies the total installed, operating system-accessible memory (RAM), measured in GiB.

class `sushy.resources.system.system.System(connector, identity, red-`

`fish_version=None, reg-`

`istries=None)`

Bases: `sushy.resources.base.ResourceBase`

asset_tag = `<sushy.resources.base.Field object>`

The system asset tag

property bios

Property to reference *Bios* instance

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done). Here the actual refresh of the sub-resource happens, if stale.

bios_version = `<sushy.resources.base.Field object>`

The system BIOS version

boot = `<sushy.resources.system.system.BootField object>`

A dictionary containing the current boot device, frequency and mode

property chassis

A list of chassis where this system resides.

Returns a list of *Chassis* objects representing the chassis or cabinets where this system is mounted.

Raises `MissingAttributeError` if '@odata.id' field is missing.

Returns A list of *Chassis* instances

description = <`sushy.resources.base.Field` object>

The system description

property ethernet_interfaces

Property to reference *EthernetInterfaceCollection* instance

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done). Here the actual refresh of the sub-resource happens, if stale.

get_allowed_reset_system_values ()

Get the allowed values for resetting the system.

Returns A set with the allowed values.

get_allowed_system_boot_source_values ()

Get the allowed values for changing the boot source.

Returns A set with the allowed values.

hostname = <`sushy.resources.base.Field` object>

The system hostname

identity = <`sushy.resources.base.Field` object>

The system identity string

indicator_led = <`sushy.resources.base.MappedField` object>

Whether the indicator LED is lit or off

maintenance_window = <`sushy.resources.settings.MaintenanceWindowField` object>

Indicates if a given resource has a maintenance window assignment for applying settings or operations

property managers

A list of managers for this system.

Returns a list of *Manager* objects representing the managers that manage this system.

Raises `MissingAttributeError` if '@odata.id' field is missing.

Returns A list of *Manager* instances

manufacturer = <`sushy.resources.base.Field` object>

The system manufacturer

memory_summary = <`sushy.resources.system.system.MemorySummaryField` object>

The summary info of memory of the system in general detail

name = <`sushy.resources.base.Field` object>

The system name

part_number = <`sushy.resources.base.Field` object>

The system part number

power_state = <`sushy.resources.base.MappedField` object>

The system power state

property processors

Property to reference *ProcessorCollection* instance

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done). Here the actual refresh of the sub-resource happens, if stale.

reset_system (*value*)

Reset the system.

Parameters **value** – The target value.

Raises `InvalidParameterValueError`, if the target value is not allowed.

serial_number = `<sushy.resources.base.Field object>`

The system serial number

set_indicator_led (*state*)

Set IndicatorLED to the given state.

Parameters **state** – Desired LED state, lit (`INDICATOR_LED_LIT`), blinking (`INDICATOR_LED_BLINKING`), off (`INDICATOR_LED_OFF`)

Raises `InvalidParameterValueError`, if any information passed is invalid.

set_system_boot_options (*target=None, enabled=None, mode=None*)

Set boot source and/or boot frequency and/or boot mode.

Set the boot source and/or boot frequency and/or boot mode to use on next reboot of the System.

Parameters

- **target** – The target boot source, optional.
- **enabled** – The frequency, whether to set it for the next reboot only (`BOOT_SOURCE_ENABLED_ONCE`) or persistent to all future reboots (`BOOT_SOURCE_ENABLED_CONTINUOUS`) or disabled (`BOOT_SOURCE_ENABLED_DISABLED`), optional.
- **mode** – The boot mode (UEFI: `BOOT_SOURCE_MODE_UEFI` or BIOS: `BOOT_SOURCE_MODE_BIOS`), optional.

Raises `InvalidParameterValueError`, if any information passed is invalid.

set_system_boot_source (*target, enabled='once', mode=None*)

Set boot source and/or boot frequency and/or boot mode.

Set the boot source and/or boot frequency and/or boot mode to use on next reboot of the System.

This method is obsoleted by *set_system_boot_options*.

Parameters

- **target** – The target boot source.
- **enabled** – The frequency, whether to set it for the next reboot only (`BOOT_SOURCE_ENABLED_ONCE`) or persistent to all future reboots (`BOOT_SOURCE_ENABLED_CONTINUOUS`) or disabled (`BOOT_SOURCE_ENABLED_DISABLED`). Default is `BOOT_SOURCE_ENABLED_ONCE`.

- **mode** – The boot mode (UEFI: `BOOT_SOURCE_MODE_UEFI` or BIOS: `BOOT_SOURCE_MODE_BIOS`), optional.

Raises `InvalidParameterValueError`, if any information passed is invalid.

property simple_storage

A collection of simple storage associated with system.

This returns a reference to *SimpleStorageCollection* instance. *SimpleStorage* represents the properties of a storage controller and its directly-attached devices.

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done). Here the actual refresh of the sub-resource happens, if stale.

Raises `MissingAttributeError` if ‘`SimpleStorage/@odata.id`’ field is missing.

Returns *SimpleStorageCollection* instance

sku = `<sushy.resources.base.Field object>`

The system stock-keeping unit

status = `<sushy.resources.common.StatusField object>`

The system status

property storage

A collection of storage subsystems associated with system.

This returns a reference to *StorageCollection* instance. A storage subsystem represents a set of storage controllers (physical or virtual) and the resources such as drives and volumes that can be accessed from that subsystem.

It is set once when the first time it is queried. On refresh, this property is marked as stale (greedy-refresh not done). Here the actual refresh of the sub-resource happens, if stale.

Raises `MissingAttributeError` if ‘`Storage/@odata.id`’ field is missing.

Returns *StorageCollection* instance

system_type = `<sushy.resources.base.MappedField object>`

The system type

uuid = `<sushy.resources.base.Field object>`

The system UUID

```
class sushy.resources.system.system.SystemCollection (connector,
                                                    path,          red-
                                                    fish_version=None,
                                                    registries=None)
```

Bases: *sushy.resources.base.ResourceCollectionBase*

Module contents

sushy.resources.taskservice package

Submodules

sushy.resources.taskservice.mappings module

sushy.resources.taskservice.task module

```
class sushy.resources.taskservice.task.Task (connector, identity, redfish_version=None, registries=None, json_doc=None)
```

Bases: *sushy.resources.base.ResourceBase*

```
description = <sushy.resources.base.Field object>  
    The Task description
```

```
end_time = <sushy.resources.base.Field object>  
    End time of the Task
```

```
identity = <sushy.resources.base.Field object>  
    The Task identity
```

```
property is_processing  
    Indicates if the Task is processing
```

```
messages = <sushy.resources.base.MessageListField object>  
    List of MessageListField with messages from the Task
```

```
name = <sushy.resources.base.Field object>  
    The Task name
```

```
parse_messages ()  
    Parses the messages
```

```
percent_complete = <sushy.resources.base.Field object>  
    Percentage complete of the Task
```

```
start_time = <sushy.resources.base.Field object>  
    Start time of the Task
```

```
task_monitor = <sushy.resources.base.Field object>  
    An opaque URL that the client can use to monitor an asynchronous operation
```

```
task_state = <sushy.resources.base.MappedField object>  
    The Task state
```

```
task_status = <sushy.resources.base.MappedField object>  
    The Task status
```

sushy.resources.taskservice.taskmonitor module

```
class sushy.resources.taskservice.taskmonitor.TaskMonitor (connector,
                                                    task_monitor,
                                                    red-
                                                    fish_version=None,
                                                    reg-
                                                    istries=None,
                                                    field_data=None)
```

Bases: object

property cancellable

The amount of time to sleep before retrying

Returns A Boolean indicating if the Task is cancellable.

get_task ()

property is_processing

Indicates if the task is still processing

Returns A boolean indicating if the task is still processing.

refresh ()

Refresh the Task

Freshly retrieves/fetches the Task. :raises: ResourceNotFoundError :raises: ConnectionError
:raises: HTTPError

property retry_after

The amount of time to sleep before retrying

Returns The amount of time in seconds to wait before calling is_processing.

property task

The executing task

Returns The Task being executed.

property task_monitor

The TaskMonitor URI

Returns The TaskMonitor URI.

Module contents

sushy.resources.update-service package

Submodules

sushy.resources.update-service.constants module

sushy.resources.update-service.mappings module

sushy.resources.update.service.softwareinventory module

class `sushy.resources.update.service.softwareinventory.SoftwareInventory` (*connector, identity, redfish_version, registries=None*)

Bases: `sushy.resources.base.ResourceBase`

identity = `<sushy.resources.base.Field object>`

The software inventory identity

lowest_supported_version = `<sushy.resources.base.Field object>`

The lowest supported version of the software

manufacturer = `<sushy.resources.base.Field object>`

The manufacturer of the software

name = `<sushy.resources.base.Field object>`

The software inventory name

related_item = `<sushy.resources.base.Field object>`

The ID(s) of the resources associated with the software inventory item

release_date = `<sushy.resources.base.Field object>`

Release date of the software

software_id = `<sushy.resources.base.Field object>`

The identity of the software

status = `<sushy.resources.common.StatusField object>`

The status of the software inventory

uefi_device_paths = `<sushy.resources.base.Field object>`

Represents the UEFI Device Path(s)

updateable = `<sushy.resources.base.Field object>`

Indicates whether this software can be updated by the update service

version = `<sushy.resources.base.Field object>`

The version of the software

class `sushy.resources.update.service.softwareinventory.SoftwareInventoryCollection`

Bases: `sushy.resources.base.ResourceCollectionBase`

description = `<sushy.resources.base.Field object>`

The software inventory collection description

name = `<sushy.resources.base.Field object>`

The software inventory collection name

sushy.resources.update.service.update.service module

```

class sushy.resources.update.service.update.service.ActionsField(*args,
                                                                **kwargs)
    Bases: sushy.resources.base.CompositeField

    simple_update = <sushy.resources.common.ActionField object>

class sushy.resources.update.service.update.service.UpdateService(connector,
                                                                    iden-
                                                                    tity,
                                                                    red-
                                                                    fish_version=None,
                                                                    reg-
                                                                    istries=None)

    Bases: sushy.resources.base.ResourceBase

    property firmware_inventory
        Property to reference FirmwareInventory collection instance

    get_allowed_transfer_protocols()
        Get the allowed values for transfer protocol.

        Returns A set of allowed values.

        Raises MissingAttributeError, if Actions/#UpdateService.SimpleUpdate attribute
            not present.

    get_task_monitor(task_monitor)
        Used to retrieve a TaskMonitor.

        Returns A task monitor.

    http_push_uri = <sushy.resources.base.Field object>
        The URI used to perform an HTTP or HTTPS push update to the Update Service

    http_push_uri_targets = <sushy.resources.base.Field object>

    http_push_uri_targets_busy = <sushy.resources.base.Field object>

    identity = <sushy.resources.base.Field object>
        The update service identity

    name = <sushy.resources.base.Field object>
        The update service name

    service_enabled = <sushy.resources.base.Field object>
        The status of whether this service is enabled

    simple_update(image_uri, targets=None, transfer_protocol='Hypertext Transport Proto-
                    col')
        Simple Update is used to update software components.

        Returns A task monitor.

    property software_inventory
        Property to reference SoftwareInventory collection instance

    status = <sushy.resources.common.StatusField object>
        The status of the update service
    
```

Module contents

Submodules

sushy.resources.base module

class sushy.resources.base.**AbstractDataReader**

Bases: object

abstract `get_data()`

Based on data source get data and parse to JSON

set_connection (*connector*, *path*)

Sets mandatory connection parameters

Parameters

- **connector** – A Connector instance
- **path** – path of the resource

class sushy.resources.base.**CompositeField** (**args*, ***kwargs*)

Bases: collections.abc.Mapping, *sushy.resources.base.Field*

Base class for fields consisting of several sub-fields.

class sushy.resources.base.**DictionaryField** (**args*, ***kwargs*)

Bases: *sushy.resources.base.Field*

Base class for fields consisting of dictionary of several sub-fields.

class sushy.resources.base.**Field** (*path*, *required=False*, *default=None*,
adapter=<function Field.<lambda>>)

Bases: object

Definition for fields fetched from JSON.

class sushy.resources.base.**FieldData** (*status_code*, *headers*, *json_doc*)

Bases: object

Contains data to be used when constructing Fields

property `headers`

The headers

property `json_doc`

The parsed JSON body

property `status_code`

The status code

class sushy.resources.base.**JsonArchiveReader** (*archive_file*)

Bases: *sushy.resources.base.AbstractDataReader*

Gets the data from JSON file in archive

get_data ()

Gets JSON file from archive. Currently supporting ZIP only

class `sushy.resources.base.JsonDataReader`
 Bases: `sushy.resources.base.AbstractDataReader`
 Gets the data from HTTP response given by path

get_data ()
 Gets JSON file from URI directly

class `sushy.resources.base.JsonPackagedFileReader` (*resource_package_name*)
 Bases: `sushy.resources.base.AbstractDataReader`
 Gets the data from packaged file given by path

get_data ()
 Gets JSON file from packaged file denoted by path

class `sushy.resources.base.JsonPublicFileReader`
 Bases: `sushy.resources.base.AbstractDataReader`
 Loads the data from the Internet

get_data ()
 Get JSON file from full URI

class `sushy.resources.base.ListField` (**args, **kwargs*)
 Bases: `sushy.resources.base.Field`
 Base class for fields consisting of a list of several sub-fields.

class `sushy.resources.base.MappedField` (*field, mapping, required=False, default=None*)
 Bases: `sushy.resources.base.Field`
 Field taking real value from a mapping.

class `sushy.resources.base.MappedListField` (*field, mapping, required=False, default=None*)
 Bases: `sushy.resources.base.Field`
 Field taking a list of values with a mapping for the values
 Given JSON `{'field':['xxx', 'yyy']}`, a sushy resource definition and mapping `{'xxx':'a', 'yyy':'b'}`, the sushy object to come out will be like `resource.field = ['a', 'b']`

class `sushy.resources.base.MessageListField` (**args, **kwargs*)
 Bases: `sushy.resources.base.ListField`
 List of messages with details of settings update status

message = `<sushy.resources.base.Field object>`
 Human readable message, if provided

message_args = `<sushy.resources.base.Field object>`
 List of message substitution arguments for the message referenced by *message_id* from the message registry

message_id = `<sushy.resources.base.Field object>`
 The key for this message which can be used to look up the message in a message registry

resolution = `<sushy.resources.base.Field object>`
 Used to provide suggestions on how to resolve the situation that caused the error

severity = <sushy.resources.base.MappedField object>

Severity of the error

```
class sushy.resources.base.ResourceBase (connector, path="", redfish_version=None, registries=None, reader=None, json_doc=None)
```

Bases: object

clone_resource (*new_resource*, *path=""*)

Instantiate given resource using existing BMC connection context

get_oem_extension (*vendor*)

Get the OEM extension instance for this resource by OEM vendor

Parameters **vendor** – the OEM vendor string which is the vendor-specific extensibility identifier. Examples are ‘Contoso’, ‘Hpe’. Possible value can be got from `oem_vendors` attribute.

Returns the Redfish resource OEM extension instance.

Raises OEMExtensionNotFoundError

invalidate (*force_refresh=False*)

Mark the resource as stale, prompting refresh() before getting used.

If `force_refresh` is set to True, then it invokes `refresh()` on the resource.

Parameters **force_refresh** – will invoke refresh on the resource, if set to True.

Raises ResourceNotFoundError

Raises ConnectionError

Raises HTTPError

property `json`

oem_vendors = <sushy.resources.base.Field object>

The list of OEM extension names for this resource.

property `path`

redfish_version = None

The Redfish version

refresh (*force=True*, *json_doc=None*)

Refresh the resource

Freshly retrieves/fetches the resource attributes and invokes `_parse_attributes()` method on successful retrieval. It is recommended not to override this method in concrete `ResourceBase` classes. Resource classes can place their refresh specific operations in `_do_refresh()` method, if needed. This method represents the template method in the paradigm of Template design pattern.

Parameters

- **force** – if set to False, will only refresh if the resource is marked as stale, otherwise neither it nor its subresources will be refreshed.
- **json_doc** – parsed JSON document in form of Python types.

Raises ResourceNotFoundError

Raises ConnectionError

Raises HTTPError

property registries

property resource_name

class `sushy.resources.base.ResourceCollectionBase` (*connector, path, redfish_version=None, registries=None*)

Bases: `sushy.resources.base.ResourceBase`

get_member (*identity*)

Given the identity return a `_resource_type` object

Parameters `identity` – The identity of the `_resource_type`

Returns The `_resource_type` object

Raises ResourceNotFoundError

get_members ()

Return a list of `_resource_type` objects present in collection

Returns A list of `_resource_type` objects

members_identities = `<sushy.resources.base.Field object>`

A tuple with the members identities

name = `<sushy.resources.base.Field object>`

The name of the collection

`sushy.resources.base.get_reader` (*connector, path, reader=None*)

Create and configure the reader.

Parameters

- **connector** – A Connector instance
- **path** – sub-URI path to the resource.
- **reader** – Reader to use to fetch JSON data.

Returns the reader

sushy.resources.common module

class `sushy.resources.common.ActionField` (**args, **kwargs*)

Bases: `sushy.resources.base.CompositeField`

operation_apply_time_support = `<sushy.resources.common.OperationApplyTimeSup`

target_uri = `<sushy.resources.base.Field object>`

class `sushy.resources.common.IdRefField` (**args, **kwargs*)

Bases: `sushy.resources.base.CompositeField`

Reference to the resource odata identity field.

resource_uri = `<sushy.resources.base.Field object>`

The unique identifier for a resource

class `sushy.resources.common.IndentifiersListField(*args, **kwargs)`

Bases: `sushy.resources.base.ListField`

This type describes any additional identifiers for a resource.

durable_name = `<sushy.resources.base.Field object>`

This indicates the world wide, persistent name of the resource.

durable_name_format = `<sushy.resources.base.MappedField object>`

This represents the format of the DurableName property.

class `sushy.resources.common.InitializeActionField(*args, **kwargs)`

Bases: `sushy.resources.common.ActionField`

allowed_values = `<sushy.resources.base.Field object>`

class `sushy.resources.common.OperationApplyTimeSupportField`

Bases: `sushy.resources.base.CompositeField`

maintenance_window_duration_in_seconds = `<sushy.resources.base.Field object>`

The expiry time of maintenance window in seconds

maintenance_window_start_time = `<sushy.resources.base.Field object>`

The start time of a maintenance window

supported_values = `<sushy.resources.base.Field object>`

The client is allowed request when performing a create, delete, or action operation

class `sushy.resources.common.ResetActionField(*args, **kwargs)`

Bases: `sushy.resources.common.ActionField`

allowed_values = `<sushy.resources.base.Field object>`

class `sushy.resources.common.StatusField(*args, **kwargs)`

Bases: `sushy.resources.base.CompositeField`

This Field describes the status of a resource and its children.

This field shall contain any state or health properties of a resource.

health = `<sushy.resources.base.MappedField object>`

Represents health of resource w/o considering its dependent resources

health_rollup = `<sushy.resources.base.MappedField object>`

Represents health state of resource and its dependent resources

state = `<sushy.resources.base.MappedField object>`

Indicates the known state of the resource, such as if it is enabled.

sushy.resources.constants module

`sushy.resources.constants.INDICATOR_LED_BLINKING = 'indicator led blinking'`

The Indicator LED is blinking

`sushy.resources.constants.INDICATOR_LED_LIT = 'indicator led lit'`

The Indicator LED is lit

`sushy.resources.constants.INDICATOR_LED_OFF = 'indicator led off'`

The Indicator LED is off

`sushy.resources.constants.INDICATOR_LED_UNKNOWN = 'indicator led unknown'`
 The state of the Indicator LED cannot be determine

`sushy.resources.constants.POWER_STATE_OFF = 'off'`
 The resource is powered off, although some components may continue to have AUX power such as management controller

`sushy.resources.constants.POWER_STATE_ON = 'on'`
 The resource is powered on

`sushy.resources.constants.POWER_STATE_POWERING_OFF = 'powering off'`
 A temporary state between On and Off. The power off action can take time while the OS is in the shutdown process

`sushy.resources.constants.POWER_STATE_POWERING_ON = 'powering on'`
 A temporary state between Off and On. This temporary state can be very short

`sushy.resources.constants.RESET_TYPE_FORCE_OFF = 'force off'`
 Turn the unit off immediately (non-graceful shutdown)

`sushy.resources.constants.RESET_TYPE_FORCE_ON = 'force on'`
 Turn the unit on immediately

`sushy.resources.constants.RESET_TYPE_FORCE_RESTART = 'force restart'`
 Perform an immediate (non-graceful) shutdown, followed by a restart

`sushy.resources.constants.RESET_TYPE_GRACEFUL_RESTART = 'graceful restart'`
 Perform a graceful shutdown followed by a restart of the system

`sushy.resources.constants.RESET_TYPE_GRACEFUL_SHUTDOWN = 'graceful shutdown'`
 Perform a graceful shutdown and power off

`sushy.resources.constants.RESET_TYPE_NMI = 'nmi'`
 Generate a Diagnostic Interrupt (usually an NMI on x86 systems) to cease normal operations, perform diagnostic actions and typically halt the system

`sushy.resources.constants.RESET_TYPE_ON = 'on'`
 Turn the unit on

`sushy.resources.constants.RESET_TYPE_POWER_CYCLE = 'power cycle'`
 Perform a power cycle of the unit

`sushy.resources.constants.RESET_TYPE_PUSH_POWER_BUTTON = 'push power button'`
 Simulate the pressing of the physical power button on this unit

sushy.resources.mappings module

sushy.resources.settings module

```
class sushy.resources.settings.MaintenanceWindowField(*args,
                                                    **kwargs)
    Bases: sushy.resources.base.CompositeField
    maintenance_window_duration_in_seconds = <sushy.resources.base.Field object>
        The expiry time of maintenance window in seconds
    maintenance_window_start_time = <sushy.resources.base.Field object>
        The start time of a maintenance window
```

```
sushy.resources.settings.NO_UPDATES = 4
    No updates made
```

```
class sushy.resources.settings.SettingsApplyTimeField
```

```
    Bases: sushy.resources.base.CompositeField
```

```
    apply_time = <sushy.resources.base.Field object>
```

```
        When the future configuration should be applied
```

```
    apply_time_allowable_values = <sushy.resources.base.Field object>
```

```
        The list of allowable ApplyTime values
```

```
    maintenance_window_duration_in_seconds = <sushy.resources.base.Field object>
```

```
        The expiry time of maintenance window in seconds
```

```
    maintenance_window_start_time = <sushy.resources.base.Field object>
```

```
        The start time of a maintenance window
```

```
class sushy.resources.settings.SettingsField
```

```
    Bases: sushy.resources.base.CompositeField
```

```
    The settings of a resource
```

Represents the future state and configuration of the resource. The field is added to resources that support future state and configuration.

This field includes several properties to help clients monitor when the resource is consumed by the service and determine the results of applying the values, which may or may not have been successful.

```
commit (connector, value)
```

```
    Commits new settings values
```

```
    The new values will be applied when the system or a service restarts.
```

Parameters

- **connector** – A Connector instance
- **value** – Value representing JSON whose structure is specific to each resource and the caller must format it correctly

```
get_status (registries)
```

```
    Determines the status of last update based
```

```
    Uses message id-s and severity to determine the status.
```

```
    Parameters registries – registries to use to parse message
```

```
    Returns SettingsUpdate object containing status and any messages
```

```
property maintenance_window
```

```
    MaintenanceWindow field
```

```
    Indicates if a given resource has a maintenance window assignment for applying settings or operations
```

```
messages = <sushy.resources.base.MessageListField object>
```

```
    Represents the results of the last time the values of the Settings resource were applied to the server
```


property operation_apply_time_support

OperationApplyTimeSupport field

Indicates if a client is allowed to request for a specific apply time of a create, delete, or action operation of a given resource

property resource_uri

time = <sushy.resources.base.Field object>

Indicates the time the settings were applied to the server

class sushy.resources.settings.SettingsUpdate (*status, messages*)

Bases: object

Contains Settings update status and details of the update

property messages

List of *MessageListField* with messages from the update

property status

The status of the update

sushy.resources.settings.UPDATE_FAILURE = 2

Update encountered errors

sushy.resources.settings.UPDATE_PENDING = 3

Update waiting for being applied

sushy.resources.settings.UPDATE_SUCCESS = 1

Update was successful

sushy.resources.settings.UPDATE_UNKNOWN = 0

Update status unknown

sushy.resources.task_monitor module

class sushy.resources.task_monitor.TaskMonitor (*connector, path="", redfish_version=None*)

Bases: *sushy.resources.base.ResourceBase*

property in_progress

Checks the status of the async task

Returns True if the async task is still in progress, False otherwise

property location_header

The Location header returned from the GET on the Task Monitor

Returns The Location header (an absolute URL)

property response

The response from the last TaskMonitor in_progress check

Returns The *requests* response object or None

property retry_after

Time the client should wait before querying the task status

Returns The Retry-After time in *datetime* format

set_retry_after (*value*)

Set the time the client should wait before querying the task status

Parameters **value** – The value of the Retry-After header, which can be the number of seconds to wait or an *HTTP-date* string as defined by RFC 7231

Returns The TaskMonitor object

property sleep_for

Seconds the client should wait before querying the operation status

Returns The number of seconds to wait

Module contents

Submodules

sushy.auth module

class `sushy.auth.AuthBase` (*username=None, password=None*)

Bases: `object`

authenticate ()

Perform authentication.

Raises `RuntimeError`

abstract can_refresh_session ()

Method to assert if session based refresh can be done.

close ()

Shutdown Redfish authentication object

Undoes whatever should be undone to cancel authenticated session.

set_context (*root_resource, connector*)

Set the context of the authentication object.

Parameters

- **root_resource** – Root sushy object
- **connector** – Connector for http connections

class `sushy.auth.BasicAuth` (*username=None, password=None*)

Bases: `sushy.auth.AuthBase`

Basic Authentication class.

This is a class used to encapsulate a basic authentication session.

Parameters

- **username** – User account with admin/server-profile access privilege.
- **password** – User account password.

can_refresh_session ()

Method to assert if session based refresh can be done.

class `sushy.auth.SessionAuth` (*username=None, password=None*)

Bases: `sushy.auth.AuthBase`

Session Authentication class.

This is a class used to encapsulate a redfish session.

can_refresh_session ()

Method to assert if session based refresh can be done.

close ()

Close the Redfish Session.

Attempts to close an established RedfishSession by deleting it from the remote Redfish controller.

get_session_key ()

Returns the session key.

Returns The session key.

get_session_resource_id ()

Returns the session resource id.

Returns The session resource id.

refresh_session ()

Method to refresh a session to a Redfish controller.

This method is called to create a new session after a session that has already been established has timed-out or expired.

Raises `MissingXAuthToken`

Raises `ConnectionError`

Raises `AccessError`

Raises `HTTPError`

reset_session_attrs ()

Reset active session related attributes.

class `sushy.auth.SessionOrBasicAuth` (*username=None, password=None*)

Bases: `sushy.auth.SessionAuth`

refresh_session ()

Method to refresh a session to a Redfish controller.

This method is called to create a new RedfishSession if we have previously established a RedfishSession and the previous session has timed-out or expired. If we did not previously have an established session, we simply return our BasicAuthentication requests.Session.

sushy.connector module

class `sushy.connector.Connector` (*url*, *username=None*, *password=None*, *verify=True*, *response_callback=None*)

Bases: `object`

close ()

Close this connector and the associated HTTP session.

delete (*path=""*, *data=None*, *headers=None*, *blocking=False*, *timeout=60*, ***extra_session_req_kwargs*)
HTTP DELETE method.

Parameters

- **path** – Optional sub-URI path to the resource.
- **data** – Optional JSON data.
- **headers** – Optional dictionary of headers.
- **blocking** – Whether to block for asynchronous operations.
- **timeout** – Max time in seconds to wait for blocking async call.
- **extra_session_req_kwargs** – Optional keyword argument to pass requests library arguments which would pass on to requests session object.

Returns The response object from the requests library.

Raises `ConnectionError`

Raises `HTTPError`

get (*path=""*, *data=None*, *headers=None*, *blocking=False*, *timeout=60*, ***extra_session_req_kwargs*)
HTTP GET method.

Parameters

- **path** – Optional sub-URI path to the resource.
- **data** – Optional JSON data.
- **headers** – Optional dictionary of headers.
- **blocking** – Whether to block for asynchronous operations.
- **timeout** – Max time in seconds to wait for blocking async call.
- **extra_session_req_kwargs** – Optional keyword argument to pass requests library arguments which would pass on to requests session object.

Returns The response object from the requests library.

Raises `ConnectionError`

Raises `HTTPError`

patch (*path=""*, *data=None*, *headers=None*, *blocking=False*, *timeout=60*, ***extra_session_req_kwargs*)
HTTP PATCH method.

Parameters

- **path** – Optional sub-URI path to the resource.
- **data** – Optional JSON data.
- **headers** – Optional dictionary of headers.
- **blocking** – Whether to block for asynchronous operations.
- **timeout** – Max time in seconds to wait for blocking async call.
- **extra_session_req_kwargs** – Optional keyword argument to pass requests library arguments which would pass on to requests session object.

Returns The response object from the requests library.

Raises ConnectionError

Raises HTTPError

post (*path=""*, *data=None*, *headers=None*, *blocking=False*, *timeout=60*, ***extra_session_req_kwargs*)
HTTP POST method.

Parameters

- **path** – Optional sub-URI path to the resource.
- **data** – Optional JSON data.
- **headers** – Optional dictionary of headers.
- **blocking** – Whether to block for asynchronous operations.
- **timeout** – Max time in seconds to wait for blocking async call.
- **extra_session_req_kwargs** – Optional keyword argument to pass requests library arguments which would pass on to requests session object.

Returns The response object from the requests library.

Raises ConnectionError

Raises HTTPError

put (*path=""*, *data=None*, *headers=None*, *blocking=False*, *timeout=60*, ***extra_session_req_kwargs*)
HTTP PUT method.

Parameters

- **path** – Optional sub-URI path to the resource.
- **data** – Optional JSON data.
- **headers** – Optional dictionary of headers.
- **blocking** – Whether to block for asynchronous operations.
- **timeout** – Max time in seconds to wait for blocking async call.
- **extra_session_req_kwargs** – Optional keyword argument to pass requests library arguments which would pass on to requests session object.

Returns The response object from the requests library.

Raises ConnectionError

Raises `HTTPError`

- set_auth** (*auth*)
Sets the authentication mechanism for our connector.
- set_http_basic_auth** (*username, password*)
Sets the http basic authentication information.
- set_http_session_auth** (*session_auth_token*)
Sets the session authentication information.

sushy.exceptions module

exception `sushy.exceptions.AccessError` (*method, url, response*)
Bases: `sushy.exceptions.HTTPError`

exception `sushy.exceptions.ArchiveParsingError` (**kwargs)
Bases: `sushy.exceptions.SushyError`

message = 'Failed parsing archive "%(path)s": %(error)s'

exception `sushy.exceptions.BadRequestError` (*method, url, response*)
Bases: `sushy.exceptions.HTTPError`

exception `sushy.exceptions.ConnectionError` (**kwargs)
Bases: `sushy.exceptions.SushyError`

message = 'Unable to connect to %(url)s. Error: %(error)s'

exception `sushy.exceptions.ExtensionError` (**kwargs)
Bases: `sushy.exceptions.SushyError`

message = 'Sushy Extension Error: %(error)s'

exception `sushy.exceptions.HTTPError` (*method, url, response*)
Bases: `sushy.exceptions.SushyError`

Basic exception for HTTP errors

body = `None`
Error JSON body, if present.

code = 'Base.1.0.GeneralError'
Error code defined in the Redfish specification, if present.

detail = `None`
Error message defined in the Redfish specification, if present.

message = 'HTTP %(method)s %(url)s returned code %(code)s. %(error)s'

status_code = `None`
HTTP status code.

exception `sushy.exceptions.InvalidParameterValueError` (**kwargs)
Bases: `sushy.exceptions.SushyError`

message = 'The parameter "%(parameter)s" value "%(value)s" is invalid. Valid

exception `sushy.exceptions.MalformedAttributeError` (**kwargs)
Bases: `sushy.exceptions.SushyError`

```

    message = 'The attribute %(attribute)s is malformed in the resource %(resource)s'
exception sushy.exceptions.MissingActionError(**kwargs)
    Bases: sushy.exceptions.SushyError

    message = 'The action %(action)s is missing from the resource %(resource)s'
exception sushy.exceptions.MissingAttributeError(**kwargs)
    Bases: sushy.exceptions.SushyError

    message = 'The attribute %(attribute)s is missing from the resource %(resource)s'
exception sushy.exceptions.MissingHeaderError(**kwargs)
    Bases: sushy.exceptions.SushyError

    message = 'Response to %(target_uri)s did not contain a %(header)s header'
exception sushy.exceptions.MissingXAuthToken(method, url, response)
    Bases: sushy.exceptions.HTTPError

    message = 'No X-Auth-Token returned from remote host when attempting to establish connection'
exception sushy.exceptions.OEMExtensionNotFoundError(**kwargs)
    Bases: sushy.exceptions.SushyError

    message = 'No %(resource)s OEM extension found by name "%(name)s".'
exception sushy.exceptions.ResourceNotFoundError(method, url, response)
    Bases: sushy.exceptions.HTTPError

    message = 'Resource %(url)s not found'
exception sushy.exceptions.ServerSideError(method, url, response)
    Bases: sushy.exceptions.HTTPError

exception sushy.exceptions.SushyError(**kwargs)
    Bases: Exception

    Basic exception for errors raised by Sushy

    message = None

exception sushy.exceptions.UnknownDefaultError(**kwargs)
    Bases: sushy.exceptions.SushyError

    message = 'Failed at determining default for "%(entity)s": %(error)s'

sushy.exceptions.raise_for_response(method, url, response)
    Raise a correct error class, if needed.

```

sushy.main module

```

class sushy.main.LazyRegistries(service_root)
    Bases: collections.abc.MutableMapping

```

Download registries on demand.

Redfish message registries can be very large. On top of that, they are not used frequently. Thus, let's not pull them off the BMC unless the consumer is actually trying to use them.

Parameters `service_root` (`sushy.main.Sushy`) – Redfish service root object

property registries

class `sushy.main.ProtocolFeaturesSupportedField` (*args, **kwargs)

Bases: `sushy.resources.base.CompositeField`

excerpt_query = <`sushy.resources.base.Field` object>

The excerpt query parameter is supported

expand_query = <`sushy.resources.base.Field` object>

The expand query parameter is supported

filter_query = <`sushy.resources.base.Field` object>

The filter query parameter is supported

only_member_query = <`sushy.resources.base.Field` object>

The only query parameter is supported

select_query = <`sushy.resources.base.Field` object>

The select query parameter is supported

class `sushy.main.Sushy` (`base_url`, `username=None`, `password=None`,
`root_prefix='/redfish/v1/'`, `verify=True`, `auth=None`, `con-`
`connector=None`, `public_connector=None`, `language='en'`)

Bases: `sushy.resources.base.ResourceBase`

create_session (`username=None`, `password=None`)

Creates a session without invoking SessionService.

For use when a new connection is to be established. Removes prior Session and authentication data before making the request.

Parameters

- **username** – The username to utilize to create a session with the remote endpoint.
- **password** – The password to utilize to create a session with the remote endpoint.

Returns A session key and uri in the form of a tuple

Raises `MissingXAuthToken`

Raises `ConnectionError`

Raises `AccessError`

Raises `HTTPError`

Raises `MissingAttributeError`

get_chassis (`identity=None`)

Given the identity return a Chassis object

Parameters **identity** – The identity of the Chassis resource. If not given, sushy will default to the single available chassis or fail if there appear to be more or less than one Chassis listed.

Raises `UnknownDefaultError` if default system can't be determined.

Returns The Chassis object

get_chassis_collection()

Get the ChassisCollection object

Raises MissingAttributeError, if the collection attribute is not found

Returns a ChassisCollection object

get_composition_service()

Get the CompositionService object

Raises MissingAttributeError, if the composition service attribute is not found

Returns The CompositionService object

get_fabric(identity)

Given the identity return a Fabric object

Parameters *identity* – The identity of the Fabric resource

Returns The Fabric object

get_fabric_collection()

Get the FabricCollection object

Raises MissingAttributeError, if the collection attribute is not found

Returns a FabricCollection object

get_manager(identity=None)

Given the identity return a Manager object

Parameters *identity* – The identity of the Manager resource. If not given, sushy will default to the single available Manager or fail if there appear to be more or less than one Manager listed.

Returns The Manager object

get_manager_collection()

Get the ManagerCollection object

Raises MissingAttributeError, if the collection attribute is not found

Returns a ManagerCollection object

get_session(identity)

Given the identity return a Session object

Parameters *identity* – The identity of the session resource

Returns The Session object

get_session_service()

Get the SessionService object

Raises MissingAttributeError, if the collection attribute is not found

Returns as SessionCollection object

get_sessions_path()

Returns the Sessions url

get_system(identity=None)

Given the identity return a System object

Parameters `identity` – The identity of the System resource. If not given, sushy will default to the single available System or fail if there appear to be more or less than one System listed.

Raises `UnknownDefaultError` if default system can't be determined.

Returns The System object

get_system_collection()

Get the SystemCollection object

Raises `MissingAttributeError`, if the collection attribute is not found

Returns a SystemCollection object

get_update_service()

Get the UpdateService object

Returns The UpdateService object

identity = <sushy.resources.base.Field object>

The Redfish root service identity

property lazy_registries

Gets and combines all message registries together

Fetches all registries if any provided by Redfish service and combines together with packaged standard registries.

Returns dict of combined message registries where key is `Registry_name.Major_version.Minor_version` and value is registry itself.

name = <sushy.resources.base.Field object>

The Redfish root service name

product = <sushy.resources.base.Field object>

The product associated with this Redfish service

protocol_features_supported = <sushy.main.ProtocolFeaturesSupportedField object>

The information about protocol features supported by the service

property registries

Gets and combines all message registries together

Fetches all registries if any provided by Redfish service and combines together with packaged standard registries.

Returns dict of combined message registries keyed by both the registry name (`Registry_name.Major_version.Minor_version`) and the message registry file identity, with the value being the actual registry itself.

uuid = <sushy.resources.base.Field object>

The Redfish root service UUID

sushy.utils module

`sushy.utils.bool_or_none(x)`

Given a value `x` this method returns either a bool or None

Parameters `x` – The value to transform and return

Returns Either None or `x` cast to a bool

`sushy.utils.cache_clear(res_selfie, force_refresh, only_these=None)`

Clear some or all cached values of the resource.

If the cache variable refers to a resource instance then the `invalidate()` method is called on that. Otherwise it is set to None. Should there be a need to force refresh the resource and its sub-resources, “cascading refresh”, `force_refresh` is to be set to True.

This is the complimentary method of `cache_it` decorator.

Parameters

- **res_selfie** – the resource instance.
- **force_refresh** – `force_refresh` argument of `invalidate()` method.
- **only_these** – expects a sequence of specific method names for which the cached value/s need to be cleared only. When None, all the cached values are cleared.

`sushy.utils.cache_it(res_accessor_method)`

Utility decorator to cache the return value of the decorated method.

This decorator is to be used with any Sushy resource class method. This will internally create an attribute on the resource namely `_cache_<decorated_method_name>`. This is referred to as the “caching attribute”. This attribute will eventually hold the resultant value from the method invocation (when method gets first time called) and for every subsequent calls to that method this cached value will get returned. It expects the decorated method to contain its own logic of evaluation.

This also assigns a variable named `_cache_attr_names` on the resource. This variable maintains a collection of all the existing “caching attribute” names.

To invalidate or clear the cache use `cache_clear()`. Usage:

```
class SomeResource(base.ResourceBase):
    ...
    @cache_it
    def get_summary(self):
        # do some calculation and return the result
        # and this result will be cached.
        return result
    ...
    def _do_refresh(self, force):
        cache_clear(self, force)
```

If the returned value is a Sushy resource instance or a sequence whose element is of type Sushy resource it handles the case of calling the `refresh()` method of that resource. This is done to avoid unnecessary recreation of a new resource instance which got already created at the first place in contrast to fresh retrieval of the resource json data. Again, the `force` argument is deliberately

set to False to do only the “light refresh” of the resource (only the fresh retrieval of resource) instead of doing the complete exhaustive “cascading refresh” (resource with all its nested subresources recursively).

```
class SomeResource(base.ResourceBase):
    ...
    @property
    @cache_it
    def nested_resource(self):
        return NestedResource(
            self._conn, "Path/to/NestedResource",
            redfish_version=self.redfish_version)
    ...
    def _do_refresh(self, force):
        # selective attribute clearing
        cache_clear(self, force, only_these=['nested_resource'])
```

Do note that this is not thread safe. So guard your code to protect it from any kind of concurrency issues while using this decorator.

Parameters `res_accessor_method` – the resource accessor decorated method.

`sushy.utils.camelcase_to_underscore_joined` (*camelcase_str*)

Convert camelCase string to underscore_joined string

Parameters `camelcase_str` – The camelCase string

Returns the equivalent underscore_joined string

`sushy.utils.get_members_identities` (*members*)

Extract and return a tuple of members identities

Parameters `members` – A list of members in JSON format

Returns A tuple containing the members paths

`sushy.utils.get_sub_resource_path_by` (*resource*, *subresource_name*, *is_collection=False*)

Helper function to find the subresource path

Parameters

- **resource** – ResourceBase instance on which the name gets queried upon.
- **subresource_name** – name of the resource field to fetch the ‘@odata.id’ from.
- **is_collection** – if *True*, expect a list of resources to fetch the ‘@odata.id’ from.

Returns Resource path (if *is_collection* is *False*) or a list of resource paths (if *is_collection* is *True*).

`sushy.utils.int_or_none` (*x*)

Given a value *x* it cast as int or None

Parameters `x` – The value to transform and return

Returns Either None or *x* cast to an int

`sushy.utils.max_safe` (*iterable*, *default=0*)

Helper wrapper over builtin `max()` function.

This function is just a wrapper over builtin `max()` w/o key argument. The default argument specifies an object to return if the provided `iterable` is empty. Also it filters out the `None` type values.

Parameters

- **iterable** – an iterable
- **default** – 0 by default

`sushy.utils.revert_dictionary` (*dictionary*)

Given a dictionary revert it's mapping

Parameters **dictionary** – A dictionary to be reverted

Returns A dictionary with the keys and values reverted

`sushy.utils.sanitize` (*item*)

Remove passwords from the item.

`sushy.utils.setdefaultattr` (*obj, name, default*)

Python's `dict.setdefault` applied on Python objects.

If name is an attribute with obj, return its value. If not, set name attribute with a value of default and return default.

Parameters

- **obj** – a python object
- **name** – name of attribute
- **default** – default value to be set

`sushy.utils.synchronized` (*wrapped*)

Simple synchronization decorator.

Decorating a method like so:

```
@synchronized
def foo(self, *args):
    ...
```

ensures that only one thread will execute the foo method at a time.

Module contents

class `sushy.Sushy` (*base_url, username=None, password=None, root_prefix='/redfish/v1/', verify=True, auth=None, connector=None, public_connector=None, language='en'*)

Bases: `sushy.resources.base.ResourceBase`

create_session (*username=None, password=None*)

Creates a session without invoking `SessionService`.

For use when a new connection is to be established. Removes prior `Session` and authentication data before making the request.

Parameters

- **username** – The username to utilize to create a session with the remote endpoint.
- **password** – The password to utilize to create a session with the remote endpoint.

Returns A session key and uri in the form of a tuple

Raises MissingXAuthToken

Raises ConnectionError

Raises AccessError

Raises HTTPError

Raises MissingAttributeError

get_chassis (*identity=None*)

Given the identity return a Chassis object

Parameters **identity** – The identity of the Chassis resource. If not given, sushy will default to the single available chassis or fail if there appear to be more or less than one Chassis listed.

Raises *UnknownDefaultError* if default system can't be determined.

Returns The Chassis object

get_chassis_collection ()

Get the ChassisCollection object

Raises MissingAttributeError, if the collection attribute is not found

Returns a ChassisCollection object

get_composition_service ()

Get the CompositionService object

Raises MissingAttributeError, if the composition service attribute is not found

Returns The CompositionService object

get_fabric (*identity*)

Given the identity return a Fabric object

Parameters **identity** – The identity of the Fabric resource

Returns The Fabric object

get_fabric_collection ()

Get the FabricCollection object

Raises MissingAttributeError, if the collection attribute is not found

Returns a FabricCollection object

get_manager (*identity=None*)

Given the identity return a Manager object

Parameters **identity** – The identity of the Manager resource. If not given, sushy will default to the single available Manager or fail if there appear to be more or less than one Manager listed.

Returns The Manager object

get_manager_collection()

Get the ManagerCollection object

Raises MissingAttributeError, if the collection attribute is not found

Returns a ManagerCollection object

get_session(identity)

Given the identity return a Session object

Parameters **identity** – The identity of the session resource

Returns The Session object

get_session_service()

Get the SessionService object

Raises MissingAttributeError, if the collection attribute is not found

Returns as SessionCollection object

get_sessions_path()

Returns the Sessions url

get_system(identity=None)

Given the identity return a System object

Parameters **identity** – The identity of the System resource. If not given, sushy will default to the single available System or fail if there appear to be more or less then one System listed.

Raises *UnknownDefaultError* if default system can't be determined.

Returns The System object

get_system_collection()

Get the SystemCollection object

Raises MissingAttributeError, if the collection attribute is not found

Returns a SystemCollection object

get_update_service()

Get the UpdateService object

Returns The UpdateService object

identity = <sushy.resources.base.Field object>

The Redfish root service identity

property lazy_registries

Gets and combines all message registries together

Fetches all registries if any provided by Redfish service and combines together with packaged standard registries.

Returns dict of combined message registries where key is Registry_name.Major_version.Minor_version and value is registry itself.

name = <sushy.resources.base.Field object>

The Redfish root service name

product = <sushy.resources.base.Field object>

The product associated with this Redfish service

protocol_features_supported = <sushy.main.ProtocolFeaturesSupportedField object>

The information about protocol features supported by the service

property registries

Gets and combines all message registries together

Fetches all registries if any provided by Redfish service and combines together with packaged standard registries.

Returns dict of combined message registries keyed by both the registry name (Registry_name.Major_version.Minor_version) and the message registry file identity, with the value being the actual registry itself.

uuid = <sushy.resources.base.Field object>

The Redfish root service UUID

- genindex

PYTHON MODULE INDEX

S

sushy, 81
sushy.auth, 70
sushy.connector, 72
sushy.exceptions, 74
sushy.main, 75
sushy.resources, 70
sushy.resources.base, 62
sushy.resources.chassis, 22
sushy.resources.chassis.chassis, 17
sushy.resources.chassis.constants, 20
sushy.resources.chassis.mappings, 22
sushy.resources.chassis.power, 15
sushy.resources.chassis.power.constants, 12
sushy.resources.chassis.power.mappings, 13
sushy.resources.chassis.power.power, 13
sushy.resources.chassis.thermal, 17
sushy.resources.chassis.thermal.constants, 15
sushy.resources.chassis.thermal.mappings, 15
sushy.resources.chassis.thermal.thermal, 15
sushy.resources.common, 65
sushy.resources.compositionservice, 25
sushy.resources.compositionservice.compositionservice, 22
sushy.resources.compositionservice.constants, 23
sushy.resources.compositionservice.mappings, 23
sushy.resources.compositionservice.resourceservice, 23
sushy.resources.compositionservice.resourcezone, 24
sushy.resources.constants, 66
sushy.resources.fabric, 28
sushy.resources.fabric.constants, 25
sushy.resources.fabric.endpoint, 25
sushy.resources.fabric.fabric, 28
sushy.resources.fabric.mappings, 28
sushy.resources.manager, 33
sushy.resources.manager.constants, 29
sushy.resources.manager.manager, 30
sushy.resources.manager.mappings, 32
sushy.resources.manager.virtual_media, 32
sushy.resources.mappings, 67
sushy.resources.oem, 34
sushy.resources.oem.base, 33
sushy.resources.oem.common, 33
sushy.resources.oem.fake, 34
sushy.resources.registry, 38
sushy.resources.registry.message_registry, 35
sushy.resources.registry.message_registry_file, 36
sushy.resources.sessionservice, 40
sushy.resources.sessionservice.session, 38
sushy.resources.sessionservice.sessionservice, 39
sushy.resources.settings, 67
sushy.resources.system, 58
sushy.resources.system.bios, 47
sushy.resources.system.constants, 49
sushy.resources.system.ethernet_interface, 50
sushy.resources.system.mappings, 51
sushy.resources.system.processor, 51
sushy.resources.system.simple_storage,

- 53
- sushy.resources.system.storage, 47
- sushy.resources.system.storage.constants, 40
- sushy.resources.system.storage.drive, 42
- sushy.resources.system.storage.mappings, 43
- sushy.resources.system.storage.storage, 43
- sushy.resources.system.storage.volume, 45
- sushy.resources.system.system, 54
- sushy.resources.task_monitor, 69
- sushy.resources.taskservice, 59
- sushy.resources.taskservice.mappings, 58
- sushy.resources.taskservice.task, 58
- sushy.resources.taskservice.taskmonitor, 59
- sushy.resources.updateservice, 62
- sushy.resources.updateservice.constants, 59
- sushy.resources.updateservice.mappings, 59
- sushy.resources.updateservice.softwareinventory, 60
- sushy.resources.updateservice.updateservice, 61
- sushy.utils, 79

INDEX

A

- AbstractDataReader (class in *sushy.resources.base*), 62
- AccessError, 74
- ActionField (class in *sushy.resources.common*), 65
- ActionsField (class in *sushy.resources.chassis.chassis*), 17
- ActionsField (class in *sushy.resources.manager.manager*), 30
- ActionsField (class in *sushy.resources.manager.virtual_media*), 32
- ActionsField (class in *sushy.resources.system.bios*), 47
- ActionsField (class in *sushy.resources.system.storage.volume*), 45
- ActionsField (class in *sushy.resources.system.system*), 54
- ActionsField (class in *sushy.resources.updateservice.updateservice*), 61
- address (*sushy.resources.fabric.endpoint.IPv4AddressField* attribute), 27
- address (*sushy.resources.fabric.endpoint.IPv6AddressField* attribute), 27
- address_origin (*sushy.resources.fabric.endpoint.IPv4AddressField* attribute), 27
- address_origin (*sushy.resources.fabric.endpoint.IPv6AddressField* attribute), 27
- address_state (*sushy.resources.fabric.endpoint.IPv6AddressField* attribute), 27
- ADDRESS_STATE_DEPRECATED (in module *sushy.resources.fabric.constants*), 25
- ADDRESS_STATE_FAILED (in module *sushy.resources.fabric.constants*), 25
- ADDRESS_STATE_PREFERRED (in module *sushy.resources.fabric.constants*), 25
- ADDRESS_STATE_TENTATIVE (in module *sushy.resources.fabric.constants*), 25
- allow_overprovisioning (*sushy.resources.compositionservice.compositionservice.CompositionService* attribute), 22
- allow_zone_affinity (*sushy.resources.compositionservice.compositionservice.CompositionService* attribute), 22
- allowed_values (*sushy.resources.common.InitializeActionField* attribute), 66
- allowed_values (*sushy.resources.common.ResetActionField* attribute), 66
- allowed_values (*sushy.resources.system.system.BootField* attribute), 54
- apply_time (*sushy.resources.settings.SettingsApplyTimeField* attribute), 68
- apply_time_allowable_values (*sushy.resources.settings.SettingsApplyTimeField* attribute), 68
- apply_time_settings () (*sushy.resources.system.bios.Bios* property), 47
- architecture (*sushy.resources.system.processor.ProcessorSummary* attribute), 52
- archive_file (*sushy.resources.registry.message_registry_file.LocationListFile* attribute), 36
- archive_uri (*sushy.resources.registry.message_registry_file.LocationListFile* attribute), 36
- ArchiveParsingError, 74
- asset_tag (*sushy.resources.chassis.chassis.Chassis* attribute), 17
- asset_tag (*sushy.resources.system.system.System* attribute), 54
- attributes (*sushy.resources.system.bios.Bios* attribute), 47

AuthBase (class in *sushy.auth*), 70

authenticate() (*sushy.auth.AuthBase* method), 70

auto_dst_enabled (*sushy.resources.manager.manager.Manager* attribute), 30

B

BadRequestError, 74

BasicAuth (class in *sushy.auth*), 70

Bios (class in *sushy.resources.system.bios*), 47

bios() (*sushy.resources.system.system.System* property), 54

bios_version (*sushy.resources.system.system.System* attribute), 54

block_size_bytes (*sushy.resources.system.storage.drive.Drive* attribute), 42

block_size_bytes (*sushy.resources.system.storage.volume.Volume* attribute), 45

body (*sushy.exceptions.HTTPError* attribute), 74

bool_or_none() (in module *sushy.utils*), 79

boot (*sushy.resources.system.system.System* attribute), 54

BOOT_SOURCE_TARGET_BIOS_SETUP (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_CD (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_DIAGS (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_FLOPPY (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_HDD (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_NONE (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_PXE (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_SD_CARD (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_UEFI_HTTP (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_UEFI_SHELL (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_UEFI_TARGET (in module *sushy.resources.system.constants*),

49

BOOT_SOURCE_TARGET_USB (in module *sushy.resources.system.constants*), 49

BOOT_SOURCE_TARGET_UTILITIES (in module *sushy.resources.system.constants*), 49

BootField (class in *sushy.resources.system.system*), 54

C

cache_clear() (in module *sushy.utils*), 79

cache_it() (in module *sushy.utils*), 79

camelcase_to_underscore_joined() (in module *sushy.utils*), 80

can_refresh_session() (*sushy.auth.AuthBase* method), 70

can_refresh_session() (*sushy.auth.BasicAuth* method), 70

can_refresh_session() (*sushy.auth.SessionAuth* method), 71

cancellable() (*sushy.resources.taskservice.taskmonitor.TaskMonitor* property), 59

capacity_bytes (*sushy.resources.system.simple_storage.DeviceListField* attribute), 53

capacity_bytes (*sushy.resources.system.storage.drive.Drive* attribute), 42

capacity_bytes (*sushy.resources.system.storage.volume.Volume* attribute), 45

change_password (*sushy.resources.system.bios.ActionsField* attribute), 47

change_password() (*sushy.resources.system.bios.Bios* method), 47

Chassis (class in *sushy.resources.chassis.chassis*), 17

chassis() (*sushy.resources.manager.manager.Manager* property), 30

chassis() (*sushy.resources.system.system.System* property), 54

CHASSIS_INTRUSION_SENSOR_HARDWARE_INTRUSION (in module *sushy.resources.chassis.constants*), 20

CHASSIS_INTRUSION_SENSOR_NORMAL (in module *sushy.resources.chassis.constants*), 20

CHASSIS_INTRUSION_SENSOR_RE_ARM_AUTOMATIC

(in module 21
sushy.resources.chassis.constants), 20

CHASSIS_INTRUSION_SENSOR_RE_ARM_MANUAL (in module *sushy.resources.chassis.constants*), 21

(in module ChassisCollection (class in *sushy.resources.chassis.chassis*), 19

CHASSIS_INTRUSION_SENSOR_TAMPERING_DETECTIVE_RESOURCE() (in module *sushy.resources.base.ResourceBase* method), 64

chassis_type (in *sushy.resources.chassis.chassis.Chassis* attribute), 17

CHASSIS_TYPE_BLADE (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_CARD (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_CARTRIDGE (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_COMPONENT (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_DRAWER (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_ENCLOSURE (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_EXPANSION (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_IP_BASED_DRIVE (in module *sushy.resources.chassis.constants*), 20

CHASSIS_TYPE_MODULE (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_OTHER (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_POD (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_RACK (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_RACK_GROUP (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_RACK_MOUNT (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_ROW (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_SHELF (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_SIDE CAR (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_SLED (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_STAND_ALONE (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_STORAGE_ENCLOSURE (in module *sushy.resources.chassis.constants*), 21

CHASSIS_TYPE_ZONE (in module *sushy.resources.chassis.constants*), 21

ChassisCollection (class in *sushy.resources.chassis.chassis*), 19

close() (in *sushy.resources.base.ResourceBase* method), 64

close() (*sushy.auth.AuthBase* method), 70

close() (*sushy.auth.SessionAuth* method), 71

close() (*sushy.connector.Connector* method), 72

close_session() (*sushy.resources.sessionservice.sessionservice.SessionService* method), 39

code (*sushy.exceptions.HTTPError* attribute), 74

command_shell (*sushy.resources.manager.manager.Manager* attribute), 30

COMMAND_SHELL_IPMI (in module *sushy.resources.manager.constants*), 29

COMMAND_SHELL_OEM (in module *sushy.resources.manager.constants*), 29

COMMAND_SHELL_SSH (in module *sushy.resources.manager.constants*), 29

COMMAND_SHELL_TELNET (in module *sushy.resources.manager.constants*), 29

commit() (*sushy.resources.settings.SettingsField* method), 68

CompositeField (class in *sushy.resources.base*), 62

composition_state (*sushy.resources.compositionservice.resourceblock.Composition* attribute), 23

composition_status (*sushy.resources.compositionservice.resourceblock.ResourceBlock* attribute), 23

CompositionService (class in *sushy.resources.compositionservice.compositionservice*), 22

CompositionStatusField (class in *sushy.resources.compositionservice.resourceblock*), 23

connect_types_supported (*sushy.resources.manager.manager.RemoteAccessField* attribute), 31

connected_entities (*sushy.resources.fabric.endpoint.Endpoint* attribute), 31

attribute), 26

connected_via (sushy.resources.manager.virtual_media.VirtualMedia attribute), 32

ConnectedEntitiesListField (class in sushy.resources.fabric.endpoint), 25

ConnectionError, 74

Connector (class in sushy.connector), 72

ContosoActionsField (class in sushy.resources.oem.fake), 34

controller_protocols (sushy.resources.system.storage.storage.StorageControllersListField attribute), 44

count (sushy.resources.system.processor.ProcessorSummary attribute), 52

country (sushy.resources.oem.fake.ProductionLocationField attribute), 34

create_session() (sushy.main.Sushy method), 76

create_session() (sushy.resources.sessionservice.sessionservice.SessionService method), 39

create_session() (sushy.Sushy method), 81

create_volume() (sushy.resources.system.storage.volume.VolumeCollection method), 46

D

data_type (sushy.resources.oem.fake.FakeOEMSystemExtension attribute), 34

delete() (sushy.connector.Connector method), 72

delete() (sushy.resources.sessionservice.session.Session method), 38

delete_volume() (sushy.resources.system.storage.volume.Volume method), 45

depth_mm (sushy.resources.chassis.chassis.Chassis attribute), 17

description (sushy.resources.chassis.chassis.Chassis attribute), 17

description (sushy.resources.compositionservice.compositionservice.CompositionService attribute), 22

description (sushy.resources.compositionservice.resourceblock.ResourceBlock attribute), 23

description (sushy.resources.compositionservice.resourceblock.ResourceBlockCollection attribute), 24

description (sushy.resources.compositionservice.resourcezone.ResourceZone attribute), 24

description (sushy.resources.compositionservice.resourcezone.ResourceZoneCollection attribute), 25

description (sushy.resources.fabric.endpoint.Endpoint attribute), 26

description (sushy.resources.fabric.fabric.Fabric attribute), 28

description (sushy.resources.manager.manager.Manager attribute), 30

description (sushy.resources.registry.message_registry.MessageRegistry attribute), 35

description (sushy.resources.registry.message_registry.MessageRegistryFile attribute), 35

description (sushy.resources.registry.message_registry_file.MessageRegistryFile attribute), 37

description (sushy.resources.sessionservice.session.Session attribute), 38

description (sushy.resources.sessionservice.session.SessionCollection attribute), 38

description (sushy.resources.sessionservice.sessionservice.SessionService attribute), 39

description (sushy.resources.system.bios.Bios attribute), 47

description (sushy.resources.system.ethernet_interface.EthernetInterface attribute), 50

description (sushy.resources.system.system.System attribute), 55

description (sushy.resources.taskservice.task.TaskCollection attribute), 58

description (sushy.resources.update.service.softwareinventory.SoftwareInventory attribute), 60

description (sushy.exceptions.HTTPError attribute), 74

device_id (sushy.resources.fabric.endpoint.PciIdField attribute), 27

device_protocols (sushy.resources.system.storage.storage.StorageControllersListField attribute), 44

DeviceListField (class in sushy.resources.system.simple_storage), 53

devices (sushy.resources.system.simple_storage.SimpleStorage attribute), 53

DictionaryField (class in sushy.resources.base), 62

disks_sizes_bytes() (sushy.resources.system.simple_storage.SimpleStorageCollection property), 53

drive (class in sushy.resources.system.storage.drive), 42

drive_block (class in sushy.resources.system.storage.drive), 42

drives() (sushy.resources.system.storage.storage.StorageControllersListField attribute), 42

drives_identities (sushy.resources.system.storage.storage.StorageControllersListField attribute), 43

drives_max_size_bytes (*sushy.resources.system.storage.storage.StorageEthernetInterfaces* (*sushy.resources.system.system.System* *property*), 43
drives_sizes_bytes (*sushy.resources.system.storage.storage.StorageEthernetInterface* (*class* *in* *sushy.resources.system.ethernet_interface*), 43
drives_sizes_bytes (*sushy.resources.system.storage.storage.StorageEthernetInterfaceCollection* (*class* *in* *sushy.resources.system.ethernet_interface*), 44
durable_name (*sushy.resources.common.IdentifiersListField* *excerpt_query* *attribute*), 66
durable_name_format (*sushy.resources.common.IdentifiersListField* *expand_query* *attribute*), 66
E *ExtensionError*, 74
effective_family (*sushy.resources.system.processor.ProcessorIdField* *attribute*), 52
effective_model (*sushy.resources.system.processor.ProcessorIdField* *attribute*), 52
eject_media (*sushy.resources.manager.virtual_media.ActionsField* *attribute*), 32
eject_media (*sushy.resources.manager.virtual_media.VirtualMedia* *attribute*), 32
enabled (*sushy.resources.system.system.BootField* *attribute*), 54
encrypted (*sushy.resources.system.storage.volume.Volume* (*in* *sushy.resources.chassis.thermal.constants*), *attribute*), 45
end_time (*sushy.resources.taskservice.task.Task* *attribute*), 58
Endpoint (*class* *in* *sushy.resources.fabric.endpoint*), 26
endpoint_protocol (*sushy.resources.fabric.endpoint.Endpoint* *attribute*), 26
EndpointCollection (*class* *in* *sushy.resources.fabric.endpoint*), 26
endpoints (*sushy.resources.compositionservice.resourcezone.EndpointField* *attribute*), 24
endpoints (*sushy.resources.fabric.fabric.Fabric* *property*), 28
entity_pci_id (*sushy.resources.fabric.endpoint.ConnectedEntitiesListField* *attribute*), 25
entity_role (*sushy.resources.fabric.endpoint.ConnectedEntitiesListField* *attribute*), 25
entity_type (*sushy.resources.fabric.endpoint.ConnectedEntitiesListField* *attribute*), 25
F *Fabric* (*class* *in* *sushy.resources.fabric.fabric*), 28
fabric_type (*sushy.resources.fabric.fabric.Fabric* *attribute*), 28
FabricCollection (*class* *in* *sushy.resources.fabric.fabric*), 28
facility_name (*sushy.resources.oem.fake.ProductionLocationField* *attribute*), 34
FakeOEMSystemExtension (*class* *in* *sushy.resources.oem.fake*), 34
FAN_READING_UNIT_PERCENTAGE (*in* *sushy.resources.chassis.thermal.constants*), 15
FAN_READING_UNIT_RPM (*in* *sushy.resources.chassis.thermal.constants*), 15
fans (*sushy.resources.chassis.thermal.thermal.Thermal* *attribute*), 17
FansListField (*class* *in* *sushy.resources.chassis.thermal.thermal*), 15
FieldData (*class* *in* *sushy.resources.base*), 62
filter_query (*sushy.main.ProtocolFeaturesSupportedField* *attribute*), 76
firmware_version (*sushy.resources.chassis.power.power.PowerSupplyListField* *attribute*), 25

attribute), 14
 firmware_version
 (sushy.resources.manager.manager.Manager
 attribute), 30

G

gateway (sushy.resources.fabric.endpoint.IPv4AddressField
 attribute), 27

get () (sushy.connector.Connector method), 72

get_allowed_initialize_volume_values ()
 (sushy.resources.system.storage.volume.Volume
 method), 45

get_allowed_reset_chassis_values ()
 (sushy.resources.chassis.chassis.Chassis
 method), 18

get_allowed_reset_manager_values ()
 (sushy.resources.manager.manager.Manager
 method), 30

get_allowed_reset_system_values ()
 (sushy.resources.system.system.System
 method), 55

get_allowed_system_boot_source_values ()
 (sushy.resources.system.system.System
 method), 55

get_allowed_transfer_protocols ()
 (sushy.resources.updateservice.updateservice.UpdateService
 method), 61

get_chassis () (sushy.main.Sushy method), 76

get_chassis () (sushy.Sushy method), 82

get_chassis_collection ()
 (sushy.main.Sushy method), 76

get_chassis_collection () (sushy.Sushy
 method), 82

get_composition_service ()
 (sushy.main.Sushy method), 77

get_composition_service () (sushy.Sushy
 method), 82

get_data () (sushy.resources.base.AbstractDataReader
 method), 62

get_data () (sushy.resources.base.JsonArchiveReader
 method), 62

get_data () (sushy.resources.base.JsonDataReader
 method), 63

get_data () (sushy.resources.base.JsonPackagedFileReader
 method), 63

get_data () (sushy.resources.base.JsonPublicFileReader
 method), 63

get_drive () (sushy.resources.system.storage.storage.Storage
 method), 43

get_extension () (in module
 sushy.resources.oem.fake), 34

get_fabric () (sushy.main.Sushy method), 77

get_fabric () (sushy.Sushy method), 82

get_fabric_collection ()
 (sushy.main.Sushy method), 77

get_fabric_collection () (sushy.Sushy
 method), 82

get_manager () (sushy.main.Sushy method), 77

get_manager () (sushy.Sushy method), 82

get_manager_collection ()
 (sushy.main.Sushy method), 77

get_manager_collection () (sushy.Sushy
 method), 83

get_member ()
 (sushy.resources.base.ResourceCollectionBase
 method), 65

get_members ()
 (sushy.resources.base.ResourceCollectionBase
 method), 65

get_members_identities () (in module
 sushy.utils), 80

get_message_registry ()
 (sushy.resources.registry.message_registry_file.MessageRegis
 method), 37

get_oem_extension ()
 (sushy.resources.base.ResourceBase
 method), 64

get_reader () (in module sushy.resources.base),
 65

get_reset_system_path ()
 (sushy.resources.oem.fake.FakeOEMSystemExtension
 method), 34

get_resource_extension_by_vendor ()
 (in module sushy.resources.oem), 34

get_resource_extension_by_vendor ()
 (in module sushy.resources.oem.common),
 33

get_session () (sushy.main.Sushy method), 77

get_session () (sushy.Sushy method), 83

get_session_key () (sushy.auth.SessionAuth
 method), 71

get_session_resource_id ()
 (sushy.auth.SessionAuth method), 71

get_session_service () (sushy.main.Sushy
 method), 77

get_session_service () (sushy.Sushy
 method), 83

get_sessions_path () (sushy.main.Sushy
 method), 77

get_sessions_path () (sushy.Sushy method),
 83

get_status ()

(*sushy.resources.settings.SettingsField* method), 68

get_sub_resource_path_by() (in module *sushy.utils*), 80

get_supported_command_shell_types() (*sushy.resources.manager.manager.Manager* method), 30

get_supported_graphical_console_types() (*sushy.resources.manager.manager.Manager* method), 30

get_supported_serial_console_types() (*sushy.resources.manager.manager.Manager* method), 30

get_system() (*sushy.main.Sushy* method), 77

get_system() (*sushy.Sushy* method), 83

get_system_collection() (*sushy.main.Sushy* method), 78

get_system_collection() (*sushy.Sushy* method), 83

get_task() (*sushy.resources.taskservice.taskmonitor.TaskMonitor* method), 59

get_task_monitor() (*sushy.resources.updateservice.updateservice.UpdateService* method), 61

get_update_service() (*sushy.main.Sushy* method), 78

get_update_service() (*sushy.Sushy* method), 83

graphical_console (*sushy.resources.manager.manager.Manager* attribute), 30

GRAPHICAL_CONSOLE_KVMIP (in module *sushy.resources.manager.constants*), 29

GRAPHICAL_CONSOLE_OEM (in module *sushy.resources.manager.constants*), 29

H

headers() (*sushy.resources.base.FieldData* property), 62

health (*sushy.resources.common.StatusField* attribute), 66

health (*sushy.resources.system.system.MemorySummaryField* attribute), 54

health_rollup (*sushy.resources.common.StatusField* attribute), 66

height_mm (*sushy.resources.chassis.chassis.Chassis* attribute), 18

host_reservation_memory_bytes (*sushy.resources.fabric.endpoint.Endpoint* attribute), 26

hostname (*sushy.resources.system.system.System* attribute), 55

http_push_uri (*sushy.resources.updateservice.updateservice.UpdateService* attribute), 61

http_push_uri_targets (*sushy.resources.updateservice.updateservice.UpdateService* attribute), 61

http_push_uri_targets_busy (*sushy.resources.updateservice.updateservice.UpdateService* attribute), 61

HTTPError, 74

I

identification_registers (*sushy.resources.system.processor.ProcessorIdField* attribute), 52

identifiers (*sushy.resources.fabric.endpoint.ConnectedEntitiesListField* attribute), 26

identifiers (*sushy.resources.system.storage.drive.Drive* attribute), 42

identifiers (*sushy.resources.system.storage.storage.StorageController* attribute), 44

identifiers (*sushy.resources.system.storage.volume.Volume* attribute), 45

IdentifiersListField (class in *sushy.resources.common*), 65

identity (*sushy.main.Sushy* attribute), 78

identity (*sushy.resources.chassis.chassis.Chassis* attribute), 18

identity (*sushy.resources.chassis.power.power.Power* attribute), 13

identity (*sushy.resources.chassis.power.power.PowerSupplyListField* attribute), 14

identity (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16

identity (*sushy.resources.chassis.thermal.thermal.Thermal* attribute), 17

identity (*sushy.resources.compositionservice.compositionservice.CompositionService* attribute), 22

identity (*sushy.resources.compositionservice.resourceblock.ResourceBlock* attribute), 23

identity (*sushy.resources.compositionservice.resourcezone.ResourceZone* attribute), 24

identity (*sushy.resources.fabric.endpoint.Endpoint* attribute), 26

identity (*sushy.resources.fabric.fabric.Fabric* attribute), 28

identity (*sushy.resources.manager.manager.Manager* attribute), 30

identity (*sushy.resources.manager.virtual_media.VirtualMedia* attribute), 30

attribute), 32
 identity (*sushy.resources.registry.message_registry.MessageRegistry*), 42
 attribute), 35 indicator_led
 identity (*sushy.resources.registry.message_registry_file.MessageRegistryFile*), 55
 attribute), 37
 identity (*sushy.resources.sessionservice.session.Session*), 38
 attribute), 38 INDICATOR_LED_BLINKING (in module
sushy.resources.constants), 66
 identity (*sushy.resources.sessionservice.sessionservice.SessionService*), 39
 attribute), 39 INDICATOR_LED_LIT (in module
sushy.resources.constants), 66
 identity (*sushy.resources.system.bios.Bios*), 47
 attribute), 47 INDICATOR_LED_OFF (in module
sushy.resources.constants), 66
 identity (*sushy.resources.system.ethernet_interface.EthernetInterface*), 50
 attribute), 50 INDICATOR_LED_UNKNOWN (in module
sushy.resources.constants), 66
 identity (*sushy.resources.system.processor.Processor*), 51
 attribute), 51 initialize (*sushy.resources.system.storage.volume.ActionsField*
 attribute), 45
 identity (*sushy.resources.system.simple_storage.SimpleStorage*), 53
 attribute), 53 initialize_volume ()
 (*sushy.resources.system.storage.volume.Volume*
 method), 45
 identity (*sushy.resources.system.storage.drive.Drive*), 42
 attribute), 42 InitializeActionField (class in
sushy.resources.common), 66
 identity (*sushy.resources.system.storage.storage.Storage*), 43
 attribute), 43 input_ranges
 identity (*sushy.resources.system.storage.volume.Volume*), 45
 attribute), 45 (*sushy.resources.chassis.power.power.PowerSupplyListField*
 attribute), 14
 identity (*sushy.resources.system.system.System*), 55
 attribute), 55 input_type (*sushy.resources.chassis.power.power.InputRangeListField*
 attribute), 13
 identity (*sushy.resources.taskservice.task.Task*), 58
 attribute), 58 INPUT_TYPE_AC (in module
sushy.resources.chassis.power.constants),
 identity (*sushy.resources.updateservice.softwareinventory.SoftwareInventory*), 60
 attribute), 60 INPUT_TYPE_DC (in module
sushy.resources.chassis.power.constants),
 identity (*sushy.resources.updateservice.updateservice.UpdateService*), 61
 attribute), 61 12
 identity (*sushy.Sushy*), 83
 attribute), 83 InputRangeListField (class in
sushy.resources.chassis.power.power),
 IdRefField (class in *sushy.resources.common*),
 65 13
 image (*sushy.resources.manager.virtual_media.VirtualMedia*), 32
 attribute), 32 insert_media
 (*sushy.resources.manager.virtual_media.ActionsField*
 attribute), 32
 image_name (*sushy.resources.manager.virtual_media.VirtualMedia*), 32
 attribute), 32 insert_media ()
 (*sushy.resources.manager.virtual_media.VirtualMedia*
 method), 32
 in_progress ()
 (*sushy.resources.task_monitor.TaskMonitor*
 property), 69 inserted (*sushy.resources.manager.virtual_media.VirtualMedia*
 attribute), 32
 indicator_led
 (*sushy.resources.chassis.chassis.Chassis*
 attribute), 18 instruction_set
 (*sushy.resources.system.processor.Processor*
 attribute), 51
 indicator_led
 (*sushy.resources.chassis.power.power.PowerSupplyListField*
 attribute), 14 initialize () (in module *sushy.utils*), 80
 indicator_led
 (*sushy.resources.chassis.thermal.thermal.FansListField*
 attribute), 15 intrusion_sensor
 (*sushy.resources.chassis.chassis.PhysicalSecurity*
 attribute), 19
 indicator_led
 (*sushy.resources.chassis.chassis.PhysicalSecurity*

attribute), 19
 intrusion_sensor_re_arm
 (*sushy.resources.chassis.chassis.PhysicalSecurity*
 attribute), 19
 invalidate()
 (*sushy.resources.base.ResourceBase*
 method), 64
 InvalidParameterValueError, 74
 involved_switches
 (*sushy.resources.compositionservice.resourcezone.links*
 attribute), 24
 IP_transport_details
 (*sushy.resources.fabric.endpoint.Endpoint*
 attribute), 26
 IPTransportDetailsListField (class in
 sushy.resources.fabric.endpoint), 26
 ipv4_address
 (*sushy.resources.fabric.endpoint.IPTransportDetailsListField*
 attribute), 27
 IPv4AddressField (class in
 sushy.resources.fabric.endpoint), 27
 ipv6_address
 (*sushy.resources.fabric.endpoint.IPTransportDetailsListField*
 attribute), 27
 IPv6AddressField (class in
 sushy.resources.fabric.endpoint), 27
 is_processing()
 (*sushy.resources.taskservice.task.Task*
 property), 58
 is_processing()
 (*sushy.resources.taskservice.taskmonitor.TaskMonitor*
 property), 59
J
 json() (*sushy.resources.base.ResourceBase* *prop-*
 erty), 64
 json_doc() (*sushy.resources.base.FieldData*
 property), 62
 JsonArchiveReader (class in
 sushy.resources.base), 62
 JsonDataReader (class in
 sushy.resources.base), 62
 JsonPackagedFileReader (class in
 sushy.resources.base), 63
 JsonPublicFileReader (class in
 sushy.resources.base), 63
L
 language (*sushy.resources.registry.message_registry.MessageRegistry*
 attribute), 35
 language (*sushy.resources.registry.message_registry_file.LocationListField*
 attribute), 36
 languages (*sushy.resources.registry.message_registry_file.MessageRegistry*
 attribute), 37
 max_power_output_watts
 (*sushy.resources.chassis.power.power.PowerSupplyListField*
 attribute), 14
 lazy_registries() (*sushy.main.Sushy* *prop-*
 erty), 78
 lazy_registries() (*sushy.Sushy* *property*),
 83
 lazy_registries (class in *sushy.main*), 75
 line_input_voltage
 (*sushy.resources.chassis.power.power.PowerSupplyListField*
 attribute), 14
 line_input_voltage_type
 (*sushy.resources.chassis.power.power.PowerSupplyListField*
 attribute), 14
 LINE_INPUT_VOLTAGE_TYPE_AC120
 module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_AC240
 (in module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_AC277
 (in module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_ACDCWIDE
 (in module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_ACHIGH
 (in module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_ACLOW
 (in module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_ACMID
 (in module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_ACWIDE
 (in module
 sushy.resources.chassis.power.constants),
 12
 LINE_INPUT_VOLTAGE_TYPE_DC240
 (in module
 sushy.resources.chassis.power.constants),
 12

12
 LINE_INPUT_VOLTAGE_TYPE_DC380 (in module *sushy.resources.chassis.power.constants*), 12
 LINE_INPUT_VOLTAGE_TYPE_DCNEG48 (in module *sushy.resources.chassis.power.constants*), 13
 LINE_INPUT_VOLTAGE_TYPE_UNKNOWN (in module *sushy.resources.chassis.power.constants*), 13
 links (*sushy.resources.compositionservice.resourcezone.ResourceZone* attribute), 24
 LinksField (class in *sushy.resources.compositionservice.resourcezone*), 24
 ListField (class in *sushy.resources.base*), 63
 location (*sushy.resources.registry.message_registry_file.MessageRegistryFile* attribute), 37
 location_header () (*sushy.resources.task_monitor.TaskMonitor* property), 69
 LocationListField (class in *sushy.resources.registry.message_registry_file*), 36
 lower_threshold_critical (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16
 lower_threshold_fatal (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16
 lower_threshold_non_critical (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16
 lowest_supported_version (*sushy.resources.update.service.softwareinventory.SoftwareInventory* attribute), 60

M

mac_address (*sushy.resources.system.ethernet_interface.EthernetInterface* attribute), 50
 maintenance_window (*sushy.resources.system.bios.Bios* attribute), 47
 maintenance_window (*sushy.resources.system.system.System* attribute), 55
 maintenance_window () (*sushy.resources.settings.SettingsField* property), 68
 maintenance_window_duration_in_seconds (*sushy.resources.common.OperationApplyTimeSupportField* attribute), 66
 maintenance_window_duration_in_seconds (*sushy.resources.settings.MaintenanceWindowField* attribute), 67
 maintenance_window_duration_in_seconds (*sushy.resources.settings.SettingsApplyTimeField* attribute), 68
 maintenance_window_start_time (*sushy.resources.common.OperationApplyTimeSupportField* attribute), 66
 maintenance_window_start_time (*sushy.resources.settings.MaintenanceWindowField* attribute), 67
 maintenance_window_start_time (*sushy.resources.settings.SettingsApplyTimeField* attribute), 68
 MalformedAttributeError, 74
 Manager (class in *sushy.resources.manager.manager*), 30
 manager_type (*sushy.resources.manager.manager.Manager* attribute), 30
 MANAGER_TYPE_AUXILIARY_CONTROLLER (in module *sushy.resources.manager.constants*), 29
 MANAGER_TYPE_BMC (in module *sushy.resources.manager.constants*), 29
 MANAGER_TYPE_ENCLOSURE_MANAGER (in module *sushy.resources.manager.constants*), 29
 MANAGER_TYPE_MANAGEMENT_CONTROLLER (in module *sushy.resources.manager.constants*), 29
 MANAGER_TYPE_RACK_MANAGER (in module *sushy.resources.manager.constants*), 29
 ManagerCollection (class in *sushy.resources.manager.manager*), 31
 managers () (*sushy.resources.chassis.chassis.Chassis* property), 18
 managers () (*sushy.resources.system.system.System*

property), 55
 manufacturer
 (sushy.resources.chassis.chassis.Chassis attribute), 18
 manufacturer
 (sushy.resources.chassis.power.power.PowerSupplyListField attribute), 14
 manufacturer
 (sushy.resources.chassis.thermal.thermal.FansListField attribute), 15
 manufacturer
 (sushy.resources.system.processor.Processor attribute), 51
 manufacturer
 (sushy.resources.system.storage.drive.Drive attribute), 42
 manufacturer
 (sushy.resources.system.system.System attribute), 55
 manufacturer
 (sushy.resources.updateservice.softwareinventory.softwareinventory.SoftwareInventory attribute), 60
 MappedField (class in sushy.resources.base), 63
 MappedListField (class in sushy.resources.base), 63
 max_allowable_operating_value
 (sushy.resources.chassis.thermal.thermal.TemperaturesListField attribute), 16
 max_compositions
 (sushy.resources.compositionservice.resourceblock.CompositionSourceField attribute), 23
 max_concurrent_sessions
 (sushy.resources.manager.manager.RemoteAccessField attribute), 31
 max_drive_size_bytes()
 (sushy.resources.system.storage.storage.StorageCollection property), 44
 max_reading_range
 (sushy.resources.chassis.thermal.thermal.FansListField attribute), 15
 max_reading_range_temp
 (sushy.resources.chassis.thermal.thermal.TemperaturesListField attribute), 16
 max_safe() (in module sushy.utils), 80
 max_size_bytes()
 (sushy.resources.system.simple_storage.SimpleStorageCollection attribute), 53
 max_size_bytes()
 (sushy.resources.system.storage.volume.VolumeCollection property), 46
 max_speed_mhz
 (sushy.resources.system.processor.Processor attribute), 51
 max_volume_size_bytes()
 (sushy.resources.system.storage.storage.StorageCollection property), 44
 max_volume_size_bytes()
 (sushy.resources.system.storage.volume.VolumeCollection property), 46
 maximum_frequency_hz
 (sushy.resources.chassis.power.power.InputRangeListField attribute), 13
 maximum_voltage
 (sushy.resources.chassis.power.power.InputRangeListField attribute), 13
 media_type (sushy.resources.system.storage.drive.Drive attribute), 42
 media_types (sushy.resources.manager.virtual_media.VirtualMedia attribute), 32
 memory_summary
 (sushy.resources.system.system.System attribute), 55
 MemorySummaryField (class in sushy.resources.system.system), 54
 message (sushy.exceptions.ArchiveParsingError attribute), 74
 message (sushy.exceptions.ConnectionError attribute), 74
 message (sushy.exceptions.ExtensionError attribute), 74
 message (sushy.exceptions.HTTPError attribute), 74
 message (sushy.exceptions.InvalidParameterValueError attribute), 74
 message (sushy.exceptions.MalformedAttributeError attribute), 74
 message (sushy.exceptions.MissingActionError attribute), 75
 message (sushy.exceptions.MissingAttributeError attribute), 75
 message (sushy.exceptions.MissingHeaderError attribute), 75
 message (sushy.exceptions.MissingXAuthToken attribute), 75
 message (sushy.exceptions.OEMExtensionNotFound)

attribute), 75
 message (*sushy.exceptions.ResourceNotFoundError attribute*), 75
 message (*sushy.exceptions.SushyError attribute*), 75
 message (*sushy.exceptions.UnknownDefaultError attribute*), 75
 message (*sushy.resources.base.MessageListField attribute*), 63
 message (*sushy.resources.registry.message_registry.MessageDictionaryField attribute*), 35
 message_args (*sushy.resources.base.MessageListField attribute*), 63
 message_id (*sushy.resources.base.MessageListField attribute*), 63
 MessageDictionaryField (class in *sushy.resources.registry.message_registry*), 35
 MessageListField (class in *sushy.resources.base*), 63
 MessageRegistry (class in *sushy.resources.registry.message_registry*), 35
 MessageRegistryFile (class in *sushy.resources.registry.message_registry_file*), 36
 MessageRegistryFileCollection (class in *sushy.resources.registry.message_registry_file*), 37
 messages (*sushy.resources.registry.message_registry.MessageRegistry attribute*), 35
 messages (*sushy.resources.settings.SettingsField attribute*), 68
 messages (*sushy.resources.taskservice.task.Task attribute*), 58
 messages () (*sushy.resources.settings.SettingsUpdate property*), 69
 microcode_info (*sushy.resources.system.processor.ProcessorIdField attribute*), 52
 min_allowable_operating_value (*sushy.resources.chassis.thermal.thermal.TemperatureListField attribute*), 16
 min_reading_range (*sushy.resources.chassis.thermal.thermal.FansListField attribute*), 15
 min_reading_range_temp (*sushy.resources.chassis.thermal.thermal.TemperatureListField attribute*), 16
 minimum_frequency_hz (*sushy.resources.chassis.power.power.InputRangeListField attribute*), 13
 minimum_voltage (*sushy.resources.chassis.power.power.InputRangeListField attribute*), 13
 MissingActionError, 75
 MissingAttributeError, 75
 MissingHeaderError, 75
 MessageDictionaryField (class in *sushy.resources.registry.message_registry*), 35
 mode (*sushy.resources.system.system.BootField attribute*), 54
 model (*sushy.resources.chassis.chassis.Chassis attribute*), 18
 model (*sushy.resources.chassis.power.power.PowerSupplyListField attribute*), 14
 model (*sushy.resources.chassis.thermal.thermal.FansListField attribute*), 15
 model (*sushy.resources.manager.manager.Manager attribute*), 31
 model (*sushy.resources.system.processor.Processor attribute*), 51
 model (*sushy.resources.system.storage.drive.Drive attribute*), 42
 module
 sushy, 81
 sushy.auth, 70
 sushy.connector, 72
 sushy.exceptions, 74
 sushy.main, 75
 sushy.resources, 70
 sushy.resources.base, 62
 sushy.resources.chassis, 22
 sushy.resources.chassis.chassis, 17
 sushy.resources.chassis.constants, 20
 sushy.resources.chassis.mappings, 22
 sushy.resources.chassis.power, 15
 sushy.resources.chassis.power.constants, 12
 sushy.resources.chassis.power.mappings, 13
 sushy.resources.chassis.power.power, 13
 sushy.resources.chassis.thermal, 17
 sushy.resources.chassis.thermal.constants, 15

[sushy.resources.chassis.thermal.mapping](#),
 15
[sushy.resources.chassis.thermal.thermal](#),
 15
[sushy.resources.common](#), 65
[sushy.resources.compositionservice](#),
 25
[sushy.resources.compositionservice.compositionservice](#),
 22
[sushy.resources.compositionservice.constants](#),
 23
[sushy.resources.compositionservice.mappings](#),
 23
[sushy.resources.compositionservice.resourceblock](#),
 23
[sushy.resources.compositionservice.resourcezone](#),
 24
[sushy.resources.constants](#), 66
[sushy.resources.fabric](#), 28
[sushy.resources.fabric.constants](#),
 25
[sushy.resources.fabric.endpoint](#),
 25
[sushy.resources.fabric.fabric](#),
 28
[sushy.resources.fabric.mappings](#),
 28
[sushy.resources.manager](#), 33
[sushy.resources.manager.constants](#),
 29
[sushy.resources.manager.manager](#),
 30
[sushy.resources.manager.mappings](#),
 32
[sushy.resources.manager.virtual_media](#),
 32
[sushy.resources.mappings](#), 67
[sushy.resources.oem](#), 34
[sushy.resources.oem.base](#), 33
[sushy.resources.oem.common](#), 33
[sushy.resources.oem.fake](#), 34
[sushy.resources.registry](#), 38
[sushy.resources.registry.message_registry](#),
 35
[sushy.resources.registry.message_registry.fiber](#),
 36
[sushy.resources.sessionservice](#),
 40
[sushy.resources.sessionservice.session](#),
 38
[sushy.resources.sessionservice.session](#),
 38
[sushy.resources.settings](#), 67
[sushy.resources.system](#), 58
[sushy.resources.system.bios](#), 47
[sushy.resources.system.constants](#),
 49
[sushy.resources.system.ethernet_interface](#),
 50
[sushy.resources.system.mappings](#),
 51
[sushy.resources.system.processor](#),
 51
[sushy.resources.system.simple_storage](#),
 51
[sushy.resources.system.storage](#),
 47
[sushy.resources.system.storage.constants](#),
 40
[sushy.resources.system.storage.drive](#),
 42
[sushy.resources.system.storage.mappings](#),
 43
[sushy.resources.system.storage.storage](#),
 43
[sushy.resources.system.storage.volume](#),
 45
[sushy.resources.system.system](#),
 54
[sushy.resources.task_monitor](#), 69
[sushy.resources.taskservice](#), 59
[sushy.resources.taskservice.mappings](#),
 58
[sushy.resources.taskservice.task](#),
 58
[sushy.resources.taskservice.taskmonitor](#),
 59
[sushy.resources.update_service](#),
 62
[sushy.resources.update_service.constants](#),
 59
[sushy.resources.update_service.mappings](#),
 59
[sushy.resources.update_service.softwareinventory](#),
 60
[sushy.resources.update_service.update_service](#),
 61
[sushy.utils](#), 79
N
[name \(sushy.main.Sushy attribute\)](#), 78
[name \(sushy.resources.base.ResourceCollectionBase\)](#),
 78

attribute), 65
 name (sushy.resources.chassis.chassis.Chassis attribute), 18
 name (sushy.resources.chassis.power.power.Power attribute), 14
 name (sushy.resources.chassis.power.power.PowerSupplyListField attribute), 14
 name (sushy.resources.chassis.thermal.thermal.Sensor attribute), 16
 name (sushy.resources.chassis.thermal.thermal.Thermal attribute), 17
 name (sushy.resources.compositionservice.compositionservice.CompositionService attribute), 22
 name (sushy.resources.compositionservice.resourceblock.ResourceBlock attribute), 23
 name (sushy.resources.compositionservice.resourceblock.ResourceBlockCollection attribute), 24
 name (sushy.resources.compositionservice.resourcezone.ResourceZone attribute), 24
 name (sushy.resources.compositionservice.resourcezone.ResourceZoneCollection attribute), 25
 name (sushy.resources.fabric.endpoint.Endpoint attribute), 26
 name (sushy.resources.fabric.fabric.Fabric attribute), 28
 name (sushy.resources.manager.manager.Manager attribute), 31
 name (sushy.resources.manager.virtual_media.VirtualMedia attribute), 32
 name (sushy.resources.registry.message_registry.MessageRegistry attribute), 35
 name (sushy.resources.registry.message_registry_file.MessageRegistryFile attribute), 37
 name (sushy.resources.sessionservice.session.Session attribute), 38
 name (sushy.resources.sessionservice.session.SessionCollection attribute), 38
 name (sushy.resources.sessionservice.sessionservice.SessionService attribute), 39
 name (sushy.resources.system.bios.Bios attribute), 47
 name (sushy.resources.system.ethernet_interface.EthernetInterface attribute), 50
 name (sushy.resources.system.simple_storage.DeviceListField attribute), 53
 name (sushy.resources.system.simple_storage.SimpleStorage attribute), 53
 name (sushy.resources.system.storage.drive.Drive attribute), 42
 name (sushy.resources.system.storage.storage.Storage attribute), 43
 name (sushy.resources.system.storage.storage.StorageControllersListField attribute), 44
 name (sushy.resources.system.storage.volume.Volume attribute), 45
 name (sushy.resources.system.system.System attribute), 55
 name (sushy.resources.taskservice.task.Task attribute), 58
 name (sushy.resources.update-service.softwareinventory.SoftwareInventory attribute), 60
 name (sushy.resources.update-service.softwareinventory.SoftwareInventoryService attribute), 61
 name (sushy.resources.update-service.update-service.UpdateService attribute), 61
 name (sushy.Sushy attribute), 83
 name (sushy.resources.settings), 67
 name (sushy.ResourceZone args (sushy.resources.registry.message_registry.MessageDictionary attribute), 23
 number_of_compositions (sushy.resources.compositionservice.resourceblock.Composition attribute), 23
O
 oem_vendors (sushy.resources.base.ResourceBase attribute), 64
 OEMResourceBase (class in sushy.resources.oem.base), 33
 only_member_query (sushy.Chain.ProtocolFeaturesSupportedField attribute), 76
 operation_apply_time_support (sushy.resources.common.ActionField attribute), 65
 operation_apply_time_support (sushy.resources.system.storage.volume.Volume attribute), 46
 operation_apply_time_support (sushy.resources.system.storage.volume.VolumeCollection attribute), 46
 operation_apply_time_support () (sushy.resources.settings.SettingsField property), 68
 OperationApplyTimeSupportField (class in sushy.resources.common), 66
 output_wattage (sushy.resources.chassis.power.power.InputRangeListField attribute), 13
 owning_entity

(*sushy.resources.registry.message_registry.MessageRegistry* attribute), 35

sushy.resources.chassis.chassis), 19

port (*sushy.resources.fabric.endpoint.IPTransportDetailsListField* attribute), 27

post () (*sushy.connector.Connector* method), 73

param_types (*sushy.resources.registry.message_registry.MessageDictionaryField* class in attribute), 35

parse_message () (in module *sushy.resources.chassis.power.power*), 13

parse_messages () (*sushy.resources.taskservice.task.Task* method), 58

power () (*sushy.resources.chassis.chassis.Chassis* property), 18

power_capacity_watts (*sushy.resources.chassis.power.power.PowerSupplyListField* attribute), 14

power_state (*sushy.resources.chassis.chassis.Chassis* attribute), 18

power_supply (*sushy.resources.system.system.System* attribute), 55

power_supply_off (*sushy.resources.constants*), 67

power_supply_on (*sushy.resources.constants*), 67

power_supply_powering_off (*sushy.resources.constants*), 67

power_supply_powering_on (*sushy.resources.constants*), 67

power_supplies (*sushy.resources.chassis.power.power.PowerSupplyListField* attribute), 14

power_supply_type (*sushy.resources.chassis.power.power.PowerSupplyListField* attribute), 14

POWER_SUPPLY_TYPE_AC (in module *sushy.resources.chassis.power.constants*), 13

POWER_SUPPLY_TYPE_ACDC (in module *sushy.resources.chassis.power.constants*), 13

POWER_SUPPLY_TYPE_DC (in module *sushy.resources.chassis.power.constants*), 13

POWER_SUPPLY_TYPE_UNKNOWN (in module *sushy.resources.chassis.power.constants*), 13

POWER_SUPPLY_TYPE_UNKOWN (in module *sushy.resources.chassis.power.constants*), 13

power_supply_list (*sushy.resources.chassis.power.power.PowerSupplyListField* class in attribute), 50

physical_context (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16

physical_security (*sushy.resources.chassis.chassis.Chassis* attribute), 18

PhysicalSecurity (class in *sushy.resources.system.processor*), 51

processor_architecture

<i>(sushy.resources.system.processor.Processor attribute)</i> , 51	40
processor_id <i>(sushy.resources.system.processor.Processor attribute)</i> , 51	RAID_TYPE_RAID10 (in module <i>sushy.resources.system.storage.constants</i>), 40
processor_type <i>(sushy.resources.system.processor.Processor attribute)</i> , 51	RAID_TYPE_RAID10E (in module <i>sushy.resources.system.storage.constants</i>), 40
ProcessorCollection (class in <i>sushy.resources.system.processor</i>), 52	RAID_TYPE_RAID10Triple (in module <i>sushy.resources.system.storage.constants</i>), 40
ProcessorIdField (class in <i>sushy.resources.system.processor</i>), 52	RAID_TYPE_RAID1E (in module <i>sushy.resources.system.storage.constants</i>), 40
processors () <i>(sushy.resources.system.system.System property)</i> , 55	RAID_TYPE_RAID1Triple (in module <i>sushy.resources.system.storage.constants</i>), 40
ProcessorSummary (class in <i>sushy.resources.system.processor</i>), 52	RAID_TYPE_RAID3 (in module <i>sushy.resources.system.storage.constants</i>), 40
product (<i>sushy.main.Sushy attribute</i>), 78	RAID_TYPE_RAID4 (in module <i>sushy.resources.system.storage.constants</i>), 40
product (<i>sushy.Sushy attribute</i>), 83	RAID_TYPE_RAID5 (in module <i>sushy.resources.system.storage.constants</i>), 41
production_location <i>(sushy.resources.oem.fake.FakeOEMSystemExtension attribute)</i> , 34	RAID_TYPE_RAID50 (in module <i>sushy.resources.system.storage.constants</i>), 41
ProductionLocationField (class in <i>sushy.resources.oem.fake</i>), 34	RAID_TYPE_RAID6 (in module <i>sushy.resources.system.storage.constants</i>), 41
protocol (<i>sushy.resources.system.storage.drive.Drive attribute</i>), 42	RAID_TYPE_RAID60 (in module <i>sushy.resources.system.storage.constants</i>), 41
protocol_features_supported <i>(sushy.main.Sushy attribute)</i> , 78	RAID_TYPE_RAID6TP (in module <i>sushy.resources.system.storage.constants</i>), 41
protocol_features_supported <i>(sushy.Sushy attribute)</i> , 84	raid_types (<i>sushy.resources.system.storage.storage.StorageControlListField attribute</i>), 44
ProtocolFeaturesSupportedField (class in <i>sushy.main</i>), 76	raise_for_response () (in module <i>sushy.exceptions</i>), 75
publication_uri <i>(sushy.resources.registry.message_registry_file.Location attribute)</i> , 36	reading (<i>sushy.resources.chassis.thermal.thermal.FansListField attribute</i>), 15
put () (<i>sushy.connector.Connector method</i>), 73	reading_celsius (<i>sushy.resources.chassis.thermal.thermal.TemperaturesListField attribute</i>), 16
R	reading_units (<i>sushy.resources.chassis.thermal.thermal.FansListField attribute</i>), 15
raid_type (<i>sushy.resources.system.storage.volume.Volume attribute</i>), 46	redfish_version (<i>sushy.resources.base.ResourceBase attribute</i>), 15
RAID_TYPE_RAID0 (in module <i>sushy.resources.system.storage.constants</i>), 40	
RAID_TYPE_RAID00 (in module <i>sushy.resources.system.storage.constants</i>), 40	
RAID_TYPE_RAID01 (in module <i>sushy.resources.system.storage.constants</i>), 40	
RAID_TYPE_RAID1 (in module <i>sushy.resources.system.storage.constants</i>), 40	

attribute), 64
refresh() (*sushy.resources.base.ResourceBase method*), 64
refresh() (*sushy.resources.taskservice.taskmonitor.TaskMonitor method*), 59
refresh_session() (*sushy.auth.SessionAuth method*), 71
refresh_session() (*sushy.auth.SessionOrBasicAuth method*), 71
registries() (*sushy.main.LazyRegistries property*), 75
registries() (*sushy.main.Sushy property*), 78
registries() (*sushy.resources.base.ResourceBase property*), 65
registries() (*sushy.Sushy property*), 84
registry (*sushy.resources.registry.message_registry_file.MessageRegistryFile attribute*), 37
registry_prefix (*sushy.resources.registry.message_registry.MessageRegistry attribute*), 35
registry_version (*sushy.resources.registry.message_registry.MessageRegistry attribute*), 36
RegistryType (*class in sushy.resources.registry.message_registry_file*), 37
related_item (*sushy.resources.updateservice.softwareinventory.SoftwareInventory attribute*), 60
release_date (*sushy.resources.updateservice.softwareinventory.SoftwareInventory attribute*), 60
RemoteAccessField (*class in sushy.resources.manager.manager*), 31
reserved_state (*sushy.resources.compositionservice.resourceblock.ResourceBlock attribute*), 23
reset (*sushy.resources.chassis.chassis.ActionsField attribute*), 17
reset (*sushy.resources.manager.manager.ActionsField attribute*), 30
reset (*sushy.resources.oem.fake.ContosoActionsField attribute*), 34
reset (*sushy.resources.system.system.ActionsField attribute*), 54
reset_bios (*sushy.resources.system.bios.ActionsField attribute*), 47
reset_bios() (*sushy.resources.system.bios.Bios method*), 47
reset_chassis() (*sushy.resources.chassis.chassis.Chassis method*), 18
reset_manager() (*sushy.resources.manager.manager.Manager method*), 31
RESET_MANAGER_FORCE_RESTART (*in module sushy.resources.manager.constants*), 29
RESET_MANAGER_GRACEFUL_RESTART (*in module sushy.resources.manager.constants*), 29
reset_session_attrs() (*sushy.auth.SessionAuth method*), 71
reset_system() (*sushy.resources.system.system.System method*), 56
RESET_TYPE_FORCE_OFF (*in module sushy.resources.constants*), 67
RESET_TYPE_FORCE_ON (*in module sushy.resources.constants*), 67
RESET_TYPE_FORCE_RESTART (*in module sushy.resources.constants*), 67
RESET_TYPE_GRACEFUL_RESTART (*in module sushy.resources.constants*), 67
RESET_TYPE_GRACEFUL_SHUTDOWN (*in module sushy.resources.constants*), 67
RESET_TYPE_NMI (*in module sushy.resources.constants*), 67
RESET_TYPE_ON (*in module sushy.resources.constants*), 67
RESET_TYPE_POWER_CYCLE (*in module sushy.resources.constants*), 67
RESET_TYPE_PUSH_POWER_BUTTON (*in module sushy.resources.constants*), 67
ResetActionField (*class in sushy.resources.common*), 66
ResourceComposition (*SushyField attribute*), 63
resolution (*sushy.resources.registry.message_registry.MessageDictionary attribute*), 35
resource_block_type (*sushy.resources.compositionservice.resourceblock.ResourceBlock attribute*), 23
resource_blocks (*sushy.resources.compositionservice.resourcezone.LinksField attribute*), 24
resource_blocks() (*sushy.resources.compositionservice.compositionservice.CompositionService property*), 22

resource_name() (*sushy.resources.base.ResourceBase* property), 65
resource_uri (*sushy.resources.common.IdRefField* attribute), 65
resource_uri() (*sushy.resources.settings.SettingsField* property), 69
resource_zones() (*sushy.resources.compositionservice.compositionservice.CompositionService* attribute), 22
ResourceBase (class in *sushy.resources.base*), 64
ResourceBlock (class in *sushy.resources.compositionservice.resourceblock*), 23
ResourceBlockCollection (class in *sushy.resources.compositionservice.resourceblock*), 23
ResourceCollectionBase (class in *sushy.resources.base*), 65
ResourceNotFoundError, 75
ResourceZone (class in *sushy.resources.compositionservice.resourcezone*), 24
ResourceZoneCollection (class in *sushy.resources.compositionservice.resourcezone*), 24
response() (*sushy.resources.task_monitor.TaskMonitor* property), 69
retry_after() (*sushy.resources.task_monitor.TaskMonitor* property), 69
retry_after() (*sushy.resources.taskservice.taskmonitor.TaskMonitor* property), 59
revert_dictionary() (in module *sushy.utils*), 81
S
sanitize() (in module *sushy.utils*), 81
select_query (*sushy.main.ProtocolFeaturesSupportedField* attribute), 76
Sensor (class in *sushy.resources.chassis.thermal.thermal*), 15
sensor_number (*sushy.resources.chassis.thermal.thermal.TemperatureListField* attribute), 16
serial_console (*sushy.resources.manager.manager.Manager* attribute), 31
SERIAL_CONSOLE_IPMI (in module *sushy.resources.manager.constants*), 29
SERIAL_CONSOLE_OEM (in module *sushy.resources.manager.constants*), 29
SERIAL_CONSOLE_SSH (in module *sushy.resources.manager.constants*), 29
SERIAL_CONSOLE_TELNET (in module *sushy.resources.manager.constants*), 29
serial_number (*sushy.resources.chassis.chassis.Chassis* attribute), 18
serial_number (*sushy.resources.chassis.power.power.PowerSupplyListField* attribute), 14
serial_number (*sushy.resources.chassis.thermal.thermal.FansListField* attribute), 15
serial_number (*sushy.resources.system.storage.drive.Drive* attribute), 42
serial_number (*sushy.resources.system.system.System* attribute), 56
ServerSideError, 75
service_enabled (*sushy.resources.compositionservice.compositionservice.CompositionService* attribute), 22
service_enabled (*sushy.resources.manager.manager.RemoteAccessField* attribute), 31
service_enabled (*sushy.resources.sessionservice.sessionservice.SessionService* attribute), 39
service_enabled (*sushy.resources.updateupdate.service.updateupdate.service.UpdateService* attribute), 61
Session (class in *sushy.resources.sessionservice.session*), 38
session_timeout (*sushy.resources.sessionservice.sessionservice.SessionService* attribute), 39
SessionAuth (class in *sushy.auth*), 70
session_auth_listfieldcollection (class in *sushy.resources.sessionservice.session*), 39

- 38
- SessionOrBasicAuth (class in *sushy.auth*), 71
- sessions() (*sushy.resources.sessionservice.sessionservice.SessionService* property), 39
- SessionService (class in *sushy.resources.sessionservice.sessionservice*), 39
- set_attribute() (*sushy.resources.system.bios.Bios* method), 47
- set_attributes() (*sushy.resources.system.bios.Bios* method), 48
- set_auth() (*sushy.connector.Connector* method), 74
- set_connection() (*sushy.resources.base.AbstractDataReader* method), 62
- set_context() (*sushy.auth.AuthBase* method), 70
- set_http_basic_auth() (*sushy.connector.Connector* method), 74
- set_http_session_auth() (*sushy.connector.Connector* method), 74
- set_indicator_led() (*sushy.resources.chassis.chassis.Chassis* method), 19
- set_indicator_led() (*sushy.resources.system.storage.drive.Drive* method), 42
- set_indicator_led() (*sushy.resources.system.system.System* method), 56
- set_parent_resource() (*sushy.resources.oem.base.OEMResourceBasesoftware_id* method), 33
- set_retry_after() (*sushy.resources.task_monitor.TaskMonitor* method), 69
- set_system_boot_options() (*sushy.resources.system.system.System* method), 56
- set_system_boot_source() (*sushy.resources.system.system.System* method), 56
- setdefaultattr() (in module *sushy.utils*), 81
- SettingsApplyTimeField (class in *sushy.resources.settings*), 68
- SettingsField (class in *sushy.resources.settings*), 68
- SettingsUpdate (class in *sushy.resources.settings*), 69
- severity (*sushy.resources.base.MessageListField* attribute), 63
- severity (*sushy.resources.registry.message_registry.MessageDictionary* attribute), 35
- sharing_capable (*sushy.resources.compositionservice.resourceblock.CompositionBlock* attribute), 23
- sharing_enabled (*sushy.resources.compositionservice.resourceblock.CompositionBlock* attribute), 23
- simple_storage() (*sushy.resources.system.system.System* property), 57
- simple_update (*sushy.resources.updateservice.updateservice.ActionsField* attribute), 61
- simple_update() (*sushy.resources.updateservice.updateservice.UpdateService* method), 61
- SimpleStorage (class in *sushy.resources.system.simple_storage*), 53
- SimpleStorageCollection (class in *sushy.resources.system.simple_storage*), 53
- size_gib (*sushy.resources.system.system.MemorySummaryField* attribute), 54
- sku (*sushy.resources.chassis.chassis.Chassis* attribute), 19
- sku (*sushy.resources.system.system.System* attribute), 57
- sleep_for() (*sushy.resources.task_monitor.TaskMonitor* property), 70
- socket (*sushy.resources.system.processor.Processor* attribute), 52
- software_id (*sushy.resources.updateservice.softwareinventory.SoftwareInventory* attribute), 60
- software_inventory() (*sushy.resources.updateservice.updateservice.UpdateService* property), 61
- SoftwareInventory (class in *sushy.resources.updateservice.softwareinventory*), 60
- SoftwareInventoryCollection (class in *sushy.resources.updateservice.softwareinventory*), 60
- spare_part_number (*sushy.resources.chassis.power.power.PowerSupplyListField* attribute), 14
- speed_gbps (*sushy.resources.system.storage.storage.StorageController* attribute), 52

attribute), 44
 speed_mbps (*sushy.resources.system.ethernet_interface.EthernetInterface* attribute), 51
 start_time (*sushy.resources.taskservice.task.Task* attribute), 58
 state (*sushy.resources.common.StatusField* attribute), 66
 status (*sushy.resources.chassis.chassis.Chassis* attribute), 19
 status (*sushy.resources.chassis.power.power.PowerSupplyListField* attribute), 14
 status (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16
 status (*sushy.resources.chassis.thermal.thermal.Thermal* attribute), 17
 status (*sushy.resources.compositionservice.compositionservice.CompositionService* attribute), 22
 status (*sushy.resources.compositionservice.resourceblock.ResourceBlock* attribute), 23
 status (*sushy.resources.compositionservice.resourcezone.ResourceZone* attribute), 24
 status (*sushy.resources.fabric.endpoint.Endpoint* attribute), 26
 status (*sushy.resources.fabric.fabric.Fabric* attribute), 28
 status (*sushy.resources.system.ethernet_interface.EthernetInterface* attribute), 51
 status (*sushy.resources.system.processor.Processor* attribute), 52
 status (*sushy.resources.system.simple_storage.DeviceListField* attribute), 53
 status (*sushy.resources.system.storage.drive.Drive* attribute), 42
 status (*sushy.resources.system.storage.storage.Storage* attribute), 43
 status (*sushy.resources.system.storage.storage.StorageControllersListField* attribute), 45
 status (*sushy.resources.system.system.System* attribute), 57
 status (*sushy.resources.updateservice.softwareinventory.SoftwareInventory* attribute), 60
 status (*sushy.resources.updateservice.updateservice.UpdateService* attribute), 61
 status () (*sushy.resources.settings.SettingsUpdate* property), 69
 status_code (*sushy.exceptions.HTTPError* attribute), 74
 status_code () (*sushy.resources.base.FieldData* property), 62
 StatusField (class in *sushy.resources.common*), 66
 Storage (class in *sushy.resources.system.storage.storage*), 43
 storage () (*sushy.resources.system.system.System* property), 57
 storage_controllers (*sushy.resources.system.storage.storage.StorageCollection* (class in *sushy.resources.system.storage.storage*), 44
StorageControllersListField (class in *sushy.resources.system.storage.storage*), 44
 sub_processors () (*sushy.resources.system.processor.Processor* property), 52
 sub_resource_block (*sushy.resources.fabric.endpoint.Ipv4AddressField* attribute), 27
 sub_resource_zone (*sushy.resources.fabric.endpoint.PcIdField* attribute), 27
 subsystem_vendor_id (*sushy.resources.fabric.endpoint.PcIdField* attribute), 27
 summary () (*sushy.resources.system.processor.ProcessorCollection* property), 52
 supported_apply_times () (*sushy.resources.system.bios.Bios* property), 48
 supported_values (*sushy.resources.common.OperationApplyTimeSupportField* attribute), 66
 Sushy (class in *sushy*), 81
 Sushy (class in *sushy.main*), 76
 sushy.exceptions module, 74
 sushy.main module, 75
 sushy.resources module, 70
 sushy.resources.base module, 62

[sushy.resources.chassis](#)
 [module, 22](#)
[sushy.resources.chassis.chassis](#)
 [module, 17](#)
[sushy.resources.chassis.constants](#)
 [module, 20](#)
[sushy.resources.chassis.mappings](#)
 [module, 22](#)
[sushy.resources.chassis.power](#)
 [module, 15](#)
[sushy.resources.chassis.power.constants](#)
 [module, 12](#)
[sushy.resources.chassis.power.mappings](#)
 [module, 13](#)
[sushy.resources.chassis.power.power](#)
 [module, 13](#)
[sushy.resources.chassis.thermal](#)
 [module, 17](#)
[sushy.resources.chassis.thermal.constants](#)
 [module, 15](#)
[sushy.resources.chassis.thermal.mappings](#)
 [module, 15](#)
[sushy.resources.chassis.thermal.thermal](#)
 [module, 15](#)
[sushy.resources.common](#)
 [module, 65](#)
[sushy.resources.compositionservice](#)
 [module, 25](#)
[sushy.resources.compositionservice.compositionservice](#)
 [module, 22](#)
[sushy.resources.compositionservice.constants](#)
 [module, 23](#)
[sushy.resources.compositionservice.mappings](#)
 [module, 23](#)
[sushy.resources.compositionservice.resources](#)
 [module, 23](#)
[sushy.resources.compositionservice.resources](#)
 [module, 24](#)
[sushy.resources.constants](#)
 [module, 66](#)
[sushy.resources.fabric](#)
 [module, 28](#)
[sushy.resources.fabric.constants](#)
 [module, 25](#)
[sushy.resources.fabric.endpoint](#)
 [module, 25](#)
[sushy.resources.fabric.fabric](#)
 [module, 28](#)
[sushy.resources.fabric.mappings](#)
 [module, 28](#)
[sushy.resources.manager](#)
 [module, 33](#)
[sushy.resources.manager.constants](#)
 [module, 29](#)
[sushy.resources.manager.manager](#)
 [module, 30](#)
[sushy.resources.manager.mappings](#)
 [module, 32](#)
[sushy.resources.manager.virtual_media](#)
 [module, 32](#)
[sushy.resources.mappings](#)
 [module, 67](#)
[sushy.resources.oem](#)
 [module, 34](#)
[sushy.resources.oem.base](#)
 [module, 33](#)
[sushy.resources.oem.common](#)
 [module, 33](#)
[sushy.resources.oem.fake](#)
 [module, 34](#)
[sushy.resources.registry](#)
 [module, 38](#)
[sushy.resources.registry.message_registry](#)
 [module, 35](#)
[sushy.resources.registry.message_registry_file](#)
 [module, 36](#)
[sushy.resources.sessionservice](#)
 [module, 40](#)
[sushy.resources.sessionservice.session](#)
 [module, 38](#)
[sushy.resources.sessionservice.sessionservice](#)
 [module, 39](#)
[sushy.resources.settings](#)
 [module, 67](#)
[sushy.resources.system](#)
 [module, 58](#)
[sushy.resources.system.bios](#)
 [module, 47](#)
[sushy.resources.system.constants](#)
 [module, 49](#)
[sushy.resources.system.ethernet_interface](#)
 [module, 50](#)
[sushy.resources.system.mappings](#)
 [module, 51](#)
[sushy.resources.system.processor](#)
 [module, 51](#)
[sushy.resources.system.simple_storage](#)
 [module, 53](#)
[sushy.resources.system.storage](#)
 [module, 47](#)
[sushy.resources.system.storage.constants](#)
 [module, 40](#)

sushy.resources.system.storage.drive module, 42
 sushy.resources.system.storage.mappings module, 43
 sushy.resources.system.storage.storage_type module, 43
 sushy.resources.system.storage.volumes module, 45
 sushy.resources.system.system module, 54
 sushy.resources.task_monitor module, 69
 sushy.resources.taskservice module, 59
 sushy.resources.taskservice.mappings module, 58
 sushy.resources.taskservice.task module, 58
 sushy.resources.taskservice.taskmonitor module, 59
 sushy.resources.update_service module, 62
 sushy.resources.update_service.constants module, 59
 sushy.resources.update_service.mappings module, 59
 sushy.resources.update_service.software_inventory module, 60
 sushy.resources.update_service.update_service module, 61
 sushy.utils module, 79
 SushyError, 75
 synchronized() (in module sushy.utils), 81
 System (class in sushy.resources.system.system), 54
 SYSTEM_INDICATOR_LED_BLINKING (in module sushy.resources.system.constants), 49
 SYSTEM_INDICATOR_LED_LIT (in module sushy.resources.system.constants), 49
 SYSTEM_INDICATOR_LED_OFF (in module sushy.resources.system.constants), 49
 SYSTEM_INDICATOR_LED_UNKNOWN (in module sushy.resources.system.constants), 49
 SYSTEM_POWER_STATE_OFF (in module sushy.resources.system.constants), 49
 SYSTEM_POWER_STATE_ON (in module sushy.resources.system.constants), 50
 SYSTEM_POWER_STATE_POWERING_OFF (in module sushy.resources.system.constants), 50
 SYSTEM_POWER_STATE_POWERING_ON (in module sushy.resources.system.constants), 50
 SYSTEM_TYPE_COMPOSED (in module sushy.resources.system.constants), 50
 SYSTEM_TYPE_OS (in module sushy.resources.system.constants), 50
 SYSTEM_TYPE_PHYSICAL (in module sushy.resources.system.constants), 50
 SYSTEM_TYPE_PHYSICALLY_PARTITIONED (in module sushy.resources.system.constants), 50
 SYSTEM_TYPE_VIRTUAL (in module sushy.resources.system.constants), 50
 SYSTEM_TYPE_VIRTUALLY_PARTITIONED (in module sushy.resources.system.constants), 50
 SystemCollection (class in sushy.resources.system.system), 57
 systems() (sushy.resources.chassis.chassis.Chassis property), 19
 systems() (sushy.resources.manager.manager.Manager property), 31
 target_uri (sushy.resources.common.ActionField attribute), 65
 Task (class in sushy.resources.taskservice.task), 58
 task() (sushy.resources.taskservice.taskmonitor.TaskMonitor property), 59
 task_monitor (sushy.resources.taskservice.task.Task attribute), 58
 task_monitor() (sushy.resources.taskservice.taskmonitor.TaskMonitor property), 59
 task_state (sushy.resources.taskservice.task.Task attribute), 58
 task_status (sushy.resources.taskservice.task.Task attribute), 58
 TaskMonitor (class in sushy.resources.task_monitor), 69
 TaskMonitor (class in sushy.resources.taskservice.taskmonitor), 59
 temperatures

(*sushy.resources.chassis.thermal.thermal.Thermal* attribute), 17

TemperaturesListField (class in *sushy.resources.chassis.thermal.thermal*), 16

Thermal (class in *sushy.resources.chassis.thermal.thermal*), 16

thermal() (*sushy.resources.chassis.chassis.Chassis* property), 19

time (*sushy.resources.settings.SettingsField* attribute), 69

total_cores (*sushy.resources.system.processor.Processor* attribute), 52

total_threads (*sushy.resources.system.processor.Processor* attribute), 52

transport_protocol (*sushy.resources.fabric.endpoint.IPTransportDeviceListField* attribute), 27

U

uefi_device_paths (*sushy.resources.updateservice.softwareinventory.softwareinventory* attribute), 60

UnknownDefaultError, 75

UPDATE_FAILURE (in module *sushy.resources.settings*), 69

UPDATE_PENDING (in module *sushy.resources.settings*), 69

update_status() (*sushy.resources.system.bios.Bios* property), 48

UPDATE_SUCCESS (in module *sushy.resources.settings*), 69

UPDATE_UNKNOWN (in module *sushy.resources.settings*), 69

updateable (*sushy.resources.updateservice.softwareinventory.softwareinventory* attribute), 60

UpdateService (class in *sushy.resources.updateservice.updateservice*), 61

upper_threshold_critical (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16

upper_threshold_fatal (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16

upper_threshold_non_critical (*sushy.resources.chassis.thermal.thermal.Sensor* attribute), 16

url (*sushy.resources.registry.message_registry_file.LocationListField* attribute), 36

username (*sushy.resources.session.service.session.Session* attribute), 38

uuid (*sushy.main.Sushy* attribute), 78

uuid (*sushy.resources.chassis.chassis.Chassis* attribute), 19

uuid (*sushy.resources.manager.manager.Manager* attribute), 31

uuid (*sushy.resources.system.system.System* attribute), 57

uuid (*sushy.Sushy* attribute), 84

V

vendor_id (*sushy.resources.fabric.endpoint.PciIdField* attribute), 28

vendor_id (*sushy.resources.system.processor.ProcessorIdField* attribute), 52

VendorListField (*sushy.resources.updateservice.softwareinventory.softwareinventory* attribute), 60

virtual_media() (*sushy.resources.manager.manager.Manager* property), 31

VirtualMediaInventory (class in *sushy.resources.manager.virtual_media*), 32

VirtualMediaCollection (class in *sushy.resources.manager.virtual_media*), 33

Volume (class in *sushy.resources.system.storage.volume*), 45

VOLUME_INIT_TYPE_FAST (in module *sushy.resources.system.storage.constants*), 41

VOLUME_INIT_TYPE_SLOW (in module *sushy.resources.system.storage.constants*), 41

VOLUME_TYPE_MIRRORED (in module *sushy.resources.system.storage.constants*), 41

VOLUME_TYPE_NON_REDUNDANT (in module *sushy.resources.system.storage.constants*), 41

VOLUME_TYPE_RAW_DEVICE (in module *sushy.resources.system.storage.constants*), 41

VOLUME_TYPE_SPANNED_MIRRORS (in module *sushy.resources.system.storage.constants*), 41

41
VOLUME_TYPE_SPANNED_STRIPES_WITH_PARITY
(in *module*
sushy.resources.system.storage.constants),
41
VOLUME_TYPE_STRIPED_WITH_PARITY
(in *module*
sushy.resources.system.storage.constants),
41
VolumeCollection (class in
sushy.resources.system.storage.volume), 46
volumes () (*sushy.resources.system.storage.storage.Storage*
property), 43
volumes_sizes_bytes ()
(*sushy.resources.system.storage.storage.StorageCollection*
property), 44
volumes_sizes_bytes ()
(*sushy.resources.system.storage.volume.VolumeCollection*
property), 46

W

weight_kg (*sushy.resources.chassis.chassis.Chassis*
attribute), 19
width_mm (*sushy.resources.chassis.chassis.Chassis*
attribute), 19
write_protected
(*sushy.resources.manager.virtual_media.VirtualMedia*
attribute), 33